




**OPERATION AND
MAINTENANCE**

MANUAL


ARPAC BRAND

MODEL: TS-2300

SN: 210011

JOB: 220562-1-1


The nVenia
Family of
Brands



NVENIA

A DURAVANT COMPANY

Table of Contents



Prelude i - Record of Revision

Revision History	ii-1
Warranty Information	ii-1

Prelude ii - Project Layout & Specifications

ii 1.1 Overview	ii-1
ii 1.2 Layout	ii-2
ii 1.3 Project Specifications.....	ii-3

Chapter 1 - Introduction

1.1 Introduction	1-1
1.2 Using This Manual	1-2
1.2.1 Graphical Notations	1-2
1.2.2 Photo's & Illustrations	1-3
1.2.3 Manual Design & Layout	1-4
1.3 TrayStar™ Series Design Features	1-6
1.4 TrayStar™ Series Concept of Operations.	1-7

Chapter 2 - Safety

2.1 Safety	2-1
2.1.1 Statement of Liability	2-1
2.2 Safety Precautions	2-2
2.1.1 Interfacing Equipment	2-2
2.1.2 Dressing for Safety	2-2
2.1.3 Maintaining a Clean Work Area	2-2
2.3 Personnel Instructions (PPE)	2-3
2.4 Safety Labels	2-4
2.5 Energy Isolation Devices	2-5
2.5.1 Main Disconnect Switch	2-5
2.2.2 Emergency Stop Pushbuttons	2-6
2.5.3 Chain Guards & Guard Doors	2-8
2.5.4 Motor Disconnects (If Equipped)	2-9
2.6 Lockout / Tagout	2-10
2.6.1 Electrical LOTO	2-11
2.6.2 Pneumatic LOTO	2-12
2.6.3 Restoring Power	2-12

Chapter 3 - Mechanical Assemblies

3.1 Overview	3-1
3.2 Product Handling	3-5
3.2.1 In-feed Conveyor	3-5
3.2.2 Product Agitator & Min. Accumulation Sensor	3-9
3.2.3 Product Collator	3-11
3.2.4 Collator Escapement Flight Bars	3-14
3.2.5 Pacing Flight Bars	3-17

3.3 Tray Handling / Tray Forming	3-22
3.3.1 Extended Tray Magazine	3-22
3.3.2 Blank Feed Magazine	3-26
3.3.3 Lugged Blank Feed Conveyor	3-30
3.3.4 Tray Former Assemblies	3-32
3.3.5 Hot Melt System	3-36
3.3.6 Compression Section	3-37

Chapter 4 - Operator Controls

4.1 Main disconnect (Power On) Switch	4-1
4.2 Main Control Panel (Operator's Station)	4-2
4.2.1 HMI	4-2
4.2.2 Push Button Controls	4-3
4.2.3 Status Beacon Indicator	4-4
4.3 Blank Magazine Control Panel	4-5
4.4 HMI (Human Machine Interface)	4-6
4.4.1 Screen Layouts	4-7
4.4.2 Data Entry & Navigation	4-9
4.4.3 Security Levels	4-11
4.5 HMI Menu Groups	4-12
4.5.1 Overview Menu Group	4-12
4.5.2 Recipes Menu Group	4-14
4.5.3 Set Points Menu Group	4-16
4.5.4 Maintenance Menu group	4-18
4.5.5 Production Menu Group	4-23

4.6 Using the HMI	4-25
4.6.1 Logging In	4-25
4.6.2 Loading & Copying Recipes	4-26
4.6.3 Changing Values	4-28

Chapter 5 - Operating Procedures

5.1 Applying Power	5-1
5.2 Loading Consumables	5-3
5.2.1 Loading Blanks	5-3
5.3 Startup & Shutdown Procedures	5-4
5.3.1 Pre-Start Inspection	5-4
5.3.2 Power On	5-4
5.4 Putting the TrayStar™ Into Cycle ..	5-5
5.5 Stopping the TrayStar™	5-6
5.5.1 Performing an Emergency Stop	5-6
5.5.2 Stopping Under Normal Conditions	5-6
5.5.3 Short Term Shutdown	5-6
5.5.4 Long Term Shutdown	5-6
5.6 Clearing Jams	5-7
5.6.1 Identifying the Jam	5-7
5.6.2 Clearing	5-7
5.7 Resetting Torque Limiters	5-9

Chapter 6 - Troubleshooting

6.1 Overview	6-1
6.2 Fault Messages	6-2
6.3 Abnormal Running Conditions	6-8

Chapter 7 - Maintenance

7.1 PM Schedule	7-1
7.2 Daily Tasks	7-3
7.2.1 Work Around Safety Inspection ...	7-3
7.2.2 Cleaning External Surfaces	7-4
7.2.3 Check Emergency Stop Buttons ...	7-4
7.2.4 Inspect Vacuum Cup Filters	7-5
7.3 Weekly Tasks	7-6
7.3.1 Cleaning Photo-Eyes	7-6
7.3.1 Inspect Glue Guns & Hoses	7-6
7.4 Quarterly Tasks	7-7
7.4.1 Inspect & Clean Conveyor Belts ...	7-7
7.4.2 Clean & Lubricate Drive Chains ...	7-8
7.4.3 Inspect Compression Section Chain Tension	7-9
7.5 Bi-Annual	7-10
7.5.1 Check Fastners for Tightness	7-10
7.5.2 Inspect Gerarbox Seals	7-10
7.6 Chain & Bearing Maintenance	7-11
7.6.1 Chain Lubrication & Care	7-11
7.5.2 Bearing Lubrication & Care	7-11

Chapter 8 - Service / Support Information


8.1 Service Information Introduction	8-1
8.2 Objective	8-1
8.3 Service Personnel	8-1
8.4 Training	8-1
8.5 ARPAC & SUPPORTPRO Commitment	8-2
8.6 Technician Scheduling	8-2
8.7 Installation Policy	8-2
8.8 The SUPPORTPRO Advantage	8-2

Appendix A - Illustrated Assembly Drawings and Mechanical BOM

Appendix B - Electrical Schematics

Appendix C - OEM Vendor Information CD

Record of Revision



i.1. Record of Revisions

i.1.1. Revision History

REV	Date	Reason for Change
A	Oct 2009	Original
B	Mar 2010	Series Update
C	Sep 2011	Series Update
D	Jul 2017	Series Update

Table i-1. Revision History


i.1.2. List of Affected Pages

Page Number	Rev Level	Page Number	Rev Level	Page Number	Rev Level
All	A				
All	B				
All	C				
All	D				

Table i-2. List of Affected Pages

Layout & Project Specifications

ii.1. Overview



ii.2. Layout



1

Introduction

1.1. Introduction

Thank you for choosing ARPAC for your packaging equipment. We sincerely appreciate your business.

For over 47 years, ARPAC has been a leader in secondary packaging machinery with proven experience in designing and manufacturing complex integrated packaging lines. As an experienced Original Equipment Manufacturer (OEM) integrator, ARPAC has in-house capabilities to conceptualize, manufacture, install and service complete end-of-line packaging solutions.

ARPAC is renowned for providing high quality end-of-line packaging machinery to consumer goods and industrial product producers. We delivery solutions to producers of food, beverage, building supplies, automotive products, printed publications, personal care products and a wide variety of packaged goods.

Corporate Office

Conveniently located just minutes from Chicago's O'Hare International Airport.

ARPAC
9555 Irving Park Road
Schiller Park, IL 60176
www.arpac.com
847-678-9034

A Duravant Company

1.2. Using this Manual

This manual is an operations and maintenance manual for ARPAC packaging equipment. Use this manual if you are responsible for using, operating and maintaining the equipment. It is organized in a manner that can be easily understood by personnel with reasonable experience. This manual is intended to provide clear and simple explanations on how to safely operate and maintain the equipment.

If operated and maintained correctly, this machine is designed to provide the user years of service. It combines up-to-date, state-of-the art technology as well as ARPAC's enormous experience in the area of packaging systems.

1.2.1. Graphical Notations

To help communicate hazardous and nonhazardous alerts, the following graphics are used through out this manual.

Hazard Alerts



DANGER indicates a hazardous situation which, if not avoided, will result in serious injury or death



WARNING indicates a hazardous situation which, if not avoided, could result in serious injury or death



CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury

NOTICE

NOTICE indicates information considered important, but not directly injury related (i.e. could cause equipment or property damage)

Non-Hazard Alerts



Indicates information considered important



Indicates detailed on complex or difficult procedures.



**Required
Tools**

Indicates the need for special tools that may be required to perform a procedure or task.

1.2.2. Photo's & illustrations

Photographs and illustration appear through out the manual for informational purposes. For highly complex and Engineered to Order (ETO) projects, actual machine photos, when possible, are used. However, not every photo shown in this manual will be of your specific machine(s).

NOTICE

Dimensions and specifications are approximates and drawings may not always be to scale.



Some photo's may show safety guarding and fencing removed for illustration purposes only.
Never operate equipment with safety devices damaged, removed or modified.

1.2.3. Manual Design & Layout

This manual is organized into the following sections:

#	Description	Comments
TOC	Table of Contents	The table of contents is the directory of this manual.
i	Prelude i	Record of Revisions
ii	Machine Layout Drawing & Spec Sheet	The layout and spec sheet provide machine specific information. Use this information to identify your machine's specific serial and model numbers.
iii	Warranty Statement	This section includes the equipment Warranty Statement.
1	Introduction	This section introduces the end user to Arpac, the equipment purchased. Explaining how to use the manual is also covered.
2	Safety	Describes the safety precautions that should be followed when working with, on or around the equipment.
3	Mechanical Sub-Assemblies	Identifies and describes the individual mechanical assemblies, their functions and how they interact.
4	Operator Controls	Explains the purpose and location of all the controls used to operate the machine, including detailed instructions on how to use the HMI.
5	Operating Procedures	This section is dedicated to the operator. It describes in detail step-by-step procedures for starting, stopping and operating the equipment including such operator functions as changeovers, if applicable.
6	Troubleshooting & Corrective Maintenance	This section was designed to help the operator and the maintenance personnel understand and resolve possible problems with the machine. Abnormal running conditions and error messages are covered in this section.
7	Preventive Maintenance	Explains the tasks maintenance personnel should do in order keep the machine in top running condition.
8	Glossary of Terms	This section contains words that pertain to the equipment, which the operator may not be familiar with.
9	Parts & Service Support Information	This section contains an overview of ARPAC's service. Included are a field service policy, installation policy and parts ordering information with an order form.
A1	Mechanical Assembly Drawings / Spare Parts Lists	The mechanical assembly drawings are the prints for all of the major assemblies on your machine with the complete mechanical bill of material.

#	Description	Comments
A2	Electrical Information	Included are electrical schematics and complete electrical bill of material.
A3	Installation Considerations	Installation of complex systems should only be performed by qualified personnel with heavy equipment rigging experience. This section provides considerations that should be taken into account for planning purposes. Step by step instruction are not included. For more information, contact our Technical Service Department.
A4	Vendor Information	Here you will find manufacturer's manuals for certain components.

1.3. Design Features of the TrayStar™ 2000 Series

ARPAC'S TrayStar™ 2000 Series continuous motion tray loaders make tray loading a variety of products fast and easy. The TrayStar™ line integrates tray erecting, product loading, and sealing, into one inline continuous motion packing machine. Wrap-around trays ensure that the product is tightly fit preventing scuffing and product damage.

ARPAC'S TrayStar™ 2000 Series collates a variety of product shapes and sizes, such as: bottles, cans, bundles and cartons or jars, and loads them onto a wrap-around tray at speeds ranging from 35 to 60 trays a minute. The machine features gentle product handling and loading and can be easily integrated with other equipment, including tray wrappers, turners and stackers.

- Continuous motion wrap-around tray former/loader
- Simple machine adjustments and quick change capabilities for fast product changeovers
- Speeds up to 60 trays per minute
- Heavy-duty rugged construction designed for durability and around-the-clock operation
- Laser cut and CNC machined components for maximum precision
- Baked on powder coat finish provides a durable scratch resistant surface and prevents corrosion
- Nordson ProBlue® hot melt glue unit for superior application flexibility and adhesion
- Rolling canopy guarding provides safe, easy access to the machines interior
- Allen-Bradley® programmable logic controller with ARPAC standard operator interface
- User-friendly ARPAC operator interface with message display and self diagnostics
- NEMA 12 electrical cabinet and controls
- Low blank alert
- Gentle product handling
- Central point lubrication simplifies periodic maintenance
- User-Friendly Operator Interfaces Rapid Changeover with Color Coded Spacers
- Product Grouper
- Folding Section
- Flight Bar Section

1.4. TrayStar™ 2000 Series Concept of Operation

The system operation begins when the product is transferred onto the In-feed conveyor and separated into lanes. The product is fed into the collator and arranged into the desired configuration. Product is then conveyed into the flight bar assembly and the configuration is pulled together with the aid of product guides.

Simultaneously, a tray blank is pulled by a vacuum pick off unit from a side mounted vertical hopper and transferred through pinch rollers to a blank lug conveyor located beneath the product flight bar assembly. The tray blank is advanced by a lug conveyor in sync with the product being pushed by flight bars. The product configuration is pushed by the flight bar onto the tray blank as both are entered into the tray pocket conveyor.

The blanks are then folded by the cam closing pocket conveyor around the product. The trailing edge minor flap is tucked into place by rotary fingers. The side flaps of the carton are lifted and held by guides while hot melt glue is applied by controlled applicators. Pressure is applied to the glue flaps by a horizontal compression section, and a tight, squarely formed tray exits the compression section.

TrayStar™ 2000 Series consists of mechanical assemblies, motion control devices such as air cylinders, servo motors, AC motors and VFD's (Variable Frequency Drives), a number of photo-cell and proximity sensors to detect and control the product throughout the process and a single PLC (Programmable Logic Controller) that integrates all of these components together. The Operator Control Station provides one centralized point to monitor and effect the performance of the machine.

Safety

2

2.1. Safety

Every effort has been made by ARPAC to provide you with a safe machine. This section describes the safety precautions that should be taken when working with, on or around the equipment. It is essential that machine operators and maintenance personnel follow the safety information. Safety everyone's responsibility and the information in this chapter is vital to maintaining a quality work environment.

2.1.1. *Statement of Liability*

While this machine has been designed for safer operation, improper operation or carelessness may result in serious injury or death, harm to the environment and damage to equipment. The manufacturer or its agents and representatives assume no responsibility for the following.

1. Injury or danger from improper use of the machine.
2. Problems or hazards resulting from failure to maintain the equipment as specified in this manual.
3. Equipment which has been tampered with or modified. ARPAC is not liable for any damage or injury arising from failure to follow the instructions and procedures provided within the manuals or associated material, or from user failure to use caution when installing, operation, adjusting, or servicing this machine. ARPAC is not liable for damage or injury arising from the use of this product for any other use than that intended by the manufacturer.

2.2. Safety Precautions

2.2.1. Interfacing Equipment

Observe all applicable codes when interfacing this equipment to other equipment. Specific attention must be paid to any pinch points that may be created and the prevention of unintended restart of the equipment when the electrical interlocks shut it down.

2.2.2. Dressing for Safety

- Tie or pull back long, loose hair that can get caught in the machinery.
- Remove loose, dangling jewelry and rings and watches that can get caught in the machinery.
- Ensure that radio headphone wires do not get caught in the machinery and cause personal injury.
- Dress comfortably. Tight clothing restricts the ability to move freely and safely.
- Do not wear shoes with slippery soles, such as high heels or boots. Uncomfortable shoes can cause personal fatigue and reduce the ability to work well.
- Do not wear neckties or scarves.
- Roll loose sleeves or secure them with rubber bands.
- Button or remove open sweaters or jackets.
- Tuck in shirttails.

2.2.3. Maintaining a Clean Work Area

Keep the work area clean to avoid injuries and damage to the equipment. Inspect your work area for possible causes of accidents:

- Water and other spills are dangerous. Clean and dry the area immediately after a spill.
- Keep a 3-foot clear walkway around the entire machine. Boxes and papers are hazards when left on the floor near the machine.
- Keep all food and drink away from the machine.
- Keep your work area well lit. Report all burned-out bulbs to your supervisor.
- Do not leave tools and other loose items on the machine.
- A cluttered work area requires unnecessary and hasty movement that causes accidents. Keep all materials orderly and easily accessible.

2.3. Personnel Instructions

Read and understand the following personnel safety information before operating the equipment.

PPE

Make sure that you wear safety goggles and other personal protective equipment according to your company's safety standards when operating this machine. You may get injured if you do not.

Disconnect Power Before Servicing

Make sure that all the power is disconnected from machine before servicing it. You may get severely injured if you do not.

Proper Cleaning Solvents

Only use non-flammable, non-aerosol cleaning solvents to clean the equipment.

Keep Hands and Other Body Parts Clear

All personnel working around or coming in contact with the equipment must be instructed to keep their hands and other body parts of their person and clothing clear of all moving parts.

Ensure Safety Devices are Operational

Equipment must not be operated if safety devices, including guards and doors, removed, disconnected or damaged.

Never Reach Into Equipment

Personnel shall not reach into the equipment for any reason, including maintenance, adjustment or clearing of jams, while the equipment is in the cycle mode. The cycle mode stops when the guard doors are opened or when the CYCLE STOP button is pressed. The process may take a couple of seconds. Do not reach into the machine until the machine has stopped.

Before any person reaches into the equipment for maintenance or adjustment, air and electrical power shall be turned off using lockable shutoffs provided. The clearing of jams may be done while the machine is turned on, but not while in the cycle mode.

Anyone entering the machine for maintenance, troubleshooting or any procedure entailing the removal of guards or performing work at any point of operation, shall be required to observe all applicable lockout-tagout requirements.

2.4. Safety Labels

Safety labels are placed at various locations around the machine to communicate potential hazards.



Figure 2-1 - Red & Black labels indicate DANGER hazards



Figure 2-2 - Orange & Black labels indicate WARNING hazards





Figure 2-3 - Yellow & Black labels indicate a Caution hazardous situation

2.5. Energy Isolating Devices

The section discusses the various devices and proper methods for isolating energy to prevent injuries when its necessary to stop the machine to clear jams or perform maintenance, for example.

2.5.1. Main Disconnect Switch

The Main Disconnect is located on the main electrical cabinet. It is connected via a rod through the door to the Main Circuit Breaker that supplies all power to the equipment. Different types of switches are used, depending on the type and style of the enclosure.




2.5.2. Emergency Stop Buttons

There are several Emergency Stop buttons located on the machine. Pressing any of these buttons will immediately stop the machine and drop all electrical and pneumatic power to the machine except the machine's internal controls. Below is a map showing the typical locations of the E-Stops for this Series of equipment.

NOTICE

Additional E-Stops are often added the equipment per customer's specifications. Refer to the project specific layout for exact locations for your machine.



WARNING

If the Wrapper is integrated with a tunnel, activating an E-Stop will stop the tunnel conveyor belt. If machine stops with product in it, remove it as soon as it is safe to do so. Product could potentially catch fire or explode if you do not. Do not try to push product out with your hands.

There are several different types of E-stop buttons. Some are lit, some are not. Some are reset by twisting the button, while others are reset by pulling them straight out. Whatever type of E-stop happens to be on your system, the function is identical. They all stop the machine immediately in case of an emergency.



E-Stop in normal run state.



**E-Stop activated.
(LED illuminated)**




2.5.3. Chain Guards and Guard Doors



Equipment must never be operated if any safety devices, including guards and doors, are removed, disconnected or damaged.

Chain guards are bolted to the machine, requiring a tool to remove.



Guard doors are equipped with an interlocking switch. When a door is opened, the switch is interrupted, disabling power to motion control devices, regardless of where the machine is in its cycle. Personnel shall not reach into the equipment for any reason, including maintenance, adjustments or clearing of jams, while the equipment is in the cycle mode. The process of stopping the cycle may take a couple of seconds. Do not reach into the machine until the machine has stopped. Refer to the electrical schematic for specific Safety Circuit information.




2.5.4. Motor Disconnects (If equipped)

If equipped, individual motors can be wired to an isolation disconnect that when in the “Off” position disables power to that motor only. These devices are not connected directly to the machine’s safety circuitry, but they can be wired to an input on the PLC so that a message can be displayed on the HMI to indicate that the motor is “Off”.



Figure 2-4 - Motor Disconnect Switch

If a motor is connected to one of these disconnects, the disconnect will be within line of sight of the motor and identified as associated with that motor. If your machine has these disconnects installed, refer to the machine’s electrical schematic for more information.



2.6. Lock Out / Tag Out

You can lock the machine out by applying locks to the electrical main disconnect and the pneumatic regulator. Locking these two sections out will ensure safety when working on the equipment.

When you are going to work on ARPAC equipment, follow the Lock Out / Tag Out (LOTO) procedure to ensure safety.



Because companies tend to tailor the LOTO protocols specific to them, we advise all users to refer to their company's procedure manual. The LOTO procedure described here are the minimum requirements

Lockout/Tagout Kit

A typical lockout/tagout kit is shown in the figure below. ARPAC machines can be locked out with most standard lockout/tagout kits.



Figure 2-5 - Typical LOTO Kit

2.6.1. Electrical LOTO

It is important to safely shut down the equipment and lock it out electrically before performing any maintenance.

1. Notify affected employees that the equipment is going to be locked out.
2. Safely shut down the equipment.
3. Complete the information on the tag.
4. Apply the lock to the main disconnect. (The example illustrates one type of main disconnect switch. Other styles have the same capacity for lock application.)




Figure 2-6 - Lockout/Tagout at Main Disconnect



Never assume power has been isolated. Always verify.

Verify power is off. The machine is now electrically locked out.

2.6.2. Pneumatic Lockout/Tagout

To lock out the air supply:

1. Notify all affected persons that the equipment is being locked out.
2. Complete the information on the tag.
3. Turn the red knob clock-wise to shut off the valve and align the knockouts for the lock and apply lock.




Figure 2-7 - Lockout/Tagout at Pneumatic Regulator

4. Verify that there is no air present. The machine is now pneumatically locked out.

2.6.3. Restoring power and air to the Machine

Restore the machine to proper working order by the following steps:

1. Ensure all personnel are clear of the machine.
2. Remove all tools and loose parts that may have been left behind from the maintenance procedure.
3. Replace all safety guarding that was removed for the maintenance procedure.
4. Remove locks and tags.
5. Notify affected employees that the lockout condition has been removed.
6. Restore power to the machine at the main disconnect.
7. Clear the machine using the human machine interface (HMI).
8. Ensure that any E-stops have been properly reset.
9. The machine is now restored to a run condition.

Mechanical Assemblies

3.1. Overview

ARPAC'S TrayStar™ 2000 Series is a high speed continuous motion tray packing machine. It's excellent flexibility, reliable performance and ease of use make it well suited to handle a wide range of product configurations and applications including: plastic bottles, cans, boxes, glass jars and more.

The TrayStar™ 2000 Series combines a number of mechanical assemblies to accept individual loose product from a customer's upstream processes and equipment and collates them into user defined configurations in order to place them in a cardboard trays.

This section identifies and explains the major assemblies and components of the equipment and how they work together.



The Machine Controls and Operating Procedure sections of this manual that explain how the TrayStar™ 2000 Series constantly monitors and controls the product throughout the process and how to operate the machine also contain information related to these assemblies. Be sure to review those manual sections as well for a complete understanding.

NOTICE

Additional Engineered to Order (ETO) assemblies related to a specific project, serial number or ARPAC OEM integrated production line purchased with this machine are included in an appendix at the end of the manual.

The TrayStar™ 2000 Series' mechanical assemblies explained here are grouped together in two categories; a product handling group and a tray handling, delivery and forming group.

Assembly Group	Assemblies Included
Product Handling	In-feed Conveyor
	Lane Guides
	Product Accumulation Detector
	Fallen Product Detector
	Product Agitator
	Product Collator Clamp
	Collator Escapement Flight Bars
	Pacing Flight Bar
Tray Handling / Delivery & Forming	Extended Tray Magazine
	Blank Feed Magazine
	Lugged Blank Feed Conveyor
	Tray Former
	Compression Section
	Hot Melt Glue System

Table 3-1 - TrayStar™ Assembly Groups

The foldout on the following page shows where each assembly is located.

3.2. Product Handling / Delivery Group

3.2.1. In-feed Conveyor

The In-feed conveyor is an independently driven conveyor that receives the product from the customer's conveyor and advances it to the Collator Clamp. It is located at the front of the machine.



The In-feed conveyor is a vital part to the machine's consistent operation by providing constant control of the product as it is being configured. It consists of several assemblies designed to delivery product to the Collator assembly.

Mechanical Design Features

- Conveyor belt is modular plastic selected to fit the application.
- Conveyors are equipped with various sets and types of lane guides that direct the product from one common lane into the required configuration.



Guides to create individual lanes

Side guides only
for flood-feed applications



Control Functions

- The In-feed conveyor starts running after the machine is put into the cycle mode.
- The speed of the conveyor belt is determined by a user defined value entered into the HMI. Conveyor speeds need to be set fast enough to accept incoming product.

#	SETPOINT	UNITS	VALUE	SAVE
7	Infeed Conveyor Speed	%	100	


- The In-feed conveyor has multiple product sensors to control the flow of product.



Figure 3-1 - Example of a maximum accumulation sensor



Figure 3-2 - Example of a fallen product sensor



- The In-feed push buttons provided on the *Machine Controls* screen in the HMI can be used to run the In-feed when the machine is NOT in cycle.


3.2.2. Product Agitator & Minimum Accumulation Sensor

An oscillating Product Agitator, if required, is included to keep the product from stalling on the lane guides. The agitator is made up of a set of oscillating plates that gently agitate the product from side to side.



Product is maintained by guides in lanes as they advance. When enough product accumulates on the In-feed to create sufficient back-pressure at the Collator, the Product Accumulation Sensor is made.

Mechanical Design Features



- A cam assembly connected to the motor (1) creates the oscillation of the set of plates (2).
- Tool less kip handles are provided for adjustment and quick changeovers.

Control Functions


- Product flows from the agitator in their respective lanes past another sensor called the Product Accumulation sensor. This sensor sends a signal to the PLC that the lanes are properly filled in order for there to be the correct amount of back pressure at the Collator Clamp. The machine will not release product at the collator unless this sensor is made.

3.2.3. Product Collator Clamp

Creation of bundles is done at the Product Collator Clamp. Full lanes of product presented to the Collator are grouped together and released to the Collator Escapement Flight Bar assembly.



Mechanical Design Features




- Silicone sponge pad covers the clamp to prevent damage to product.
- Air operated



- Height adjustment screw with ratchet


Control Functions



- Lifting and lowering of the clamp is control by user defined inputs. From the HMI, an operator can determine when the clamp turns ON and for how long, based off pulses from the Encoder.

3.2.4. Collator Escapement Flight Bars

The Collator Escapement Flight Bars collate and release the product, now formed into “groups” to the Pacing Flight Bars. As the Escapement Flight Bar rotates, the Clamps retract long enough to allow the required number of rows to be released to the Escapement.



Mechanical Design Features





Figure 3-3 - Escapement Flight Bar Assembly (shown here with one of the side plates removed)


- Servo motor driven flight bars connected via a chain and sprocket arrangement.

Control Functions

The timing is determined by the encoder. After a predetermined number of pulses and timed with the Pacing Flight Bars immediately following the Escapement, the Escapement Flight Bars rotate for “X” # of pulses. As the Escapement Flight Bar rotates, the Clamps retract long enough to allow the required number of rows to be released to the Escapement.



- The Collator Flight Bar Clear PE located at the upstream end of the assembly is used to ensure the flight bars are clear.



- Photo eye that is used to determine the Escapement flight Bars “home” and “off set” positions.



OUR INTEGRATION
YOUR SUCCESS

SETPOINT MODIFY

RECIPE #3 4 Pack 30 Trays / min.

 ENGLISH
 1:43:32 PM 6/28/2017
 SECURITY: 5

#	SETPOINT	UNITS	VALUE	SAVE
2	Collator Flight Bar Product Position	0.1"	20	Collator FB Position 1.98
3	Collator Flight Bar Release Speed	%	150	
4	Collator Flight Bar Release Speed Distance	0.1"	0	
5	Collator Flight Bar Finishing Speed	%	1600	
10	Collator Flight Bar Clear		18	

- The *Collator Flight Bar Product Position* parameter, also referred to as the “Off-set” position, sets the starting position of the escapement flight bars.
- The *Collator Flight Bar Release Speed* determines how fast the escapement flight bars move during the RELEASE portion.
- The *Collator Flight Bar Release Speed Distance* determines how long the escapement flight bars run at the release speed.
- The *Collator Flight Bar Finishing Speed* determines how fast the escapement flight bars move during the FINISHING portion.
- The *Collator Flight Bar Clear* parameter set the window for when the PLC looks to make sure product is clear of the escapement flight bars to prevent a jam.


3.2.5. Pacing Flight Bars

Product released by the Collator Escapement enters the Pacing Flight Bar area where the flight bars drop down behind them.

The pacing flight bar assembly is used to square the collated products and move them across a transfer plate and onto a tray blank at the beginning of the tray-forming conveyor.



Mechanical Design Feature



- The flight bars are specifically spaced bars driven by a chain and sprocket arrangement, attached to the main drive.
- The flight bars travel slightly faster than the conveyor belt therefore squaring the product group front to back.
- Side guides are used to hold the product square side to side as the flight bars move the product over a dead plate and onto a tray blank entering the main tray-forming conveyor. This ensures the product driven by the pacing flight bars correctly merge with an emerging tray blank from the blank lug conveyor.
- The pacing flight bars are equipped with a single point engagement torque limiter that operates a proximity switch that stops the machine if tripped.
- The flights bars must be manually advanced to reset the torque limiter if it trips.

Control Functions


- The pacing flight bars begin moving when the machine is put into cycle.
- Timing of a flight bar making contact with the product group should be just prior to the product making it to the dead plate.




- Photo eyes mounted above the dead plate area detect product and initiate the tray blank feed. This ensures the product driven by the pacing flight bars correctly merge with an emerging tray blank from the blank lug conveyor.



- The photo eye location at the down stream end, near the dead plate, looks for fallen product, based of the user defined “window” entered in the HMI.



- The proximity switch located at the top of the upstream end is used to zero the Pacing flight bars.



- A Set Point Modify screen accessed from the Maintenance screens of the HMI allow for resetting the flight bars zero position.

ARPAC **SETPOINT MODIFY 2**

OUR INTEGRATION YOUR SUCCESS

RECIPE #3 4 Pack 30 Trays / min.

ENGLISH 1:43:32 PM 6/28/2017 SECURITY: 5

#	SETPOINT	UNITS	VALUE	SAVE
6	Pacing Conveyor Speed	%	69	

Low Blank Supply

OVERVIEW RECIPES SETPOINTS MAINTENANCE PRODUCTION DATA

Door #2 Open 00 hr 02 min 22 sec

- The speed of the Pacing Flight Bar conveyor and the flight bars is set as a % of the Main Drive speed.

ARPAC **SETPOINT MODIFY 13**

OUR INTEGRATION YOUR SUCCESS

RECIPE #3 4 Pack 30 Trays / min.

ENGLISH 1:44:42 PM 6/28/2017 SECURITY: 5

SAVE

Collator FB Position 1.98

Pacing FB Position 3.57

69	Product Fallen At Flight Bar	0.1in	315	105	3.57
----	------------------------------	-------	-----	-----	------

OVERVIEW RECIPES SETPOINTS MAINTENANCE PRODUCTION DATA

Door #3 Open 00 hr 00 min 39 sec

- The window for when the PLC looks for fallen product on the Pacing Flight Bar Conveyor is set in one of the MAINTENANCE screens in the HMI.


3.3. Tray Handling / Delivery & Forming Group

3.3.1. Extended Tray Magazine

The blank feed assembly is located parallel to the main machine behind the blank magazine. This assembly is used to store a supply of blanks that can be automatically fed into the blank magazine when needed. This assembly consists of a blank conveyor, blank lifter mechanism and a blank loader mechanism. This assembly is automated, but can be run manually by using the various push buttons.




Mechanical Design Feature



- The blank feed conveyor is an independently driven Intralox conveyor with rubber strips to grip the tray blank stacks as they travel to the blank loader mechanism. A side guide is used to help stabilize the blanks and helps the operator to square the stack as they load the conveyor.
- Blanks are loaded onto the conveyor manually by the operator. The blanks should be loaded on the conveyor in the same orientation as the blanks loaded in the blank magazine.
- The blank lifter is a pneumatically controlled device located in between the blank loader rollers. This device is used to elevate the position of the stack of tray blanks. This lifter is made of metal arms with Delrin material mounted to the top.

Control Functions



- The blank feed conveyor stops and starts intermittently at a speed determined in the HMI. Two conditions must be met in order for the blank feed assembly to operate: both the blank feed assembly power on push button and the main tray loader's power button must be pushed.
- As the blanks are indexed to the blank loader they block a blank in position photo eye mounted to the side of the blank loader mechanism. It will stop when either a stack of blanks is detected by the blank in position photo eye on the blank loader or until the blank in position photo eye remains unblocked for a preset amount of time.
- If the photo eye detects a stack of tray blanks, the photo eye will signal PLC to actuate the blank lifter mechanism. If the photo eye remains unblocked for a preset amount of time it will time out and the PLC will signal the conveyor to go into standby mode.
- The program is designed to signal the conveyor to begin indexing again after a specific amount of time. This allows the operator to reload the conveyor. The operator can either press the blank conveyor jog push button to restart the conveyor or wait until the PLC signals the conveyor to begin cycling.



The *Power On* push button for the blank feed assembly is an illuminated, extended head push button. This button will light up when power is supplied to the assembly.



Keep all hands and clothes away from this assembly. When the blank feed assembly is in the cycle mode there are many moving parts that sit idle for periods of time. Approach this assembly with caution and remember that the mechanisms move automatically.


- Blanks enter the blank loader area and trip a blank in position photo eye. When the low blank supply photo eye on the blank magazine becomes unblocked it sends a signal to the PLC. This photo eye signals the PLC to actuate the blank lifter solenoid valve.
- Proximity switches monitor the position of the lifter. When the blank lifter up proximity switch is tripped the PLC signals the pusher to move forward. This action delivers the stack of tray blanks across the bridge and into the blank magazine. The blank lifter returns to its home position (lower) when the pusher returns to its home position.

3.3.2. Blank Feed Magazine


The Blank Feed Magazine is positioned at a right angle to the machine, directly across from the Pacing Flight Bar assembly.




Mechanical Design Feature



- Two assembled “L” shaped stainless steel plates form a vertical chute, referred to as the “Hopper”. The magazine will hold approximately 200 (1/8” thick) tray blanks.
- Adjustable supports at the bottom of the magazine hold the column of tray blanks and provide resistance for the blank vacuum pull down system located below the magazine.




- Support Guides that follow the Pinch Rollers position the blank for the Lugged Blank Feed Conveyor.




- The blank pull-down mechanism is located below the blank magazine. This mechanism pulls individual blank trays from the blank magazine and transfers them to the blank lug conveyor. Two vacuum cup arms attached to a spline shaft each hold two vacuum cup assemblies.

Control Functions



- Photo eyes located on the pacing flight bar conveyor detect the presence of product and send a signal to the PLC to start a timing sequence for the blank pull-down mechanism. As soon as the vacuum cup assembly has almost reached the blanks in the magazine, the vacuum suction is turned on. The cups then suction a blank, pulling it down toward the blank shelf. The suction stays


on until the blank and the arm is almost back to the home position. As the arm completes its cycle to the home position, the blank falls to the blank shelf where it is swept away by the blank ejector conveyor.



- A photo eye mounted to the magazine detects a low supply of blanks that sends a signal to the Extended Blank Magazine to feed another stack of blanks. An operator can set the number of cycles the machine will continue to run AFTER the PLC receives the signal from the Low Blank Detection PE.
- The blank pull down mechanism begins operating when the machine is put into the cycle start mode. The vacuum arms raise and lower whether or not a blank is present. This movement is mechanical in nature. Suction will only be generated if the product detect photo eye on the pacing flight bar assembly is tripped.

3.3.3. Lugged Blank Feed Conveyor

The blank lug conveyor is located below the pacing flight bar assembly. This conveyor is constantly driven by and timed off of the main drive. It extends from the blank pull-down mechanism to the exit end of the pacing flight bar assembly.



Mechanical Design Features

- Once the tray blank reach the end of the blank lug conveyor under the dead plate area, they are propelled out from below the dead plate area. Product being swept off the dead plate area by the pacing flight bars is merged with the tray blank as they meet at the beginning of the main tray-forming conveyor.

Control Functions

ARPAC **SETPOINT MODIFY 13**

OUR INTEGRATION
YOUR SUCCESS

RECIPE #3 4 Pack 30 Trays / min.

ENGLISH 1:44:42 PM 6/28/2017 SECURITY: 5

#	SETPOINT	UNITS	STATUS	ON	DISTANCE	SAVE
65	Blank Vacuum On/Off	0.1in	☐	200	170	
67	Blank Jam Detection	0.1in	☐	260	30	

Collator FB Position
1.98

Pacing FB Position
3.57


OVERVIEW RECIPES SETPOINTS MAINTENANCE PRODUCTION DATA

Door #3 Open 00 hr 00 min 39 sec

- Timing of feeding of blanks from the Blank Magazine via the pinch rollers is determined by the *Blank Vacuum On/off* “window” set in the HMI. Feeding a blank needs to be timed with the Lugged Blank Feed conveyor.


3.3.4. Tray Former Assemblies

The Tray Forming conveyor and assemblies are located after the Pacing Flight Bar area and extend to the exit end of the machine. The main tray forming conveyor forms and glues the tray blank around the product.



Mechanical Design Features


- The bundle and blank converge simultaneously after the Dead Plate. Here, the lugs on the Lug conveyor fold the long sides of the tray up as the bundle is slid onto the tray. Provided hold downs keep product on the tray blank.



- The loaded tray is advanced and the minor flaps are folded in. The tray is advanced further and a bead of glue is applied to all the minor flaps. The major flaps are then folded and pressed into the minor flaps.
- Four roller chain assemblies (left and right Leading Lug & left and right Trailing Lugs) form the pocket. Each roller chain has a set of articulated lugs mounted to the top of the chain. Two of the roller chains are positioned so the lugs are in a leading position and the other two chains are positioned in a trailing position. This chain and lug configuration holds the product and trays in place as the assembly folds and glues the tray. The distance between lugs can be adjusted to accommodate different size trays.



- At the point where product and blank merge on the main tray-forming conveyor, the flap of the tray's leading edge is folded up.



- As the tray and product continue moving forward, minor flap tuckers fold in the tray's trailing minor flaps.

- The horizontal side guides keep the flaps in place while the glue guns apply a glue pattern on each minor flap.



- Immediately after the glue is applied to the tray's minor flaps, an angled guide on each side of the conveyor folds the major flap up to meet the minor flaps. Once folded, the flaps are held closed by the compression. By the time the tray reaches the end of the compression rails the glue is set.

Control Functions

- Open flap photo eyes mounted to each side of the main tray forming conveyor after the compression section identify if flaps have not been glued properly. If these photo eyes are blocked they send a signal to the PLC to stop the machine cycle and an error message is displayed on the operator interface.
- If the flaps jam, the machine will trip the torque limiter and an error message will appear on the operator interface indicating that the torque limiter must be reset.

ARPAC **SETPOINT MODIFY 14**

OUR INTEGRATION
YOUR SUCCESS

RECIPE #3 4 Pack 30 Trays / min.

ENGLISH 1:44:49 PM 6/28/2017 SECURITY: 5

#	SETPOINT	UNITS	STATUS	ON	DISTANCE	SAVE
73	Detect Tray for Glue Window	0.1in		51	8	1.98
77	Glue 1st Pulse	0.1in		115	10	
79	Glue 2nd Pulse	0.1in		138	10	3.57

Collator FB Position

Pacing FB Position


Low Blank Supply

OVERVIEW RECIPES SETPOINTS MAINTENANCE PRODUCTION DATA

Door #3 Open 00 hr 00 min 47 sec

- The glue gun nozzle heads point down toward the major flaps to spray glue as the tray passes.
- Application of glue to the minor flaps of the blank is determined by the values of the *1st And 2nd Glue Pulse* settings.

3.3.5. Hot Melt System




A hot melt glue system consisting a melt tank, hoses, glue guns and nozzles apply a predetermined amount of glue to the trays.

3.3.6. Compression Section

The final assembly of the machine is the Compression Section.



- Angled guides hold the front and back panels in place while the glue sets.



A chain tensioner located under the conveyor is provided due to normal stretching of the chain.

Operator Controls

4.1. Main Disconnect (Power On) Switch

The Main Disconnect Switch, located on the Main Control Cabinet supplies power to the equipment.



Figure 4-1 - Main Disconnect



High Voltage. Electrical connection to main power supply required. Connections to be performed by qualified electricians only.

4.2. Main Control Panel (Operator's Station)

The Main Control Panel, referred to as the Operator's Station, includes the HMI (Human Machine Interface) and push button controls. It is from here that an operator can monitor and effect the operation of the equipment. The operator station is typically mounted to a swing arm on the control side of the machine.




Figure 4-2 - Operator's Station

4.2.1. HMI (Human Machine Interface)

The HMI, also referred to as the operator interface is a touch screen panel is used to change various settings of the machine. It also displays error messages when the machine experiences a fault or jam. It's use is covered more thoroughly later in this chapter.



4.2.2. Push Button Controls

Multiple push buttons mounted on the station provide inputs to the PLC to initiate the following:

1. **EMERGENCY STOP Push-Pull Button** - Pressing this button will immediately shut down the machine. The button must be pulled out before restarting the machine. This button is also located at various points around the machine.
2. **POWER ON** - Pressing this button turns the machine on.
3. **CYCLE STOP RESET Button** - Pressing this button stops the machine after it has completed a full cycle. Pressing this button will also clear error messages on the machine's interface after the problem that caused the message has been resolved.
4. **CYCLE START Button** - Pressing this button will start the normal production cycling of the machine.
5. **JOG Button** - Pressing and holding this button will jog the machine's conveyors without feeding blanks. The machine will stop when the button is released. This button can only be used when the machine is not in cycle.

4.2.3. Status Indicator Beacon

The stack light provides a visual and audio indication of the status of the machine.



- Solid Red indicates an emergency stop push-pull button is tripped.
- Flashing Red indicates a fault or alarm situation.
- Solid Amber indicates the blank magazine is getting low.
- Flashing Amber indicates the machine is in the override or interlock mode.
- Solid Green indicates the machine is in the cycle mode.
- Flashing Green indicates the machine is going into or coming out of the cycle mode. Also indicates that machine is in standby mode because it received an outside signal from an upstream or downstream sensor to stop.

4.3. Blank Magazine Control Panel

The Extended Blank Magazine has a set of push button controls.



1. **EMERGENCY STOP Push-Pull Button** - Pressing this button will immediately shut down the machine. The button must be pulled out before restarting the machine. This button is also located at various points around the machine.
2. **CYCLE STOP RESET Button** - Pressing this button stops the machine after it has completed a full cycle. Pressing this button will also clear error messages on the machine's interface after the problem that caused the message has been resolved.
3. **BLANK LOADER JOG Button** - Pressing this button will jog the Blank Loader assembly.
4. **BLANK LIFTER JOG Button** - Pressing this button will jog Lifter assembly.
5. **BLANK CONVEYOR JOG Button** - Pressing this button will jog the Blank feed conveyor forward.

4.4. HMI (Human Machine Interface)

The HMI (also referred to as the operator interface) is the operators primary means of directly interfacing with the equipment. The HMI is a color touch screen that allows the operator to monitor and change the operation of the machine. The HMI is a component of the electrical control system. It is a programmable device that communicates directly with the machines PLC control system via direct cabling or an Ethernet device. Typically, but not always, it is mounted on the main electrical cabinet along with the other operator controls called the “Operator Control Station”.

The program logic is based off the concept of treating products and the number of configurations required as “recipes”. Each recipe contains the machine settings, (set points) required to properly control the flow of product through the machine. Using recipes allows for a single machine to be used for multiple different products and configurations.



Caution

Do not use anything but your fingers to operate the interface's touch screen. Using pens or pencils to contact the touch screen can easily damage it and it is very expensive to replace.

The following sections provide an understanding of the HMI and how to navigate the different HMI screens, as well as explaining the different screens and their functions.

4.4.1. Screen Layouts & General Operation

HMI screens are categorized, or grouped together according to their function and purpose. Screen groups for the TS-2000 Series are; the Overview, Recipes, Set Points, Maintenance and Production groups. The appearance and layout of the screens have many things in common.

Screen Layouts

Below is an image of the Control screen. This example is used to explain how the HMI screens are laid out.




Figure 4-3 - Screen Layouts

1. Title Block

There's a title block at the top of each screen. The title block displays the name of the screen, the current date and time and the security level currently accessed.

2. Main Body

The main body of the screen displays information related specifically to it's purpose. It may also contains push button control for certain functions. Push Buttons - there are two types of push buttons used; "momentary" and "maintaining".

- Momentary buttons change "states" (on/off) as soon as the are released

- Maintaining buttons, when pressed, maintain that state until pressed again. These buttons may also change color, for example, from gray to white or green to red.

Grey-ed out push button, like the “Jog Selection” boxes in the example above are disabled, meaning they are currently inactive.

3. Menu Group Buttons & Message Banners

The bottom of the screen contains a button for each menu group, a message banner and toggle buttons. Pressing one of the menu group buttons will navigate to and open the first screen (some menu groups have multiple screens) for that group. The menu groups are password protected. The Over View and Set Point menu groups contain the control functions and parameter settings to effect the operation of the equipment. The Maintenance menu group contains diagnostic data and high level settings. The Maintenance menu group should only be accessed by qualified individuals. The Production Data menu group contains production efficiency data and should only be accessed by supervisory/management personnel. Menu groups are discussed in greater detail later in the chapter.

The message banner displays the current status of the machine; i.e. running condition, faults and warnings.

The toggle buttons can be used to cycle between the screens of menu groups with multiple pages.

4.4.2. Data Entry & Navigating to Different Screens

The interface is equipped with two objects for data entry [numeric and string (i.e. text)]. If the interface is at a sufficient security level for a particular function, the keypad or keyboard opens when an operator touches an object calling for data entry.




Figure 4-4 - Numeric Keypad




Figure 4-5 - Alpha-numeric Keypad

Navigation Tools

To navigate directly to a specific screen within a Menu Group that has multiple screens, press the button for that screen from the expandable screen menu that pops-up when the Menu Group button is pressed, as long as an operator is logged in with sufficient security access. The toggle buttons in the lower right hand corner can also be used to navigate to the next or previous screen.




Figure 4-6 - Expandable Screen Menu Pop-Ups

4.4.3. Security Levels

There are three different security levels associated with the interface, not including “Level 0”, the default security level upon power-up. Each progressive level offers a deeper level of access to controlling and monitoring the machine. The levels are as follows:

1. **Operator (O):** This gives access to basic running conditions; starting/stopping recipes, wrap mode, jogging functions.
2. **Maintenance (M):** This level is available to trained operators of the machine. It allows the operator to modify existing and make new recipes for different products into the machine and to change setpoints in the machine’s operation. The operator must login to the machine and enter a password to gain access to this level
3. **Supervisor/Manager (S):** This level is available to trained maintenance technicians. It allows access to all functions of the machine. The technician must login to the machine and enter an password to gain access to this level.



The default security level, Level 0, is available to all users and is active when the machine is first turned on. This level does not allow anyone to change anything, but it does allow the operator to view basic machine messages.


4.5. HMI Menu Groups

The following explains the specific functions of each HMI menu group.

4.5.1. The Over View Menu Group

The Overview group, in addition to being the “home” or “default” screen, is where the user monitors and controls the machine. Security level 1 or higher needed to access the following screens:

Main Screen



Displayed on the screen:

1. **Production Rate** - Displays the set production rate, based off user defined parameters.
2. **Machine Status** - Displays messages on the machines current status. In this example, guard door #2 is open.
3. **Collator Mode** - The text above the button indicates what mode the Collator is in.
4. **Warning Messages** - Warnings will be displayed. In this example, the Blank magazine is low.

Machine Controls Screen

The Machine Control screen is used to perform the following functions:





Figure 4-7 - Machine Controls Screen

- **Collator Mode** - This button is used to put the collator in stand-by (**HALT**) if an operator wants to stop the flow of product, but not stop the machine entirely. Press it again to put the collator back into **RUN** mode.
- **Tray Loader Purge Mode** - Used to override or ignore accumulation inputs from the In-feed conveyor in order to run out product for a changeover or at the end of production. This button is disabled when the machine is in cycle.
- **Collator Flight Bar to Product Position** - Used to return the escapement flight bars back to their starting position. Required after certain faults. This button is disabled when the machine is in cycle.
- **Start In-feed Conveyor** - Use this button to run the In-feed conveyor belt independently. Priming the conveyor with product is an example of when to use this feature. This button is disabled when the machine is in cycle.
- **Jog Collator Flight Bar Forward** - When the machine is not in cycle, a user can move the Pacing Flight Bars forward with this button.
- **Jog Collator Flight Bar Reverse** - When the machine is not in cycle, a user can move the Pacing Flight Bars backwards with this button.
- **Stop In-feed Conveyor** - Use this button to stop the In-feed conveyor belt if the *Start In-feed Conveyor* button was used.


4.5.2. Recipes Menu Group

The Recipe Menu Group contains the screens from which an operator can view the available product Recipes. Each individual Recipes contains the unique settings for that product configuration.



1. **Recipe # and Description** - A quick reference list containing all the product configurations that have been programmed into the HMI.
2. **Load** - Used to load an existing Recipe into the HMI.
3. **Copy** - Used to copy one Recipe into a different Recipes # slot. This is helpful when an operator has a new product configuration to create that is similar to another one to minimize the amount of information that needs to keyed in.

View & Compare Screen



The View & Compare screen is used to compare recipe set-ups.

1. Select a group of parameters
2. Select two Recipes to compare

4.5.3. The Set Points Menu Group

The Set Points menu group consists of several screens containing all of the available set point parameters needed to adjust the performance of the machine. Each screen can contain up to five different parameters. Regardless of the number of available set point screens, they are all laid out the same.

Set Point Modify Screens

#	SETPOINT	UNITS	VALUE	SAVE
1	Machine Rate	PPM	40	Collator FB Position 1.98
2	Collator Flight Bar Product Position	0.1"	20	
3	Collator Flight Bar Release Speed	%	150	
4	Collator Flight Bar Release Speed Distance	0.1"	0	
5	Collatort Flight Bar Finishing Speed	%	1600	

Low Blank Supply

OVERVIEW RECIPES SETPOINTS MAINTENANCE PRODUCTION DATA

Door #2 Open 00 hr 02 min 14 sec

Figure 4-8 - Set Point Modify Screen Example

1. # - Each parameter is assigned a number
2. Parameter - The names of the parameters are listed next to the # column
3. Units - This represents the unit of measure for a parameter.
4. Value - This represents the actual setting value



Parameter descriptions that say “Spare” or “Reserved” are available slots that are either not used by the PLC or are reserved by the PLC for available equipment options that are not a part of this system.

Changeover Point Screens

Several screens in the Set Point Modify group were included to store changeover related data. Changeover points have dial indicator readings or scales to mark their set point. These screens are used to store that data. An operator can refer to these settings to aid with changeover.

ARPAC
OUR INTEGRATION
YOUR SUCCESS

SETPOINT MODIFY 4

RECIPE #3 4 Pack 30 Trays / min.

ENGLISH 1:43:46 PM 6/28/2017 SECURITY: 5

#	SETPOINT	UNITS	VALUE	SAVE
16	Changeover Point #1	#	168	
17	Changeover Point #2	0.1"	2	
18	Changeover Point #3	0.1"	9	
19	Changeover Point #4	0.1"	139	
20	Changeover Point #5	0.1"	82	

OVERVIEW RECIPES SETPOINTS MAINTENANCE PRODUCTION DATA

Door #2 Open 00 hr 02 min 36 sec

4.5.4. The Maintenance Menu Group

The Maintenance menu group allows a user to access various maintenance-level functions. This menu requires security level 3 or above for access.

Main Maintenance Screen





Figure 4-5 - 1st Maintenance Screen

From this Maintenance screen, qualified personnel can change the following:


- **Logout Delay** - Once someone logs in to a security level, that login remains active based on this setting. Once the Logout Delay times out, that person would need to re-enter the password.
- **Override Interlocks** - This machine is capable of being interlocked to other equipment immediately upstream or downstream. If these options are being used, an operator can override these interlocks if necessary by pressing this button.
- **Diagnostics List** - This button is used to view the communication protocol messages between the HMI and the PLC.
- **Reset Master FB "0" Position** - Press this button to reset the zero position of the Pacing Flights Bars to current encoder position.

Timers & Counters Screen



The Timers & Counters screen allows one to see preset parameter values and accumulated values, but does not list the specific timer description. This screen should be used as a diagnostic tool, along with the PLC code for troubleshooting.

Alarm History



Alarm History shows alarms and faults that occurred on the system. Use the red buttons to acknowledge and clear the list, cycle from one to another or page up and down the list.

PLC Chassis Screens





Figure 4-10 - PLC Chassis Screen

To aid with diagnosis of issues and troubleshooting, multiple diagnostic screens have been provided. Not all of them are covered here, but the concept for all the screen are the same.

Touching the screen where a text block exists will open an addition screen. The example below is the screen what would appear for the “Digital IN” text. A green box indicates the I/O is “ON” and a gray box indicates the I/O is “OFF”.



Maintenance Level Set Point Modify Screens

OUR INTEGRATION
YOUR SUCCESS

SETPOINT MODIFY 14

RECIPE #3 4 Pack 30 Trays / min.

ENGLISH 1:44:49 PM 6/28/2017 SECURITY: 5

#	SETPOINT	UNITS	STATUS	ON	DISTANCE	SAVE
71	Infeed Conveyor Stop	0.1in	☐	30	30	Collator FB Position 1.98
73	Detect Tray for Glue Window	0.1in	☐	51	8	
75	Main Drive Stop	0.1in	☐	320	30	Pacing FB Position 3.57
77	Glue 1st Pulse	0.1in	☐	115	10	
79	Glue 2nd Pulse	0.1in	☐	138	10	

Low Blank Supply

OVERVIEW RECIPES SETPOINTS MAINTENANCE PRODUCTION DATA

Door #3 Open 00 hr 00 min 47 sec

Several Set Point Modify screens, similar to those in the Set Point Modify group are included in the Maintenance group. These screens are included here and not in the Set Point Modify group because these settings are typically only required to be accessed and modified during initial set-up and/or during troubleshooting.

4.5.5. The Production Data Menu Group

The Product Data menu group has two screens; Production Data and Production Data Settings. product count per shift with a running total. Access level 3 or above is required to clear production data.

Production Data




Figure 4-11 - Production Data Screen

- Data values related to the number of loads wrapped are displayed here.
- Two different reset buttons allow for resetting the production data for the current shift only or all the data collected since the last reset occurred.

A warning message that has to be acknowledged will appear before the data can be reset.

Production Data Settings

The second screen related to production data allows an operator or supervisor to change the shift times

ARPAC **SETTINGS**

OUR INTEGRATION
YOUR SUCCESS

RECIPE #3 4 Pack 30 Trays / min.

ENGLISH 1:47:44 PM 6/28/2017 SECURITY: 5

	Start	Finish
Shift #1	7:00 am	7:00 pm
Shift #2	7:00 pm	7:00 am
Shift #3	DISABLED	DISABLED

NOTE: Set Start and Finish to zero to disable Shift.

OVERVIEW RECIPES SETPOINTS MAINTENANCE PRODUCTION DATA

Door #8 Open 00 hr 00 min 10 sec

Figure 4-12 - Production Data Settings Screen


- Press inside any of the boxes for **Start** or **Finish** to change the setting. The numeric key pad will pop-up. Enter the new value and press the ENTER key.

4.6. Using the HMI

The following describes how to use the HMI.

4.6.1. Logging In

The HMI, when first powered on, boots up on security level 0. Security level 0 allows an operator to view the machine status and to start and stop the machine. Accessing screens requires an operator to be logged.



1. Log in by pressing the green LEVEL button.
2. The numeric key pad will open. Enter the 4 digit password for that required level.
3. Press the ENTER key.

NOTICE

Passwords can be obtained by your company's authorized personnel or by calling Arpac's Technical Service department.

4.6.2. Loading & Copying Recipes

This machine has the ability to store multiple different recipes. Recipes contain the set point values for various machine functions. Each recipe is identified by a number and name. Security level 1 or higher is required to load a recipe.

Loading an Existing Recipe




Figure 4-13 - Recipe Load & Copy 1 screen

When you wish to load a recipe, you must make sure the machine is out of cycle.


1. Identify the assigned # of the Recipe you want to load.
2. Press the LOAD FROM to open the numeric keypad. Enter the recipe number you wish to use.
3. Press LOAD to upload. Click YES to load the recipe or NO to abort the operation.

NOTICE

A warning pop-up will appear letting you know you are about to overwrite the current recipe settings.

Using the Copy Recipe feature to Create a New Recipe

Copying a recipe overwrites the data stored in one recipe and replaces it with the data from another recipe.



1. Press COPY FROM to open the numeric keypad and enter the recipe number from which you wish to copy set points.





The recipe you are copying information from remains unaffected by this operation.

2. Press COPY TO to enter recipe number that you wish to copy the setpoints to for use.
3. Press CANCEL to abort the operation without copying any data.
4. Press COPY to copy the recipe.
5. A warning pop-up will appear letting you know you are about to overwrite the contents.

Press YES to copy the recipe data or NO to abort the operation.

4.6.3. Changing Values

To change a value, navigate to that screen.




1. Press the box containing the set point value. The pop-up keypad will appear.
2. Enter the new value.
3. Press the ENTER key to accept the new value.

5

Operating Procedures

5.1. Applying Power

Power is applied to the equipment at the Main Electrical Cabinet






Figure 5-1 - Main Disconnect Switch

1. Make sure the machine is connected to its power source.
2. Notify all involved that power is being applied.
3. Flip the Main Disconnect to the ON position.
4. Press the POWER ON push button @ the Main Control Cabinet.

5.2. Loading Consumables

5.2.1. Loading Blanks



1. Inspect the blanks to be loaded and discard any that are damaged. Examples of damaged blanks are the following: blanks that are coming apart, that have water damage, that are warped, that are torn or have crease marks from banding straps.
2. Orient the blanks as they will be run. Make sure that the score line side is up. Some stacks may have blanks upside down. Always watch for these and position them properly or the blanks will jam.
3. Load the blank magazine. Do not allow the height of the blank stack to exceed the height of the side guides.
4. Load the blanks stacks onto the conveyor as shown. Make sure that the stacks are square and oriented in the correct direction. Also, the stacks should be at least 6" away from adjacent stacks.

5.3. Startup and Shutdown Procedures

5.3.1. Pre-Start Inspection

Before starting the machine, check for the following:

5. 1. Make sure the machine and the area around the machine is clear of items not directly related to the normal operation of the machine.
6. Check the pneumatic lubricator and regulator. Fill or empty, accordingly.
7. 3. Inspect the tunnel's insides and belt, for film and any other debris.
8. 4. Make sure that all persons in the area of the machine are aware the machine is about to start.

5.3.2. Apply Power

1. Place the **Main Power Disconnect** switch to the ON position.
2. Open the **Master Air Supply Regulator** valve. Verify the air regulator gauge is at least 80 psi.
3. Pull out all **Emergency Stop** push-pull buttons.



If this is the first time the machine has been turned on in your plant, be sure to check the tunnel conveyor belt and blower motors for the proper rotation. If either are going in the reverse direction, then **STOP!!!** Shut off the machine immediately. Running the machine in reverse could damage the machine.

4. 5. Press the **Power On** push button. This will turn on the Seal Bar heating elements, the Tunnel heater elements and the main drive motor.

5.4. Putting the TrayStar™ Into Cycle



Make sure all personnel are clear from machine before putting the machine in cycle. Press the **EMERGENCY STOP button to stop the machine if a hazard appears to personnel or the machine.**



Power has to be applied and all faults must be cleared before the machine can be put into cycle.

1. Make sure consumables have been loaded.
2. Make sure that proper recipe for the product has been selected.
3. Press the **CYCLE STOP/RESET** button.
4. Press the **CYCLE START** button.

5.5. Stopping the TrayStar™

5.5.1. Performing an Emergency Stop

In case of an emergency, press any one of the Emergency Stop push buttons to stop the machine immediately.

Recovering from an Emergency Stop

After pressing the **EMERGENCY STOP** button, do the following to reset the machine:

1. Remove all product from machine.
2. Remove or resolve the cause of the emergency stop action.
3. Pull all the **EMERGENCY STOP** buttons out.
4. Press the **POWER ON** button.
5. Press the **CYCLE STOP/RESET** button.
6. Press the **CYCLE START** button.

5.5.2. Stopping Under Normal Conditions

The best way to stop the machine, under normal conditions, is to press the **CYCLE STOP / RESET** push button. This allows the machine to come to a controlled stop.


NOTICE
Opening a guard door will also stop the machine, but this method isn't a controlled stop and removal of some product will be necessary, increasing the amount of time the machine will be out of cycle.

5.6. Clearing Jams/ Recovering from a Fault

A complete list of faults, possible causes and corrective actions is included in the Troubleshooting chapter. This section explains how to identify the fault and procedures for restarting.

5.6.1. Identifying the Fault

When a fault occurs, a red banner will appear at the bottom of the HMI screen indicating what the fault is.



5.6.2. Address the Cause

1. Remove product, if necessary
2. Reset any torque limiters, if necessary
3. Prep the machine for a restart by adding or removing product, if necessary.
4. Close the guard door.
5. Press the **CYCLE STOP / RESET** button.
6. Press the **CYCLE START** button when ready.

5.7. Shutting Down

5.7.1. Short Term Shut Down

To stop the machine for a short period of time (lunch break, product changeover, etc), press the **CYCLE STOP / RESET** button.


5.7.2. Long Term Shut Down

To completely shut down the machine for an extended period of time (maintenance, end of production for the day):

1. Press the **CYCLE STOP / RESET** button.
2. Clear out any product from the machine.
3. Press an **EMERGENCY STOP** push button.
4. From the Main Electrical Cabinet, turn the **Main Disconnect Switch** to the OFF position.

5.8. Resetting Torque Limiters

Chain driven assemblies come equipped with a torque limiter that trips and disengages the assembly due to excessive force caused by a jam.



All torque limiters, like the *Flap Tucker* torque limiter (2) shown here, have a spring loaded plate that energizes a prox switch (3) when tripped. A corresponding input is sent to the PLC to stop the machine and display a fault message.

- With the machine cycle stopped, use the provided hand wheel (1) to reengage the torque limiter.
- Press a **CYCLE STOP / RESET** button to clear the fault.

6

Troubleshooting

6.1. Overview

This chapter includes troubleshooting information, divided into two sections to guide you through getting the machine up and running with minimal downtime.

The first section is a table of fault messages that appear on the HMI. Below that is a list of remedies.

The second section is a compiled list of possible abnormal running conditions and their remedies.



Do not attempt to service equipment that is in cycle. Serious injury or death may occur. Properly stop the equipment when addressing faults. Refer to you specific plant safety protocols required for opening guard doors to clear jams and faults.

Perform LOTO before performing maintenance.

6.2. Faults Messages

Message	Possible Cause	Remedy
Trayloader Low Air Pressure	Air supply is not connected to machine or is OFF. Shut-off Valve is closed. Air regulator is not set correctly. Air filter is clogged. Main air solenoid valve is faulty. Air pressure switch faulty.	Make sure that air line is connected and ON. Make sure that main air valve is in the SUP position. Make sure air regulator is set to 80 PSI. Replace air filter according to Section Check operation of main air solenoid valve. There is a red LED indicator on the valve that will light up when the valve is activated provided that the valve and it's support circuits are working properly Check operation of pressure switch.
Glue Unit Not Ready	The glue hoses, guns and/or tank are not at setpoint temperature.	Wait for temperature to reach setpoint temperature. Refer to glue units instruction manual for more details.

Message	Possible Cause	Remedy
Detect Blank Missed On Blank Feed Conveyor.	Blank not picked and fed. “Detect blank in position” photo eye problems.	Check cups for clogs and cleanliness Check mounting and function of photo eye.
	Damaged or warped corrugated blank.	Remove blank. Inspect blanks in magazine for similar conditions.
Blank Jammed at Blank Feed Conveyor	Blank Feed Torque Limiter tripped.	Clear jam. Reset torque limiter.
Fallen Product - Trayloader Flight Bar Area	Product has fallen in pacing flight area.	Remove product. Check for any obstructions in area.
Blank Feed Conveyor Torque Limiter Tripped	Lugged conveyor is jammed by an obstruction.	Correct jam condition. To reset torque limiter, locate associated handwheel or ratchet point and turn until torque limiter engages.
	Torque limiter not set properly.	If torque limiter disengages under normal or starting load conditions, verify torque setting on limiter. Adjust as needed.
	Torque limiter proximity sensor problems.	Inspect wiring and position of sensor. Adjust or repair as needed.
Trayloader Flight Bar Torque Limiter Tripped	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>

Message	Possible Cause	Remedy
Flap Tucker Torque Limiter Tripped	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>
Trayloader Flight Bar Torque Limiter Tripped	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>
Blank Pusher Torque Limiter Tripped	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>
Tray Former Torque Limiter Tripped	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>
Product Release Gate Jammed	Collator Clamp did not get back to the full down position.	Check for and remove any obstruction.
Main Drive Fault	Drive controller fault.	Shut down the machine for a minimum of 1 minute and restart the machine. Refer to the controller manual on CD for more details.
Collator Servo's Not Ready	Drive controller fault.	Shut down the machine for a minimum of 1 minute and restart the machine. Refer to the controller manual on CD for more details.
Flap Closer Torque Limiter Tripped	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>
Collator Must Be Homed	Servo motor has lost track of its position.	Press HOME button on HMI Machine Controls screen.

Message	Possible Cause	Remedy
Collator Jammed	Escapement Flight Bar Clear PE blocked as product is being released	Check for and remove any obstruc- tion.
Reset Door Safety Relay	A guard door was opened, then closed and the CYCLE STOP / RESET button was not pressed.	The guard door safety relay circuit can detect when a door is open and when one is closed. In this situation, the LED on the switch will be flashing green
Blank Roller Drive Fault	Drive controller fault.	Shut down the machine for a mini- mum of 1 minute and restart the machine. Refer to the controller manual on CD for more details.
Open Flap Detected	<i>See: Blank Feed Con- veyor Torque Limiter Tripped</i>	<i>See: Blank Feed Conveyor Torque Limiter Tripped</i>
Main Drive Ratchet Missing	Prox Switch to detect presence of ratchet not made	Replace missing ratchet
		Check for faulty prox sensor
		Check position of prox sensor
Door “#” Open	Canopy door is open.	Close door. Press CYCLE STOP / RESET button
Blank Magazine Door “#” Open	Guard door on Extended Blank Maga- zine is openis open.	Close door. Press CYCLE STOP / RESET button

Message	Possible Cause	Remedy
E-STOP “#” Pressed	Emergency Stop button pressed at location cited.	Make sure all Emergency Stop buttons are pulled up. Press CYCLE STOP/RESET button to clear message
Line E-Stop Engaged	Emergency Stop button on the equipment interconnected to the TrayStar pressed	Make sure all Emergency Stop buttons are pulled up. Press CYCLE STOP/RESET button to clear message
Blank Loader Bridge is Not in the Down Position	Prox Switch to detect down position not made	Replace missing ratchet
		Check for faulty prox sensor
		Check position of prox sensor
Blank Lifter Jammed	The Blank Lift assembly left the DOWN prox and did not make the UP prox in time or did not make it back to the DOWN prox in time	Check for an obstruction
		Check position of prox sensor
		Check for an obstruction
Blank Loader Jammed	The Blank Loader assembly left the HOME prox and did not make the FORWARD prox in time	Check for an obstruction
		Check position of prox sensor
		Check for an obstruction

Message	Possible Cause	Remedy
Blank Magazine Conveyor Drive Fault	Drive controller fault.	Shut down the machine for a minimum of 1 minute and restart the machine. Refer to the controller manual on CD for more details.
Escapement Servo Faulted	Drive controller fault.	Shut down the machine for a minimum of 1 minute and restart the machine. Refer to the controller manual on CD for more details.
Home Escapement Servo	Servo motor has lost track of its position.	Press HOME button on HMI <i>Machine Controls</i> screen.
Escapement Flight Bar Blocked	Escapement Flight Bar Clear PE blocked when Escapement FB's started to move	Remove product, Home servo and press CYCLE STOP/RESET button to clear message and reset the machine

6.3. Abnormal Running Conditions

This section was designed to help the operator and the maintenance personnel understand and resolve abnormalities with the machine.

This section was designed to help the operator and the maintenance personnel understand and resolve any possible abnormalities with the

machine. Abnormal running conditions and operator interface error messages are covered.

Use the following troubleshooting index and troubleshooting charts as an aid in solving your machine's malfunction.

Problem	Possible Cause	Remedy
Product Jams at Infeed Conveyor	Insufficient back pressure. Infeed side guides too loose/tight	Increase speed of upstream conveyor. Set up the product triangle pattern and check for the proper clearance.
Product Jams at Collator	The collator is not set up for the proper width and/or length.	Reset the width of the collator using the operator interface.
Product Escapes From Collator Lugs	The collator is not set to the proper width. The products have loose labels. The center guide is not square with the collator. Is the center support guide mounting tight?	Check the pack pattern and adjust the width accordingly. Correct the problem at labeler. If not, reposition the center guide. Check center support nut for tightness.
Pacing Flight Bar Problems	The flight bar infeed guides are not set properly for the product size being run through the machine. The flight bar conveyor is not set up properly.	Recheck the guides and if wrong, readjust. Verify that the machine is set to mechanical zero.

Problem	Possible Cause	Remedy
Blank Feed Problems	The clearance is not set properly on the blank magazine.	When properly set, the tray should have a maximum 1/16-inch side and end clearance.
Blank Feed Problems (Cont.)	The support pins are not set properly on the blank magazine. The rear "T" support on the blank magazine is not in the correct position.	Check the pins on each side. Center pints should be equal and protrude further than additional pins, which should be set for minimal engagement. Take care not to pre-break minor flaps. The centerline of the front rod of the "T" support should be positioned at the tray edge.
Blank Ejector Problems	Incorrect program setup. The blank ejector lugs are not set to the correct position. Incorrect air pressure.	Recheck the Electro Cam program number and settings for the proper channel. Verify program number and product size. Reset the position of the blank ejector lugs. Check airflow adjustment (solenoid/cylinder). Check for air leakage.

Problem	Possible Cause	Remedy
Blank Conveyor Jams	Loose, broken or worn drive timing belts. Bad tray blanks.	Check and replace worn parts. The trays should be clean, flat and dry. The trays should not be bowed or warped more than 1/4 inch/linear foot. Check to see if the tray blank is in the wrong direction.
	Wrong size tray blank. Parts and/or a damaged tray blank blocking discharge path. Bad or worn bearings. Loose, broken or worn drive timing belts. Blank feed conveyor torque limiter is out of adjustment. Blank feed conveyor synchronizer faulty or out of adjustment.	Measure the trays to see if they are correct. Check the tray blank lower path is clear of debris. Check and replace worn parts. Adjust lubrication schedule. Check for proper alignment. Check that the torque limiter is in proper adjustment Check tightness and/or replace belts. Check for proper roller chain adjustment.

6-11

Problem	Possible Cause	Remedy
Flap Closure Problems	Flap closure torque limiter not reset.	Check that the torque limiter is in proper adjustment.
	Flap closure out of adjustment.	Flap tucker must engage, tuck and remain engaged until retained by guides allowing a 1/4-inch clearance from tucker to tray on each side.
	Tray/product not centered.	Center tray and or the product.
	Flap closure parts loose, worn or broken	Inspect and replace worn or broken parts.
Glue Guns Not Operating	No or low glue supply.	Check; if low, fill the glue unit.
	Low air supply to the glue unit.	Adjust incoming pressure to 80 psi.
	Low supply of glue.	Inspect glue supply and add glue, if needed.
	Low glue temperature.	Inspect the temperature of the glue and adjust, if needed. Make sure to stop production until the glue temperature is correct.
	Dirty, defective or misaligned glue photo eye.	Inspect the photo eye sensor and wiring. Clean or replace as needed.
	Glue gun/nozzle damaged or clogged.	Clean/replace component.
	Main glue unit not set up properly for the application.	Check glue supplier for correct set up procedure.

Problem	Possible Cause	Remedy
Trays Not Sealing	Glue gun disconnected. Low air supply to the glue unit. Glue gun damaged. Clogged nozzle. Bad or wrong glue Faulty glue photo sensor. Damaged or disconnected hoses.	Check for a broken or disconnected air line to the glue gun; if damaged, replace it. Adjust incoming air pressure to 80 PSI. If damaged, replace glue gun Unclog the nozzle. If the wrong glue type was accidentally added to the glue unit, serious problems could result. Check with the glue manufacturer for glue compatibility and follow their directions. Check for damage and repair.
	Glue guns not properly set up, programmed or adjusted.	If the problem still persists, re-read and follow the Electro cam glue setup procedures. Check glue suppliers. Verify program number and product size.

Problem	Possible Cause	Remedy
Trays Not Sealing (Cont.)	Main glue unit not properly setup for the application.	Re-read and follow directions on the setup of the tray-forming conveyor.
	Wrong tray or product size. Flap closure side rails too high or too low. Compression side rails not properly adjusted. Wrong program Side compression and lug compression not properly adjusted for the required tray size.	Verify program number and product size.

7

Maintenance

7.1. Preventive Maintenance Schedule

Refer to the schedule below for information on when to perform periodic maintenance on the machine.



Due to varying operating conditions, the procedures listed below may have to be performed at greater or lesser intervals. You may have to adjust intervals according to your machine's performance



The following procedures should only be done after the machine has been turned off, allowed to cool down and the air pressure has been released. Always follow Lockout/Tagout procedures. Always wear safety glasses and all required personal protective equipment.

Task	When To Do It			
	Daily	Weekly	Quarterly	Every 6 Months
Perform Walk Around Safety Inspection	X			
Clean External Surfaces	X			
Check EMERGENCY STOP Button For Proper Operation	X			
Inspect Vacuum Cup Filters	X			
Clean Photo Eyes		X		
Inspect Glue Gun Nozzles & Hoses		X		
Inspect Conveyor Belts			X	
Lubricate Drive Chains			X	
Inspect Chain Tensions			X	
Check Fastners				X
Grease Zerk Fittings				X
Inspect Gearbox Seals				X

Table 7-1 - Periodic Maintenance Schedule

7.2. Daily Tasks

7.2.1. Walk Around Safety Inspection



Before continuing with any maintenance checks, shut off power supply to machine. You can be severely injured if you do not.

At the beginning of each day, do a daily safety inspection of the machine and its surrounding area. Pick up any trash or obstacles around the machine. Wipe up any grease or spills.

Commodities like rolls of film should be placed conveniently, yet out of the way so an operator can move around safely.

The areas in red represent areas around the machine that should be kept clear so an operator can safely operate the equipment.




Figure 7-1 - Walk around inspection

7.2.2. Cleaning External Surfaces



Required Tools

You need the following special tools for this procedure:

- cleaning wipes or a soft, damp cloth



Warning

Turn off machine's main disconnect switch before servicing machine. You can get severely injured if you do not.

1. Use cleaning wipes to clean external surfaces of the machine.

7.2.3. Check Emergency Stop Button

Verify functionality of all Emergency Stop push buttons. With the machine cycling, press the **EMERGENCY STOP** button. The machine should stop immediately. Pull button back up and press RESET button to reset.



E-Stop in normal run state.



E-Stop activated.
(LED illuminated)

Figure 7-2 - Emergency Stop Push Button

7.2.4. Inspect Vacuum Cup Filters

Inspect the vacuum cups for corrugate dust. Use an air nozzle with low pressure to blow away debris.



7.3. Weekly Tasks

7.3.1. Cleaning Photo Eye

To clean the photo eye spray a small amount of window cleaner on it and wipe it clean with a cleaning wipe.





Figure 7-3 - Photo Eye Lens

7.3.2. Inspect Glue Guns & Hoses

The type of glue system depends on the application, but the principal is the same regardless. Inspect and clean as necessary all glue system components; nozzles, glue gun, hoses and connections.



7.4. Quarterly

7.4.1. Inspect & Clean Conveyor Belts

Inspect the plastic modular belting for any loose pins at the edges of the belt (1) or damaged links (2). Using cleaning wipes or a soft damp cloth, wipe remove any built up debris.



Figure 7-4 - Inspect Modular Belts




Figure 7-5 - Inspect Table Top In-feed Conveyor Belt


7.4.2. Clean & Lubricate Drive Chains



Required Tools


You need the following special tools for this procedure:

- cleaning wipes
- Light weight chain lubricant
- Applicator



7.4.3. Inspect Compression Chain Tension

Each of the Leading and Trailing Compression chains comes with a chain tensioner. Adjust as necessary.



7.5. B-Annual

7.5.1. *Checking Fasteners for Tightness*



Required Tools

You need the following special tools for this procedure:

- Adjustable End Wrench
- Medium Flat Tip Screwdriver
- Medium Phillips Tip Screwdriver
- Set of Hex Wrenches

Check/tighten all exterior fasteners.

7.5.2. *Inspect Gearbox Seals*

The gearbox types used on this equipment are referred to as: “SEALED”, meaning; according to the OEM, the gearboxes are sealed and do not require additional lubrication, but the seals at the motor/gearbox union should be inspected twice a year for leaks.

7.6. Chain & Bearing Maintenance

7.6.1. Chain Lubrication & Care

Proper lubrication is critical in achieving the maximum wear life of any roller chain. As the chain articulates around the sprockets, the pin and bushing wear. This wearing causes the elongation, or “stretch”, in the chain. Lubrication of these surfaces through proper lube application can greatly increase the wear life of the chain.

Recommended Lubricants

Ambient temperature: 20-40 F - SUS Viscosity 100 F of 200-400, SAE Engine oil of 20 Weight, SAE Gear Oil 80 W, ISO 46 or 68, and AGMA lubrication 1 or 2.

Ambient temperature: 40-100 F - SUS Viscosity 400-650, SAE Engine oil of 30 Weight, SAE Gear Oil 85 W, ISO 100, and AGMA lubrication 3.

Ambient Temperature 100-120 F - SUS Viscosity 650-950, SAE Engine oil of 40 Weight, SAE Gear Oil 90, ISO 150, and AGMA lubrication 4.

Ambient Temperature 120-140 F - SUS Viscosity 950-1450, SAE Engine oil of 50 Weight, SAE Gear Oil 90, ISO 220, and AGMA lubrication 5.

7.6.2. Bearing Lubrication & Care

Food Grade

LUBRIPLATE SFL-2 is a **synthetic multi-purpose food-grade grease**, which can be used throughout most modern food processing plants for most all grease lubrication requirements. This product has an approximate operating temperature range of -25 to 400°F. (white in color).

Non-Food Grade

MULTIPLEX RED #2 **lithium complex grease** developed for the lubrication of automotive and industrial equipment operating under heavy loads and at moderate to high temperatures. It is particularly recommended for use in applications that are too severe or require higher performance than provided by conventional extreme-pressure lithium greases.

These are just brands, there are many other comparable brands which can be used on industrial equipment use in secondary packaging.

They only need to be comparable in temperature range, viscosity, and application (food grade or not).

Service/Support Information

8.1. Service Information Introduction

This section contains an overview of ARPAC®'s field service policies. ARPAC aims to deliver the highest level of service with the assistance of the aftermarket department, SupportPro™.

8.2. Objective

To furnish our customer with prompt, competent, and complete service so they can operate at optimum efficiency.

SupportPro is a one-stop, nation aftermarket solution, representing strategic secondary packaging equipment partners. Our facilities in Chicago and Syracuse, combined with a nationwide field service network, allow us to provide a complete range of aftermarket services. We offer these in a convenient, cost-effective, and value-added manner for our equipment partners and end-customers across the US.

8.3. Service Personnel

Our technical services work to optimize your equipment investment. With their experience in servicing ARPAC equipment, instructing customer's personnel in correct operation and maintenance is a simple task. All field service technicians receive support from the factory and engineering departments.

8.4. Training

An ARPAC advantage is free lifetime training for customers purchasing packaging machines from ARPAC or its distributors. Knowledge of machines leads to power, performance, and profitability. SupportPro teaches theory of operation, machine setup and operation, preventive maintenance and long-term care. For further information please contact SupportPro at 844.777.8776.

8.5. ARPAC & SupportPro Commitment

Consistently accessible to communicate with customer(s). Service Technician availability for supervision and instruction of personnel. The goal of the tech is to minimize downtime of your production facilities and commence training of your personnel.

8.6. Tech Scheduling

Please allow 10-days advance notice to schedule a SupportPro technician. Emergency situation are handled as quickly as possible. If assistance is required please contact SupportPro to schedule a technician at 844.777.8776.

8.7. Instillation Policy


All equipment is unloaded, unpacked and inspected for any damage. If there is any damage, the Bill of Landing will need to be signed describing the damage.

Prepare area to install your ARPAC equipment. Assemble your equipment.

Provide qualified technicians, operators, and maintenance personnel to start up system.

8.8. The SupportPro Advantage

Leverage our aftermarket services. Our secure web portal gives you access to all documentation of your machines. Therefore, no need to reorder any lost manuals, schematics, or bill of materials. In addition, the portal user can access pictures and videos of their machine to visually understand the machine. Finally, the portal gives the machine operator secure way to contact SupportPro with any questions or concerns. Details about the web portal will be sent via email after the machine is shipped.





Illustrated Assembly Drawings & BOM

A.1. Illustrated Assembly Drawings & BOM

This section contains the bills of materials (BOMs) with mechanical prints. The mechanical print, if available, precedes the corresponding BOM. In some instances, the mechanical print is not available. The BOM, whether a print accompanies it or not, still contains valid descriptions and part numbers for the assemblies.

REVISIONS

RV	DATE	BY	DESCRIPTION
A	5/10/2021	SRA	ADDED BRIDGE CONVEYOR TO SIDE TRANSFER



PRODUCT INFORMATION				PRODUCT IN				PRODUCT OUT			
PROD #	PRODUCT DESCRIPTION	WIDTH	LENGTH	HT	RATE	PATTERN	WIDTH	LENGTH	RATE		
1	355 ML 12 COUNT LOOSE	2.26	2.26	6.13	744	4 X 3 X 1	9.04	6.78	62		
2	355 ML 4-PACK CARTON, 6 PER TRAY	4.52	4.52	6.13	200	3 X 2 X 1	13.56	9.04	34		
3	355 ML 8-PACK CARTON, 4 PER TRAY	6.78	4.52	6.13	134	2 X 2 X 1	13.56	9.04	34		
4	355 ML 12-PACK CARTON, 2 PER TRAY	9.04	6.78	6.13	67	2 X 1 X 1	13.56	9.04	34		
5	355 ML 24-PACK CARTON, 1 PER TRAY	13.56	9.04	6.13	62	1 X 1 X 1	13.56	9.04	62		
6	12 OZ 12 COUNT LOOSE	2.60	2.60	4.81	744	4 X 3 X 1	10.40	7.80	62		
7	12 OZ 24 COUNT LOOSE	2.60	2.60	4.81	800	4 X 6 X 1	10.40	15.60	34		
8	12 OZ 4-PACK CARTON, 6 PER TRAY	5.20	5.20	4.81	200	3 X 2 X 1	15.60	10.40	34		
9	12 OZ 8-PACK CARTON, 4 PER TRAY	7.80	5.20	4.81	134	2 X 2 X 1	15.60	10.40	34		
10	12 OZ 12-PACK CARTON, 2 PER TRAY	7.80	10.40	4.81	67	2 X 1 X 1	15.60	10.40	34		
11	12 OZ 24-PACK CARTON, 1 PER TRAY	15.60	10.40	4.81	62	1 X 1 X 1	15.60	10.40	62		
12	16 OZ 12 COUNT LOOSE	2.60	2.60	6.13	744	4 X 3 X 1	10.40	7.80	62		
13	16 OZ 24 COUNT LOOSE	2.60	2.60	6.13	800	4 X 6 X 1	10.40	15.60	34		
14	16 OZ 4-PACK CARTON, 6 PER TRAY	5.20	5.20	6.13	200	3 X 2 X 1	15.60	10.40	34		
15	16 OZ 8-PACK CARTON, 4 PER TRAY	7.80	5.20	6.13	134	2 X 2 X 1	15.60	10.40	34		
16	16 OZ 12-PACK CARTON, 2 PER TRAY	7.80	10.40	6.13	67	2 X 1 X 1	15.60	10.40	34		
17	16 OZ 24-PACK CARTON, 1 PER TRAY	15.60	10.40	6.13	62	1 X 1 X 1	15.60	10.40	62		

TECHNICAL INFORMATION

PRODUCT ELEVATION: 48" +2/-0
 ELECTRICAL POWER: 460V 60HZ 3PH, 70 FULL LOAD AMPS
 MAIN CIRCUIT BREAKER AMPERAGE: 90A, 5KA SCCR
 COMPRESSED AIR: 80 PSI (OPERATING PRESSURE) 20 SCFM
 AMBIENT TEMPERATURE LESS THAN 95 DEG F
 ARPAC PAINT COLORS: BLACK & SILVER
 IP ADDRESS SCHEME: 10.255.255.XXX
 PLC FIRMWARE VERSION: STUDIO 5000 V32
 HMI FIRMWARE VERSION: FACTORY TALK STUDIO V10

ANY PRODUCTS SPECIFIED ABOVE THAT ARE NOT PROVIDED FOR MACHINE SETUP/TESTING AT ARPAC, INCLUDING CONSUMABLES (CORRUGATE, FILM, GLUE), WILL REQUIRE ADDITIONAL SETUP/TESTING IN THE FIELD AT THE STANDARD SERVICE AND ENGINEERING RATE.

Approved By: _____

Signature: _____

Date: _____



RETURN TO:

ARPAC

ARPAC
 A DURALAVANT COMPANY

9555 WEST IRVING PARK RD.
 SCHILLER PARK, IL 60176

DRAWN: 4/22/2021	BY: SRA	SCALE: N/A	SIZE: B
RELEASED:	FILENAME: S220562-1-1	APPROVED BY:	
DESCRIPTION: LAYOUT, TRAY LOADER, TS-2300			
BLUE MARBLE PRODUCTIONS		DRAWING NUMBER: S220562-1-1	



3	1	800318-002	PIN, ROLL, 1/4X3/4 LG
2	1	135004	SLEEVE, 7/8 SQ.
1	1	134996	SHAFT, 7/8 SQ.
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:
FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°

DRAWN: 8-13-99	BY: FEB	SCALE: 1:1	SIZE: A
RELEASED: 8-13-99	FILENAME: 135005	APPROVED BY: FEB	







ASSY, SLEEVE, SQUARE

FINISH- NONE

DRAWING NUMBER:
135005

REVISIONS			
RV	DATE	BY	DESCRIPTION
A	4/23/2018	HG	19-5/64 WAS 18-21/64



ITEM	QTY	PART NUM	DESCRIPTION
27	4	199589	ARM, LUG WPINS, BLANK, CONV., LH MACH.
26	1	195403-002	BKT, FRONT, BLANK CONV. LH
25	2	809370	FSNR, WASHER, C/SINK, 4MM, TYPE GN184
24	1	837218	BRG, FLG, 1 ID, 3-BOLT, STD DUTY
23	1	191144-001	BRACKET, TAIL, BLANK, CONV. LH
22	1	191144	BRACKET, TAIL, BLANK, CONV. RH
21	2	827116	BRG, FLG, 1 ID, 2-BOLT, 3-88 BOLT CNTR
20	2	306773	BRG, FLG, 3/4 ID, 3-BOLT STANDARD-DUTY
19	12	800489	CHAIN, RLR, #60, HOLLOW PIN, PLEASE ORDER TSUBAKI ONLY
18	1	800609	CPLG, PHASE-LOCK, HDI-25-11 BORE
17	1	191142	SHAFT, IDLER CONV., BLANK
16	1	195403-001	BKT, FRONT, BLANK CONV. RH
15	1	809688	TENSIONER, SATP
14	1	192817	SPKT, 60B24, MOD. 0.750 BORE
13	8	110024	SPACER, TOGGLE, DOG BLANK
12	1	128423	SPKT, 60B24
11	1	110022-001	SPKT, 60A20, MOD. 1.750 BORE
10	1	191145	SHAFT, IDLER
9	2	809078	HDVMT, SAFETY, W/CPLG, 5/8 B., 5 1/2OD
8	1	113060	SPKT, 50A15, MOD. 1.000 BORE
7	4	108844	SPACER, LUG PUSHER
6	4	199591	ARM, LUG
5	4	137849	ARM, PIVOT, LH
4	1	187247	SHAFT, DRIVE CONV. BLANK
3	4	801350	CLAMP, RAIL, SINGLE, 1.5 LG. SS, ROUND HOLE
2	1	192598-000A	CHAIN, GUIDE #60
1	1	192815	CHANNEL, FORMED, CONV. BLANK

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED: FRACTIONS: ± 1/64
TWO (2) DECIMALS: ± 0.005
ALL DIMENSIONAL TOLERANCES: THREE (3) DECIMALS: ± 0.005
ANGLES: ± 0.5°


DRAWN: 06/14/2001 BY: FEB SCALE: 0.25:1 SIZE: D
RELEASED: 06/14/2001 FILENAME: 192812 APPROVED BY: FEB

DESCRIPTION: ASSY, CONV, FEED, BLANK


DRAWING NUMBER: 192812

36" PITCH X 4 = 144"


192812-001 LH MACHINE, AS SHOWN
192812-002 RH MACHINE, OPPOSITE



PART NUMBER	CONFIGURATION
220975	LH, AS SHOWN
220975-001	RH, OPPOSITE



220975



220975-001

17	1	324796	WASHER, SPECIAL
16	1	260166	PROX BRACKET
15	1	241985	PLT, MTG, RANGE
14	1	238683	WLDMT, WRENCH, INSERT
13	1	324771	SLEEVE, 7/8 SQ HOLE
12	1	324793	HANWHEEL, WITH INDICATOR
11	1	190806	ADJUST SCREW, W/ HANDLE
10	1	190805	ADJUST SCREW, W/OUT HANDLE
9	2	220981	BLK, LH THREAD, RAIL ADJ
8	2	220980	BLK, RH THREAD, RAIL ADJ
7	4	805929	BRG, FLG, 2 ID, 2-BOLT STANDARD-DUTY
6	2	134997	SPACER, 1" OD X 17/32 ID
5	2	104853	40B-42 SPROCKET, MOD, 2 BORE
4	1	800502	LINK, CONN, #40,
3	1	800462-002	CHAIN, RLR, #40, RLR RVT,
2	2	107918-100	CHAIN TAKE-UP SPACER
1	1	108213	SUPPORT, GUIDE CHAIN

ITM	QTY	PART NUM	DESCRIPTION
-----	-----	----------	-------------

BILL OF MATERIALS





ARPAC

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:

FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°





DRAWN: 10/03/2001	BY: TTR	SCALE: 1:14	SIZE: B
RELEASED:	FILENAME: 220975	APPROVED BY: TTR	
DESCRIPTION:	ASSY, SCREW, ADJ		
			
		DRAWING NUMBER: 220975	



21	1	244284-001	BLANK GUIDE, BOTTOM, LH
20	1	244293-001	BLANK GUIDE, TOP, LH
19	1	244292	BKT, BLANK GUIDE
18	1	242173	BKT, PROX, TARGET
17	1	242172	BKT, PROX
16	2	193143	NUT, REAR DOOR, LH THD.
15	1	193142-002	INT, DOOR, RH MACH
14	1	244266-002	GUIDE, SIDE, BLANK, LH
13	1	193141	GUIDE, SIDE, BLANK
12	1	193138	BLANK SUPPORT, BOTTOM
11	1	244267-002	SUPPORT, BOTTOM, BLANK, LH
10	4	187499	BRACKET
9	1	193137	BAR, BLANK GUIDE HOLDER
8	1	193136	BAR, BLANK GUIDE SUPPORT
7	1	193174	LIMITOR, TOP, BLANK
6	1	193173	LIMITOR, TOP, BLANK
5	2	802653	LATCH, VISE-ACTION
4	1	187546	DOOR
3	1	187545	SUPPORT, LOWER DOOR
2	1	193135	SUPPORT, BLANK
1	1	193134	SUPPORT, BLANK
ITEM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS		
AIRPAC 9511 WEST RIVER ST. SCHILLER PARK, IL 60176		
UNLESS OTHERWISE SPECIFIED: FRACTIONS: ± 1/64 TWO (2) DECIMALS: ± 0.005 THREE (3) DECIMALS: ± 0.005 ANGLES: ± 0.5°		
DRAWN: 4/09/2007	BY: LLS	SCALE: 0.1875:1 SIZE: D
RELEASED: 4/09/2007	FILENAME: 244278	APPROVED BY: LLS
DESCRIPTION: ASSY, BLANK, SUPPORT & GUIDE		
DRAWING NUMBER: 244278		

PART NUMBER	DESCRIPTION	ITEM 12	PART DESCRIPTION	ITEM 13	PART DESCRIPTION
244278-001	LH, AS SHOWN	193138	BLANK, SUPPORT, BOTTOM, MAGAZINE SIDE	193139	BLANK, SUPPORT, BOTTOM, DOOR SIDE
244278-002	RH, OPPOSITE	193141	GUIDE, SIDE, BLANK, MAGAZINE SIDE	193140	GUIDE, SIDE, BLANK, DOOR SIDE



286728 AS SHOWN
286728-001 OPPOSITE

25	2	294630	SPACER, IDL SPKT
24	1	822341	SLEEVE, 5/8ID, 3/4OD
23	1	822223	COUNTER, POSITION, CODE: CE986019
22	2	807746	BRG, FLG, 5/8 ID, 2-BOLT STANDARD-DUTY
21	2	800906	SPKT, 40BB17H, IDL, 5/8 ID, EXTREME SK9445
20	2	136727	SPKT, 40B13, MOD, 0.625 BORE
19	1	197876	SHAFT, ADJUSTING, LOWER, LH THD
18	1	197875	SHAFT, ADJUSTING, LOWER, RH THD
17	1	197874	NUT, LH
16	1	197873	NUT, RH
15	2	197872	BLK
14	2	197865	BLK
13	2	193214	SPACER
12	1	221899	NUT, LH
11	1	193213	NUT, ADJ., RH THD
10	2	802862	BRG, FLG, 5/8 ID, 3-BOLT STANDARD-DUTY
9	1	846703	HANDWHEEL, 6.3 DIA, COATED AL DISK W/O HANDLE, 0.5BORE
8	2	817248-001	CPLG, 5/8 BORE, ONE-PIECE W/KEYWAY, SS
7	1	193212	ADJUSTING SHAFT - COLLATOR, TS 2000
6	1	193211	ADJUSTING SHAFT - COLLATOR, TS 2000
5	2	193210	SHAFT, GUIDE
4	2	193209	SPACER
3	4	193204	ASSY, BLK, BUSH, SHAFT, 1", 6" LG, INCLUDES CARRIAGE BUSH BLK
2	2	193206	CLAMP, GUIDE, SHAFT
1	2	193205	CLAMP, GUIDE, SHAFT
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC 9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED:
ALL DIMENSIONAL TOLERANCES:

FRACTIONS
TWO (2) DECIMALS
THREE (3) DECIMALS
ANGLES

± 1/64
± 0.010
± 0.005
± 0.5°


DRAWN: 9/22/2020 BY: SCALE: 1:8 SIZE: C

FILENAME: 286728

DESCRIPTION: ASSY, COLLATOR GUIDE & ADJ.







DRAWING NUMBER:
286728



REVISIONS			
RV	DATE	BY	DESCRIPTION
A	1/10/2014	SRA	ITEM 9 WAS 802731
B	6/21/2016	SRA	ITEM 1 WAS 101909

12	1	822223	COUNTER, POSITION, CODE: CE986019
11	1	816364	CPLG, 3/4 BORE, SPLIT CLAMP 8-BOLT CLAMP
10	1	306773	BRG, FLG, 3/4 ID, 3-BOLT, MOD.
9	3	827113	BRG, BLK, PILLOW, 3/4 ID, INTERMEDIATE DUTY
8	1	290836	BKT, MNT, 1" -8 RH NUT
7	1	850550	SPKT, 40B13, MOD, 0.750 BORE, KWW&SS
6	1	290794	SPACER, BRG, MTG
5	1	193145	NUT, 1"-8, RIGHT HAND
4	1	189865	SHAFT, ADJ MAGAZINE
3	1	189864	SHAFT, MAG., ADJ., FRONT
2	1	141354	HAND WHEEL, SPECIAL
1	1	290835	PLT, MTG

ITM	QTY	PART NUM	DESCRIPTION
BILL OF MATERIALS			
		ARPAC	9511 WEST RIVER ST. SCHILLER PARK, IL 60176
		UNLESS OTHERWISE SPECIFIED ALL DIMENSIONAL TOLERANCES:	FRACTIONS ± 1/64 TWO (2) DECIMALS ± 0.010 THREE (3) DECIMALS ± 0.005 ANGLES ± 0.5°
DRAWN:	10/27/2012	BY: SR	SCALE: 1:8 SIZE: B
RELEASED:	10/27/2012	FILENAME: 290792	APPROVED BY: SRA
DESCRIPTION: ASSY, SCREW, ADJ, RH			
			DRAWING NUMBER: 290792



17	1	282786-001	GUARD, MAGAZINE, RH
16	1	282786	GUARD, MAGAZINE
15	1	282746-001	COVER, TOP, END
14	1	195417-001	CHANNEL, MAGAZINE, RH, LH MACHINE
13	2	810224	HDL, ADJ, SS, 1.57 LG 1/4-20 X 1.18 STUD
12	1	809737	FOLLOWER, CAM, 1 OD, 5/8-18 STUD, W/HEX HOLE, SEALED
11	1	802881	FOLLOWER, CAM, 1 OD, 7/16-20 STUD, CROWNED, ECCENTRIC 5/8 O.D
10	1	290830	WLDMT, CHANNEL, MAGAZINE, RH
9	1	282750	PLT, SLIDE, GUARD
8	1	282749	PLT, NUT
7	1	282748-001	COVER, TOP, DOWNSTREAM
6	1	282747-001	COVER, TOP, UPSTREAM
5	1	193151	COVER, BACK, MAGAZINE
4	1	189870	RAIL
3	4	189860	SPACER
2	1	189859	PLATE, BEARING MTG.
1	2	188687	PLATE, NUT
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176


UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:

FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°

DRAWN: 11/3/2012	BY: SR	SCALE: 1:12	SIZE: B
RELEASED: 11/3/2012	FILENAME: 290825	APPROVED BY: SRA	
DESCRIPTION: ASSY, MAGAZINE, GUIDE, SUPPORT, RH			

AS

DRAWING NUMBER:
290825



3	1	187337	SHAFT, RAIL
2	2	187346	ASSY, PILLOW BLOCK, OPEN
1	2	189866	BRACKET, MTG, SLIDE, BEARING
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED FRACTIONS $\pm 1/64$
ALL DIMENSIONAL TOLERANCES: TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES $\pm 0.5^\circ$

DRAWN: 10/27/12 BY: SR SCALE: 1:4 SIZE: A





RELEASED: 10/27/2012 FILENAME: 290827

DESCRIPTION:

ASSY, MAGAZINE, GUIDE, RH

DS

DRAWING NUMBER:
290827



REVISIONS			
RV	DATE	BY	DESCRIPTION
A	1/10/2014	SRA	ITEM 5 WAS 802731
B	6/21/2016	SRA	ITEM 2 WAS 101909

5	2	827113	BRG, BLK, PILLOW, 3/4 ID, INTERMEDIATE DUTY
4	1	193148	SPACER, BRG, MTG
3	1	188681	SHAFT, THREAD, REAR DOOR
2	1	850550	SPKT, 40B13, MOD, 0.750 BORE, AKA 101909
1	1	800462	CHAIN, RLR, #40, RLR RVT
ITM	QTY	PART NUM	DESCRIPTION


BILL OF MATERIALS

ARPAC 9511 WEST RIVER ST.
SCHILLER PARK, IL 60176




UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:

FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°

DRAWN: 10/27/12	BY: SR	SCALE: 1:6	SIZE: B
RELEASED: 10/27/2012	FILENAME: 290828	APPROVED BY: SRA	
DESCRIPTION: ASSY, SCREW, ADJ, MAGAZINE			
DRAWING NUMBER: 290828			




4	2	187536	PUSHER
3	1	213237	BAR, PUSHER
2	4	213238	PIN
1	4	213236	BLOCK
ITM	QTY	PART NUM	DESCRIPTION
BILL OF MATERIALS			
ARPAC		9511 WEST RIVER ST. SCHILLER PARK, IL 60176	
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONAL TOLERANCES:		FRACTIONS TWO (2) DECIMALS THREE (3) DECIMALS ANGLES	± 1/64 ± 0.010 ± 0.005 ± 0.5°
DRAWN:	10/26/12	BY:	SR
RELEASED:	10/26/2012	FILENAME:	290834
DESCRIPTION:		SCALE:	1:2
		APPROVED BY:	SRA
		ASSY, BAR, CHAIN, MAGAZINE FEED	
		DRAWING NUMBER: 290834	



6	4	807831	CLIP, RAIL, SELF-TIGHTENING, 5/16 STUD X 5/8 LG, SS, HEAVY DUTY
5	1	283419-002	GUIDE, SIDE, PRODUCT, LH
4	1	283419-001	GUIDE, SIDE, PRODUCT, RH
3	4	283373	BLK, CLAMP
2	8	810231	ROD, ADJ, 5/8 X 8 LG, 5/16-18 TAP, SS
1	2	283368	BKT, MTG, GUIDE
ITM	QTY	PART NUM	DESCRIPTION
BILL OF MATERIALS			
ARPAC		9511 WEST RIVER ST. SCHILLER PARK, IL 60176	
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONAL TOLERANCES:		FRACTIONS TWO (2) DECIMALS THREE (3) DECIMALS ANGLES	± 1/64 ± 0.010 ± 0.005 ± 0.5°
DRAWN:	12/3/2012	BY:	SRA
RELEASED:	12/3/2012	FILENAME:	291515
DESCRIPTION:		APPROVED BY:	SRA
		ASSY, GUIDE, SIDE, PRODUCT	
<i>AS</i>		DRAWING NUMBER: 291515	

REVISIONS			
RV	DATE	BY	DESCRIPTION
A	8/18/2016	SRA	CHANGED POSITIONS OF ITEMS 8, 9, 36, AND 37
B	11/15/2016	SRA	ITEM 41 WAS PART # 846368







ITEM 52 NOT SHOWN

52	1	272049	BKT. MTG. PROX
51	1	810218	BUSH, 1-3/8 BORE
50	1	800516	LINK, CONN. #60, COATED
49	1	800505	LINK, CONN. #50
48	1	803868-002	LOCKING DEVICE, KEYLESS 3/4
47	1	272050-001	WLDMT. BKT. MTG. PROX
46	1	228961-001	GUARD, ENCODER, DRIVE
45	1	129863-002	SPACER, IDLER, 2 1/2
44	1	221623-001	WLDMT. MTG. IDL. GEARBOX
43	1	825367	GEARBOX, BEVEL, 1:1, SPIRAL GEAR, 1-3/8 DIA. ALL SHAFTS, TYPE A
42	1	823018	GEARBOX, BEVEL, 1:1, SPIRAL GEAR, 1-1/4 DIA. ALL SHAFTS, TYPE A
41	1	851244	GEARMOTOR, HELICAL, IN-LINE, 5 HP, 230/460V, RATIO: 24.4:1, 1755 RPM MOTOR SPEED, PREMIUM EFFICIENCY
40	1	816281	CPLG., 1.25 X 1.25, KEYED
39	1	809942	GEARBOX, BEVEL, 1:1, SPIRAL GEAR, 1-1/4 DIA. ALL SHAFT, TYPE A
38	1	809888	TENSIONER, SAITP
37	2	808643	CLUTCH, OVERLOAD, BORE 1 1/4, PROX. PLT. SET TO 75 IN-#, WARPAC #
36	1	808642	CLUTCH, OVERLOAD, BORE 1 1/4, PROX. PLT. SET TO 500 IN-#, WARPAC #
35	1	808641	CLUTCH, OVERLOAD, W/O BUSHING, PROX. PLT. SET TO 1000 IN-#, WARPAC #
34	1	808474	CPLG., DISC, SINGLE FLEX, 1-1/2 X 1-3/8
33	1	807444	BRG., PILLOW BLK., 1-1/4 ID
32	2	807271	CPLG., DISC, SINGLE FLEX
31	1	803815	CPLG., DISC, SINGLE FLEX, 1-1/2 X 1-1/4
30	2	802835	BRG., LG., 1-1/4 ID, 3-BOLT
29	1	801160	STANDARD DUTY BELT, TIMING, 5MM P, 15MM W, 670MM LG.
28	1	800915	SPKLT. 608B13H, IDLER, 5/8 ID
27	4	800905	SPKLT. 608B13H, IDLER, 5/8 ID, HARDENED TEETH
26	1	800486	CHAIN, RLR, #50
25	1	800468	CHAIN, RLR, #50
24	1	283170	BKT. MTG. ENCODER
23	2	272670	BKT. PROX
22	2	226433	SPACER, IDLER
21	2	225523	SPACER, MNT. GEAR BOX
20	1	194537	PLT. NUT
19	1	194536	BKT. TENSIONER
18	1	194527	MAIN DRIVE SHAFT
17	1	194526	SHAFT, MAIN DRIVE
16	1	193168	SPROCKET, SPECIAL
15	1	193167	SHAFT, DRIVE, MAIN
14	1	193166	SPROCKET, SPECIAL
13	1	191136	BRKT. IDLER, INFEED & FLIGHT BAR
12	1	191121	JACK SHAFT, 1-1/4 DIA
11	2	187563	SPKLT. WITH POWER LOCK
10	1	187514	SPKLT. WITH POWER LOCK
9	1	187506	SPROCKET, SPECIAL
8	1	187505	SPROCKET, SPECIAL
7	1	135622	CPLG., DISC, SINGLE FLEX, 1.625 X 1.375
6	1	129863-001	SPACER, IDLER, 2 1/2
5	1	127921	SPKT. 50828, MOD. 1, 250 BORE
4	4	113061	SPCR MTG GEAR BOX
3	1	108225	DRIVEN, SPROCKET
2	1	108224	DRIVER, SPROCKET
1	2	107917	SPKT. 50820, MOD. 1, 250 BORE






ITEM QTY		PART NUM	DESCRIPTION
BILL OF MATERIALS			
AIRPAC 9511 WEST RIVER ST. SCHILLER PARK, IL 60176			
UNLESS OTHERWISE SPECIFIED: FRACTIONS: ±.004 ALL DIMENSIONAL TOLERANCES: TWO (2) DECIMALS ±.005 THREE (3) DECIMALS ±.005 ANGLES ±.5°			
DRAWN	11/2/2012	BY: SR	SCALE: 1:12 SIZE: D
RELEASED	11/2/2012	FILENAME: 294624	APPROVED BY: SRA
DESCRIPTION: ASSY. MAIN DRIVE			
			DRAWING NUMBER: 294624

294624-001	LH, OPPOSITE	221623-002	272049-001	272050
294624	RH, AS SHOWN	221623-001	272049	272050-001
ASSY No.	NOTE	ITEM 44	ITEM 47	ITEM 48



6	4	801359	CLAMP, RAIL, SINGLE, 1.5 LG, SS, ROUND HOLE
5	1	323269	BRKT, FRAME, PRD DTCTR, ACCUM, ADJ
4	1	291031	BRACKET, PROD DETECTOR, ACCUM
3	2	800424	BUSH, OILITE, FLG, 0.252 X 0.3775 X 1/4, 15/32 OD X 1/16 THK FLG
2	1	107147	WEIGHT, COUNTER
1	1	107149	SHAFT, WEIGHT, COUNTER
ITM	QTY	PART NUM	DESCRIPTION
BILL OF MATERIALS			
ARPAC 9511 WEST RIVER ST. SCHILLER PARK, IL 60176			
UNLESS OTHERWISE SPECIFIED		FRACTIONS	± 1/64
ALL DIMENSIONAL TOLERANCES:		TWO (2) DECIMALS	± 0.010
		THREE (3) DECIMALS	± 0.005
		ANGLES	± 0.5°
DRAWN:	11/8/2012	BY:	SR
RELEASED:	11/8/2012	FILENAME:	323268
DESCRIPTION:		SCALE:	1:2
ASSY, PRODUCT DETECTOR, ACCUMULATION, ADJ		APPROVED BY:	SRA
		DRAWING NUMBER:	
		323268	

REVISIONS			
RV	DATE	BY	DESCRIPTION
A	3/9/2018	SRA	ADDED NOTES AND CHAINS TO VIEWS
B	10/14/2021	SRA	NUT 800290-090 WAS 800290-061






DETAIL A
SCALE 1 : 3

ASSEMBLE 4 CHAINS. TWO CHAINS INCLUDE 6 PITCH LENGTHS FOR A TOTAL CHAIN LENGTH OF 216". THE OTHER TWO CHAINS INCLUDE 5 PITCH LENGTHS FOR A TOTAL LENGTH OF 180".

NOTE: APPLY BLUE LOCTITE THREAD LOCKING ADHESIVE TO THREADS OF SHOULDER BOLTS BEFORE ATTACHING NUTS.

B	10	22	800290-090	FSNR, NUT, HEX, 1/4-20, JAM, FINISH
	9	22	800322-002	FSNR, BOLT, SHLDR, 5/16 DIA X 1/2 LG, SS
	8	22	800516	LINK, CONN, #60
	7	22	246329	LUG, FORMING, TRAY
	6	22	246330	ARM, CONTROL, LUG
	5	88	836856	SPACER, NYLON, 1/8" LG, FOR 1/4" SCR
	4	44	800519	LINK, CONN, #60, OFFSET
	3	44	836863	CHAIN, RLR, LINK CONN, #60 DOUBLE, CLIP
	2	66	802579-002	FLIGHT, PLASTIC, 1.75 W, UNI 863
	1	66	802579-001	BASE CHAIN 863
BILL OF MATERIALS				
DRAWN: 12/23/2016		BY: HG		SCALE: 1:6
RELEASED:		FILENAME: 328585		APPROVED BY:
DESCRIPTION:		ASSY, CHAIN, LUG		
DRAWING NUMBER:				328585



LINK, CONN #40 NOT SHOWN

19	1	104832-002	ROTARY ARM
18	1	104832-001	ROTARY ARM
17	1	328587-001	MNT, ROTARY FOLDER
16	1	328587	MNT, ROTARY FOLDER
15	2	800502	LINK, CONN, #40
14	9	800462	CHAIN, RLR, #40, RLR RVT
13	2	190795	PLT, WEAR, ROTARY SLEEVE
12	2	190794	PLT, WEAR, ROTARY SLEEVE
11	1	104858	50B26 SPROCKET, MOD, 1 BORE TS60
10	2	827116	BRG, FLG, 1 ID, 2-BOLT, 3.89 BOLT CNTRS
9	1	133802	ROTARY FOLDER DRIVE SHAFT
8	2	275921	ROTARY SPLINE SLEEVE
7	2	104857	40A26, SPROCKET, MOD, 1 3/4 BORE
6	2	114201-003	SPACER, IDL SPKT
5	2	800906	SPKT, 40BB17H, IDLER, 0.625 ID
4	2	124817	SPKT, 40B26, 1.00 BORE
3	4	837218	BRG, FLG, 1 ID, 3-BOLT, STD DUTY
2	2	319501	SHAFT, FOLDER, FLAP, ROTARY
1	2	104831	ROTARY ARM MOUNTING
ITM	328588/301 112/Q TY.	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC 9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:



FRACTIONS	± 1/64
TWO (2) DECIMALS	± 0.010
THREE (3) DECIMALS	± 0.005
ANGLES	± 0.5°

DRAWN: 12/27/2013	BY: SRA	SCALE: 1:8	SIZE: B
RELEASED: 12/27/2013	FILENAME: 328588	APPROVED BY: SRA	

DESCRIPTION: ASSY, FLAP FOLDER, ROTARY

AS

DRAWING NUMBER:	328588
-----------------	--------



5	1	190809-004	SPACER
4	1	190809-010	SPACER
3	1	190809-011	SPACER
2	2	112726	SPROCKET - MODIFIED
1	1	220971	SHAFT, IDLER, COMPRESSION SECTION
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:
FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°


DRAWN: 05/24/2001 BY: TTR SCALE: 0.5:1 SIZE: A


RELEASED: 05/24/2001 FILENAME: 328589 APPROVED BY: TTR

DESCRIPTION: ASSY, IDLER, COMPRESSION SECTION

JS

DRAWING NUMBER:
328589





12	2	802832	BRG, FLG, 1-1/2 ID, 4-BOLT ALTERNATE FOR SEALMASTER
11	1	802411	WRENCH, RATCHET 7/8 SQ X 16-1/2 LG
10	1	197826	SPKT, 60A32, COMP, DRIVE
9	1	197824	SPKT, 60A32, COMP, DRIVE
8	1	192759	SPKT, 60B20, MOD, 1.500 BORE
7	2	190802-002	SPKT, CARRIER SPACER
6	2	190802-001	SPKT, CARRIER SPACER
5	1	187303	SPACER, 4 BOLT, BEARING
4	1	135005	SLEEVE, 7/8 SQ.
3	1	134996	SHAFT, 7/8 SQ.
2	1	133803	SHAFT, SPLINE, W/HANDLE
1	2	108850-000C	CONVEYOR DR. SPRKT CARRIER
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS


ARPAC 9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:

FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°

DRAWN: 10/02/2001	BY: TTR	SCALE: 0.25:1	SIZE: B
RELEASED:	FILENAME: 328591	APPROVED BY: TTR	
DESCRIPTION: ASSY, DRIVE, SPLINE SHAFT, TRAIL			
			
DRAWING NUMBER:			328591

ITEM 11 NOT SHOWN



17	4	806459	HDL, ADJ, ZINC, 2-1/2 LG 5/16-18 X 1.18 STUD
16	4	802676-001	HDL, ADJ, ZINC, 1.77 LG 1/4-20 X .78 STUD
15	2	276478	PLT, INDICATOR
14	1	241699-001	POINTER, SCALE, 9/32 RH
13	1	241699	POINTER, SCALE, 9/32
12	4	328586	PLT, MTG, SIDE
11	1	237923-002	MNT, GLUE GUN & MINOR PLOW
10	1	237923-001	MNT, GLUE GUN & MINOR PLOW
9	2	221935	KEY, SIDE ANGLE
8	1	332572-001	WLDMT, COMPRESSION, SIDE
7	1	332572	WLDMT, COMPRESSION, SIDE
6	1	221628-002	HOLD DOWN, PRODUCT
5	1	221628-001	HOLD DOWN, PRODUCT
4	4	190789	ROD, PLOW, 5.06 LG
3	1	292127-002	PLOW, MINOR, LH
2	1	292127-001	PLOW, MINOR, RH
1	6	144124-142	SHAFT, 1.000, TAPPED
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC 9511 WEST RIVER ST.
SCHILLER PARK, IL 60176





UNLESS OTHERWISE SPECIFIED:
FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°

DRAWN: 09/02/2015 BY: SRA SCALE: 0.125:1 SIZE: C

RELEASED: FILENAME: 328592 APPROVED BY: SRA

DESCRIPTION: ASSY, FORMING, TRAY

DRAWING NUMBER: 328592



A	36	1	800324-007	SHOULDER BOLT
A	35	1	221957-001	SCALE, 17" LG, LH
A	34	1	282745	NUT, T, 5/16-18
A	33	1	802677	HDL, ADJ, ZINC, 2.56 LG 5/16-18 X 1.57 STUD FOLLOWER, CAM, 3/4 OD, 3/8-24 STUD, W/HEX HOLE, W/ECCENTRIC STUD
	32	4	851375	PLT, GUARD, MAGAZINE, LH SIDE
	31	1	298216	PLT, GUARD, MAGAZINE, RH SIDE
	30	1	298215	WALL, SIDE, L.H.
	29	1	282741	WALL, SIDE, RH
	28	1	282740	HDL, ADJ, ZINC, 2-1/2 LG 5/16-18 X .78 STUD
	27	2	809385	SUPPORT, BLANK, MAG.
	26	1	282743-002	SUPPORT, BLANK, MAG.
	25	1	282743-001	COVER, BREARING, CLOSE END, 1"
	24	2	845246	RAIL, GUIDE, 15MM, 280L
	23	2	851378	BLK, BRG, LINEAR, 15MM
	22	2	851377	BRG, FLG, 1 ID, 3-BOLT, STD DUTY
A	21	2	837218	HDL, ADJ, SS, 1.57 LG 1/4-20 X 1.18 STUD
	20	2	810224	HDL, ADJ, ZINC, 2-1/2 LG 5/16-18 X 1.26 STUD
	19	6	823126	SUPPORT, REAR, MAGAZINE
	18	1	298272	WLDMT, SPACER
	17	2	282742	BAR
	16	1	282731	FRONT SUPPORT HOLDER
	15	1	282730	PLT, MTG, CAM FOLLOWER
	14	2	328783	PLATE, BACK
	13	1	282728	BAR, MTG, HOPPER
	12	2	282727	LH MACH
A	11	1	282726	SCALE, 17" LG, RH
	10	1	221957	PIN, SUPPORT, ROD
	9	4	186703	WLDMT, SUPPORT, BLANK
	8	1	291898	BLOCK
	7	4	141335	RACK RETAINER
	6	2	141330	GEAR, SPECIAL
	5	1	141329	RACK WELDMENT
	4	2	141328	SIDE, BASE, BLANK
	3	1	122551	REAR, BLANK, SUPPORT
	2	1	122539	MTG, PLATE, SUPPORT, BLANK
	1	1	122524	
ITM	QTY	PART NUM	DESCRIPTION	

BILL OF MATERIALS

ARPAC 9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED:
ALL DIMENSIONAL TOLERANCES:

FRACTIONS: ± 1/64
TWO (2) DECIMALS: ± 0.010
THREE (3) DECIMALS: ± 0.005
ANGLES: ± 0.5°

DRAWN: 11/3/2012 BY: SR SCALE: 1:8 SIZE: C

RELEASED: 11/3/2012 FILENAME: 328784 APPROVED BY: SRA

DESCRIPTION: ASSY, HOPPER, RH MACH

DRAWING NUMBER: 328784

A	3/31/2021	GMA	ADDED QTY 1 OF 800324-007, 282745, 802677, 221957-001. REMOVED QTY 1 OF 221957 & 810224
REV	DATE	BY	NOTE
			REVISIONS





D

C

B

A

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	345485	ASSY, RAIL
2	1	328592	ASSY, FORMING, TRAY
3	1	328588	ASSY, FLAP FOLDER, ROTARY
4	1	328590	ASSY, DRIVE, SPLINE SHAFT, LEAD
5	1	328591-001	ASSY, DRIVE, SPLINE SHAFT, TRAIL
6	1	220975	ASSY, SCREW, ADJ. RH
7	2	328589	ASSY, IDLER, COMPRESSION SECTION
8	1	345486	ASSY, CHAIN SUPPORT
9	1	291515	ASSY, GUIDE, SIDE, PRODUCT
10	1	328585	ASSY, CHAIN, LUG



REV				DATE	BY	NOTE
REVISIONS						
SIZE	SCALE	MATERIAL	DESCRIPTION			
C	1:12	SEE BILL OF MATERIALS	ASSY, SECTION, COMPRESSION, TS-2000			
3RD ANGLE	UNITS	TOLERANCES	FINISH			
INCH		XX: ±1/32 X.XX: ±0.15 X.XXX: ±0.05 ANGLES: ±1°	Finish <not specified>			
DATE CREATED	DATE UPDATED	DATE CREATED	DATE UPDATED	DATE CREATED	DATE UPDATED	NUMBER
3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	332391

C

B

A





D

C

B

A

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	2	283366	PLT, MTG, ROLLER
2	1	292552-001	SHAFT, 1.000, TAPPED, 3/8-16, SS
3	2	826950	ASSY, RLR, NO-CRUSH, 6 OD, 2 WD, W/ HUB
4	4	800600	COLLAR, SHAFT, CLAMP, 1-PIECE
5	2	848565	HDL, ADJ, SS, 3.07 LG 3/8-16 X .78 STUD



REV	DATE	BY	NOTE
REVISIONS			
SIZE B			SCALE 1:5
3RD ANGLE UNITS INCH			MATERIAL SEE BILL OF MATERIALS
TOLERANCES X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°			FINISH NONE
DESCRIPTION ASSY, ROLLER, HOLD-DOWN			NUMBER 332418



NOTES		CREATED IN SOLIDWORKS 2013		ARPAC A DURAVANT COMPANY		9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com	
• INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2013.		MODEL FILE \CONFIG SIMILAR TO DATE CREATED DATE UPDATED UPDATED BY		332418\Default Thursday, July 28, 2016 12:06:57 PM Monday, April 26, 2021 1:29:13 PM Gibran.Mota		DRAFT DATE CREATED DATE UPDATED UPDATED BY	
				Wednesday, March 29, 2017 8:43:57 AM Monday, April 26, 2021 1:29:14 PM Gibran.Mota			

D

C

B

A



11	2	294789	PLT, NUT
10	4	821863	HDL, ADJ, SS, 1.57 LG 1/4-20 X 1.57 STUD
9	2	294787	BAR, TRANSFER, ADJ, OUTER
8	3	298289-001	SCALE, 10 LG, 1/2 W, LH
7	1	298289	SCALE, 10 LG, 1/2 W, RH
6	4	810224	HDL, ADJ, SS, 1.57 LG 1/4-20 X 1.18 STUD
5	2	282823	BAR, TRANSFER, ADJ
4	4	282822	BAR, TRANSFER, STATIONARY
3	2	282820	PLATE, BRIDGE, SIDE
2	2	332606	PLT, CROSS, BRIDGE
1	2	800416	BUSH, OILITE, FLG, 1.001 X 1.253 X 3/4, 1-7/8 X 1/8 THK FLG
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS


ARPAC

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:


FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°

DRAWN: 4/10/2017	BY: SRA	SCALE: 1:4	SIZE: B
RELEASED:	FILENAME: 332605	APPROVED BY:	
DESCRIPTION: ASSY, BRIDGE, MAG, EXT			
			DRAWING NUMBER: 332605



345164

345164-001



345164-001	345162-001	345161-001
345164	345162	345161
PART NUMBER	ITEM 3	ITEM 9

12	1	828104	SLIDE, SPACER, SS, B = 896MM OAL, C&D = 43MM
11	1	828103	SYSTEM, SLIDE, BASED, SS
10	1	345163	BAR, STIFFNER, GUIDE, DIVIDER
9	1	SEE TABLE	BLK, MTG, PIVOT, GUIDE, SLIDE
8	2	284071	PIN, MNT, PIVOT, GUIDE, SLIDE
7	2	284069	GUIDE, LANE, SHORT, GUIDE, SLIDE
6	2	345160	BLK, MTG, GUIDE, LONG
5	2	284065	GUIDE, LANE, LONG, GUIDE, SLIDE
4	1	284064	SUPPORT GUIDE
3	1	SEE TABLE	FRAME, SUPPORT, SLIDE, GUIDE, LANE
2	1	284060	GUIDE PROFILE
1	1	284059	BLK, MTG, PIVOT, GUIDE, SLIDE
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:

FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°

DRAWN: 3/5/2018	BY: hhg	SCALE: 1:8	SIZE: B
RELEASED: 3/5/2018	FILENAME: 345164	APPROVED BY: hhg	
DESCRIPTION: ASSY, GUIDE, SLIDE, GUIDE, LANE			
			DRAWING NUMBER: 345164

D


C

B

A

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	345484	WLDMT, RAIL, COMPRESION SECTION
2	1	345484-001	WLDMT, RAIL, LH, COMPRESION SECTION
3	2	333980	RAIL, TRANSFER, TRAY
4	2	369931	PLT, GUIDE, BLANK
5	2	297844	BLK, MTG, TRANSFER, ENTRANCE

A



A	1/6/2020	SRA	PART 3# 369931 WAS 297843
REV	DATE	BY	NOTE
REVISIONS			

NOTES • INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2013.		CREATED IN SOLIDWORKS 2013		ARPAC A DURAVANT COMPANY 9555 W. Irving Park Rd. Scholar Park, L 80176 www.arpac.com		SIZE B	SCALE 1:12	MATERIAL SEE BILL OF MATERIALS		DESCRIPTION ASSY, RAIL	
		MODEL	345485\345485		3RD ANGLE		UNITS INCH				
			-- Friday, March 11, 2011 12:40:24 AM		TOLERANCES X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°						
			DATE CREATED Monday, January 6, 2020 11:41:18 AM								
		DRAFT	DATE CREATED Monday, March 27, 2017 3:19:24 PM		DATE UPDATED Monday, January 6, 2020 11:40:50 AM		FINISH NONE		NUMBER 345485		


D

C





B

A


BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	2	190812-000A	CHAIN GUIDE #60 (SHORT)
2	2	190813-000A	CHAIN GUIDE #60 (LONG)
3	26	801359	CLAMP, RAIL, SINGLE, 1.5 LG, SS, ROUND HOLE
4	4	226432-006	SPACER
5	4	226432-005	SPACER
6	4	237912	TENSIONER



ARPAC		9511 WEST RIVER ST. SCHILLER PARK, IL 60176	
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONAL TOLERANCES:		FRACTIONS TWO (2) DECIMALS THREE (3) DECIMALS ANGLES	± 1/64 ± 0.010 ± 0.005 ± 0.5°
DRAWN: 5/24/2001	BY: TTR	SCALE: 0.125:1	SIZE: B
RELEASED: 5/24/2001	FILENAME: 345486	APPROVED BY: TTR	
DESCRIPTION: ASSY, CHAIN SUPPORT			
			DRAWING NUMBER: 345486



77	1	291804	PANEL, GUARD, MAGAZINE
76	1	807279-001	TENSIONER, SPRING, ROTARY 20-45LBS
75	2	803668-001	LOCKING DEVICE, KEYLESS 1"
74	1	274122-001	MNT. MOTOR
73	1	290829	WLDMT. FRAME, MAGAZINE, RH MACHINE
72	1	195409A-001	CROSS MEMBER RH MACHINE
71	1	193131-003	LH OPPOSITE
70	1	193131-002	RH AS SHOWN
69	1	189852-000	RLR, PINCH, UPR
68	2	144606-019	SPACER, RND, 1", AL, 0.5LG, 2102THRU
67	6	837218	BRG. FLG, 1 ID, 3-BOLT, STD DUTY MOTOR, 3/4 HP, 230/480V, 60HZ, 3PH, 56 FRM, FOOT MNT, 1200RPM, F1
66	1	827724	CONDUIT BOX
65	1	823057	CLUTCH, ROLLER, DC 5/8 ID X 7/8 OD X 5/8 LG, (NOM.)
64	1	823055	RING, INNER, 3/75 ID X .625 OD X .785 LG
63	1	822522	ROD END, 5/8-18, MALE, LH THREAD
62	1	822521	ROD END, 5/8-18, MALE, RH THREAD
61	16	821600	CHAIN, DELRIN, #40 WITH SST PIN
60	1	821596	SPKLT, D40P28, REQUIRE P1 BUSHING
59	2	816471	SPRING, COMP, 0.825 OD X 1.25 LG, 100 WIRE DIA (BLUE)
58	1	816285	CLUTCH, OVERLOAD, BORE 1", PROX PLT SET TO 75 IN# WAAPAC
57	1	816284	BUSH, TAPER, QT, .625 BORE
56	1	810478	BELT, TIMING, 8MM P, 20MM W, 800MM LG, 100 TEETH
55	1	809737	FOLLOWER, CAM, 1 OD, 5/8-18 STUD, W/EX. HOLE, SEALED
54	1	809446	SPKLT, 50JA13 H, OD BUSH, HARDENED
53	2	808128	BUSH, OILITE, FLG, 0.752 X 0.879 X 3/4 L-1/8 OD X 1/8 THK FLG
52	1	807464	PULLEY, TIMING, 30 T, 8MM P, 20MM W, OT BUSHING REQUIRED
51	2	807096	COLLAR, SHAFT, CLAMP, 1-PIECE, 3/4, EXTREME CL8867
50	1	807017	PULLEY, TIMING, 22T, 8MM P, 20MM W, 1 BORE
49	1	806450	BUSH, TAPER, OD, 1 BORE X 1-15/16 LG
48	1	802881	FOLLOWER, CAM, 1 OD, 7/16-20 STUD, CROWNED, ECCENTRIC 5/8 OD
47	2	827116	BRG, F.L.G., 1 ID, 2-BOLT, 3/89 BOLT CNTRS
46	1	800905	SPKLT, 30BB15H, IDLER, 5/8 ID, HARDENED TEETH
45	1	800665	BUSH, TAPER, OD, 1 BORE X 1-1/16 LG
44	1	800609	CPLG, PHASE-LOCK, HDI-25-1 1 BORE
43	2	800600	COLLAR, SHAFT, CLAMP, 1-PIECE
42	1	800468	CHAIN, RLR, #50
41	2	800438	W/SHR, OILITE, 0.753 X 1.375 X 1/8 THK
40	2	290834	ASSY, BAR, CHAIN, MAGAZINE FEED
39	1	290831	SHAFT, LWR, RLR, PINCH
38	4	283409	NUT, HANDLE
37	1	282792	DEFLECTOR, URR
36	1	282754	SPKLT, D40B32, 32 TEETH, 1" P TYPE B
35	1	231440	BKT, CLAMP, PIVOT
34	1	230295	HANDWHEEL, 5" ROLLER CLUTCH
33	1	230293	SHAFT, TAIL CONV
32	1	228962	BKT, MTG, PROX
31	1	223740	ROD, CONNECTING, 1"
30	1	223739	MNT, SHAFT, JACK
29	1	223738	SHAFT, DRIVE
28	1	223735	SHAFT
27	1	300037	GUIDE, FEED, BLANK, TOP
26	1	290833	SHAFT, ROLLER, TOP, MTG
25	1	223729	SHAFT, RLR, UPR
24	1	221942	KEY, CUP MNT
23	2	220985	SHAFT, VAC, ARM
22	1	214933	WLDMT, MNT, VACUUM PUMP
21	2	213235	SPKLT WITH BEARING
20	2	213234	SPKLT, D40B32, 32 TEETH, 1/2" P TYPE B
19	1	213233	SPKLT, D40B32, 32 TEETH, 1/2" P TYPE B
18	1	197877	PIVOT ARM
17	1	193126	RAMP, MAGAZINE, BELT, RH
16	1	193125	RAMP, MAGAZINE, BELT, LH
15	1	193116	PLATE
14	1	193114	BLANK SUPPORT MAGAZINE SIDE
13	1	193110	RLR, PINCH, LWR
12	1	190818	GUIDE, LOWER, MAG
11	1	223082	MOUNT, ROLLER, RH
10	1	189367	MOUNT, ROLLER, LH
9	1	189366	HOLDER, SPRING, RH
8	1	189365	HOLDER, SPRING, LH
7	2	186513	VACUUM CLIP MNT
6	2	186490	KEY
5	1	186488	SHAFT, CONV, LWR
4	1	142585	VACUUM CLIP MNT
3	1	140334	SPKLT WITH TLSP5U
2	1	140332	TAKE - UP SCREW
1	2		
ITEM QTY PART NUM			DESCRIPTION
			BILL OF MATERIALS
			9511 WEST RIVER ST. SCHILLER PARK, IL 60176
			UNLESS OTHERWISE SPECIFIED: FRACTIONS: ± .004 TWO (2) DECIMALS: ± .005 THREE (3) DECIMALS: ± .005 ANGLES: ± .5°
DRAWN	4/17/2018	BY: SRA	SCALE: 1:6 SIZE: D
RELEASED:	FILENAME: 358161	APPROVED BY:	
DESCRIPTION:			ASSY, ROLLERS, PINCH, RH MAGAZINE
DRAWING NUMBER:			358161



7	1	358161	ASSY. ROLLERS, PINCH, RH MAGAZINE
6	1	290825	ASSY. MAGAZINE, GUIDE, SUPPORT, RH
5	1	328784	ASSY. HOPPER, RH MACH
4	1	290792	ASSY. SCREW, ADJ, RH
3	1	290827	ASSY. MAGAZINE, GUIDE, RH
2	1	290828	ASSY. SCREW, ADJ, MAGAZINE
1	1	244278-002	ASSY. BLANK, SUPPORT & GUIDE, RH
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC 9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED:
ALL DIMENSIONAL TOLERANCES:

FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°


DRAWN: 3/31/2021 BY: SRA SCALE: 1:8 SIZE: C

RELEASED: FILENAME: 358162 APPROVED BY:

DESCRIPTION:
ASSY. MAGAZINE, BLANK FEED, TS-2000, RH


358162

DRAWING NUMBER:
358162








21	1	803668-007	LOCKING DEVICE, KEYLESS 1-3/4"
20	1	221042	ADAPTOR, PULLEY LOWER, OUTER SPINDEL
19	1	802770	BRG, FLG, 3/4 ID, 3-BOLT, SINGLE-LOCK, STANDARD DUTY
18	1	807854	BRG, FLG, 3/4 ID, 2-BOLT, SKWEZLOC, STANDARD-DUTY
17	1	193202	HOUSING
16	2	817243	BRG, CART, 1.771 X 2.95 X .6299 LG TWO SEALS
15	1	803668-009	LOCKING DEVICE, KEYLESS 2-1/2"
14	2	846484	BRG, NEEDLE, 3/4 X 1-1/4 X 1 LG, DOUBLE SEAL, HEAVY DUTY
13	2	803668	LOCKING DEVICE, KEYLESS 3/4
12	2	802947	BRG, THRUST, 3/4 X 1-1/4 X 5/64 RLR DIA.
11	4	802948	WSHR, THRUST, 3/4 X 1-1/4 X 1/8 THK
10	2	108509	BEARING, HOUSING
9	2	108508	DISK, VERT. SHAFT RETAINER
8	1	193201	SPACER
7	1	193200	DISK, VERT. SHAFT RETAINER
6	1	364841	SPINDLE, OUTER
5	1	195556	PULLEY, 30T, 1/2P, 1-1/2W, SPECIAL
4	1	108570	SPINDLE INNER DRIVER SPROCKET
3	1	221040	PULLEY, OUTER SPINDLE, LOWER
2	1	221038	PULLEY, INNER SPINDLE, UPPER
1	1	193195	CONCENTRIC DRIVE SPINDLE INNER SHAFT

ITM	QTY	PART NUM	DESCRIPTION
BILL OF MATERIALS			
ARPAC		9511 WEST RIVER ST. SCHILLER PARK, IL 60176	
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONAL TOLERANCES:		FRACTIONS ± 1/64 TWO (2) DECIMALS ± 0.010 THREE (3) DECIMALS ± 0.005 ANGLES ± 0.5°	
DRAWN: 1/14/2020	BY: HG	SCALE: 1:4	SIZE: B
RELEASED:	FILENAME: 364832	APPROVED BY:	
DESCRIPTION:		ASSY, PULLEY, DRIVE, VERTICAL	
		DRAWING NUMBER: 364832	



369992

369992-001



SECTION A-A

369992 AS SHOWN
369992-001 OPPOSITE

6	2	195469	MOUNTING PIN - LONG
5	2	803621-008	PIN, DOWEL, 1/4 X 3/4, SS,
4	2	286739	LUG, MNT KEY
3	1	193215	CLAMP
2	1	286738	MNT, LUG
1	1	286737	BRACKET
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC

9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:

FRACTIONS
TWO (2) DECIMALS
THREE (3) DECIMALS
ANGLES

± 1/64
± 0.010
± 0.005
± 0.5°

DRAWN: 1/15/2020

BY: SRA

SCALE: 2:3

SIZE: B

FILENAME: 369992

DESCRIPTION:

ASSY, CARRIER, LUG, COLLATOR

25

DRAWING NUMBER:
369992

D

C

B

A

ARPAC B SIZE FORMAT R5.1

2





1

2

1

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	371504	BLK, SPACER, SUPPORT, FRAME, DOOR
2	1	371503	PLT, SUPPORT, FRAME, DOOR
3	1	371511	PLT, CLAMP
4	1	371507	WLDMT, ADJ, FRAME, DOOR
5	4	845826	T-NUT, E, M6, SLIDING DOORS

NOTE: ITEM 5 NOT SHOWN



REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
B	1:2	SEE BILL OF MATERIALS	ASSY, SUPPORT, ADJ, FRAME, DOOR
3RD ANGLE	UNITS	FINISH	NUMBER
	INCH	NONE	371514
TOLERANCES			
X.X: ±1/32			
X.XX: ±.015			
X.XXX: ±.005			
ANGLES: ±1°			

NOTES		CREATED IN SOLIDWORKS 2018		ARPAC	
• INTERPRET PER ASME Y14.5M-1994.		FILE \CONFIG		9555 W. Irving Park Rd.	
• DIMENSIONS ARE IN INCHES [mm].		SIMILAR TO		Schiller Park, IL 60176	
• DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.		DATE CREATED		www.arpac.com	
• BREAK SHARP EDGES AND CORNERS.		DATE UPDATED			
• PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.		UPDATED BY			
• CREATED IN SOLIDWORKS 2018.		DRAFT			
		DATE CREATED			
		DATE UPDATED			
		UPDATED BY			

ARPAC B SIZE FORMAT R5.1

2

1

D





C

B

A

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	371512	PLT, SUPPORT, FRAME, DOOR
2	1	371513	BLK, SPACER, SUPPORT, FRAME, DOOR
3	1	371507	WLDMT, ADJ, FRAME, DOOR
4	4	845826	T-NUT, E, M6, SLIDING DOORS

NOTE: ITEM 4 NOT SHOWN



REV	DATE	BY	NOTE
REVISIONS			
SIZE B		SCALE 2:3	MATERIAL SEE BILL OF MATERIALS
3RD ANGLE UNITS INCH		TOLERANCES X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°	FINISH NONE
DESCRIPTION ASSY, SUPPORT, ADJ, FRAME, DOOR			NUMBER 371515



NOTES			CREATED IN SOLIDWORKS 2018		 A DURAVANT COMPANY		9555 W. Irving Park Rd Schiller Park, IL 60176 www.arpac.com	
• INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2018.			DRAFT	MODEL	FILE \CONFIG SIMILAR TO DATE CREATED DATE UPDATED UPDATED BY	371515/Default Monday, April 13, 2020 4:13:59 PM Monday, April 13, 2020 5:50:02 PM sarcher		
			DRAFT		DATE CREATED DATE UPDATED DATE UPDATED BY	Monday, April 13, 2020 4:21:06 PM Monday, April 13, 2020 4:44:01 PM sarcher		

D


C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	4	284073	SUPPORT COLUMN GUIDES
2	2	372299	BAR, SUPPORT, GUIDE, LANE
3	2	284077	HANDRAIL SUPPORT
4	4	284080	SUPPORT SLEEVE
5	2	284081	PLT, SIDE, GUIDE, LANE
6	2	284082	BLK, SUPPORT, GUIDE, LANE
7	4	289850	GUIDE, CHAIN, 14X20MM MODIFIED
8	1	293304	NUT, GUIDE, SCREW, ADJ, GUIDE, LANE
9	1	293305	NUT, GUIDE, SCREW, ADJ, GUIDE, LANE
10	1	372274	SCREW, ADJ, GUIDE, LANE, 17" OPEN
11	8	827974	BRG, LINEAR, BALL, ID25MM, OD35MM, L40MM
12	1	827975	INDICATOR, DIGITAL, DIRECT DRIVE, INCLINED UPPER, P4MM, CW
13	2	845289	BUSH, OILITE, 20MM OD X 15MM ID X 15MML
14	2	846868	BRG, BALL, DEEP GROOVE, AXIAL, ID15MM, OD28MM, W9MM
15	4	845590	BUSH, FLG, 8MM ID X 10MM OD X 9.5MM LG X 15MM FLG OD



NOTES

- INTERPRET PER ASME Y14.5M-1994.
- DIMENSIONS ARE IN INCHES [mm].
- DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
- BREAK SHARP EDGES AND CORNERS.
- PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
- CREATED IN SOLIDWORKS 2018.

CREATED IN
SOLIDWORKS 2018

FILE \CONFIG
SIMILAR TO
DATE CREATED
DATE UPDATED
DATE UPDATED BY

MODEL

DRAFT

ARPAC
A DURAVANT COMPANY

9555 W. Irving Park Rd.
Schiller Park, IL 60176
www.arpac.com

372271\372271

Friday, June 29, 2012 3:56:01 PM
Wednesday, March 24, 2021 6:10:44 PM
sarcher

Tuesday, September 11, 2012 9:21:31 AM
Wednesday, March 24, 2021 6:12:10 PM
sarcher

SIZE
B

3RD ANGLE

TOLERANCES
X.X: ±1/32
X.XX: ±.015
X.XXX: ±.005
ANGLES: ±1°

SCALE
1:8

UNITS
INCH

MATERIAL
SEE BILL OF MATERIALS

FINISH
PART OF ASSEMBLY

DESCRIPTION
ASSY, GUIDE, LANE,
ENTRY, DIVIDER,
DYNAMIC, MAX 10" W





NUMBER
372271

D

C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	284203	SENSOR ADJUSTMENT SUPPORT
2	1	284206-001	BAR, VERTICAL ADJ, 13" LG
3	4	284207	FLANGE PLACKAT
4	1	372280	BAR, BRIDGE, ADJ
5	2	284209	SUPPORT BRACE
6	2	284210	BLK. CLAMP BODY
7	2	845686	HANDLE, ADJ, M6X1, THRD 45MM, HNDL RAD 30MM
8	1	306874	PLT, ADAPTOR, MTG, SENSOR

NOTES • INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2018.		CREATED IN SOLIDWORKS 2018		ARPAC A DUBAYANT COMPANY 9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com		SIZE B	SCALE 1:8	MATERIAL SEE BILL OF MATERIALS	DESCRIPTION ASSY, PRODUCT COUNT, DYN DIV
MODEL FILE \CONFIG SIMILAR TO DATE CREATED DATE UPDATED UPDATED BY		372277\372277 Monday, July 2, 2012 1:01:55 PM Friday, July 24, 2020 10:50:11 AM jw		3RD ANGLE 		UNITS INCH	FINISH PART OF ASSEMBLY		NUMBER 372277
DRAFT DATE CREATED DATE UPDATED UPDATED BY		Wednesday, August 29, 2012 4:40:16 PM Friday, July 24, 2020 10:50:46 AM jw		TOLERANCES X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°					

D

C

B




A

D


C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	2	284097	ASSY, WLDMT, SUPPORT, CARRIER
2	4	300373	DEFLECTION ROLLER
3	4	309572-009	SHAFT, IDLER
4	4	315002	PLT, CONNECTING, CONV, DIVIDER, DYNAMIC, CSINK
5	7	345146	CROSSBAR, INTERMEDIATE
6	1	372288	PLT, SIDE, CONV, DIVIDER, DYNAMIC
7	1	372288-001	PLT, SIDE, CONV, DIVIDER, DYNAMIC
8	6	801296-002	RAIL, GUIDE, TEE, 1.60 W, 10' LG, SS
9	42	801359	CLAMP, RAIL, SINGLE, 1.5 LG, SS, ROUND HOLE
10	2	850128	EXTRUSION, UHMW, J-LEGS, 10' LG, FOR 11GA SHEET



REV	DATE	BY	NOTE
REVISIONS			
SIZE B		SCALE 1:20	MATERIAL SEE BILL OF MATERIALS
3RD ANGLE UNITS INCH		TOLERANCES X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°	
FINISH PART OF ASSEMBLY			DESCRIPTION ASSY, CONV, LONG, DIVIDER, DYNAMIC NUMBER 372287

NOTES
 • INTERPRET PER ASME Y14.5M-1994.
 • DIMENSIONS ARE IN INCHES [mm].
 • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
 • BREAK SHARP EDGES AND CORNERS.
 • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
 • CREATED IN SOLIDWORKS 2013.

CREATED IN SOLIDWORKS 2013		 9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com
MODEL	FILE \CONFIG SIMILAR TO DATE CREATED DATE UPDATED UPDATED BY	
DRAFT	DATE CREATED DATE UPDATED UPDATED BY	372287/372287 Monday, July 9, 2012 12:39:42 PM Thursday, October 15, 2020 3:47:20 PM sarcher Wednesday, February 28, 2018 4:49:15 PM Thursday, October 15, 2020 3:48:48 PM sarcher

ARPAC B SIZE FORMAT R5.1

2

1

D




"C:\ARPAC_VAULT\Designs\CORRUGATED\ITS-2300\17766\372306.slddrw" accessed Monday, August 10, 2020.

D

C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	372308	SHAFT, IDLER, CONV, INFEED
2	2	828156	FTG, GREASE, STRAIGHT, SS, 1/4-28
3	1	372307	BEARING SUPPORT
4	1	372307-001	BEARING SUPPORT
5	2	810473	BRG, CART, 1/2 X 1-1/8 X 5/16 LG, SS,DOUBLE SEALED

NOTES

- INTERPRET PER ASME Y14.5M-1994.
- DIMENSIONS ARE IN INCHES [mm].
- DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
- BREAK SHARP EDGES AND CORNERS.
- PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
- CREATED IN SOLIDWORKS 2018.

CREATED IN SOLIDWORKS 2018	
MODEL	FILE \ CONFIG SIMILAR TO DATE CREATED DATE UPDATED UPDATED BY
DRAFT	DATE CREATED DATE UPDATED UPDATED BY






372306\372306	Thursday, July 16, 2020 2:56:49 PM
Friday, July 24, 2020 4:31:27 PM	jw
Monday, July 20, 2020 8:50:53 AM	Friday, July 24, 2020 4:31:27 PM
jw	

REV	DATE	BY	NOTE
REVISIONS			
SIZE B		SCALE 1:1	MATERIAL SEE BILL OF MATERIALS
3RD ANGLE		UNITS INCH	DESCRIPTION ASSY, ROLLER, NOSE
TOLERANCES X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°		FINISH PART OF ASSEMBLY	NUMBER 372306

2

1

SHEET 1 OF 1



#50 HOLLOW PIN CHAIN 47.5" LENGTH EACH SIDE
FLIGHT BAR PITCH = 23.75"
GEARBOX RATIO = 10
PULLEY RATIO = 2
CHAIN DRIVE SPROCKET IS 24 TEETH
31.66 SERVO MOTOR REVOLUTION = 1 FLIGHT BAR PITCH (23.75")
1 MOTOR REVOLUTION = .75 FLIGHT BAR TRAVEL

BILL OF MATERIALS		
ITEM	QTY	DESCRIPTION
1	2	SPKT, 50B24, MOD. 0.750 BORE
2	4	SPCR, AL, 21/32 ID X 1 1/4 OD, 0.116 LG
3	2	SPACER, BKT, MTG, SERVO
4	1	BKT, MTG, GEARBOX
5	2	BLK, TENSIONER
6	2	SPCR, AL, 21/32 ID X 1 1/4 OD
7	1	PULLEY, TIMING, 25T, MOD. 22MM BORE
8	1	BKT, MTG, SERVO, SCAPEMENT
9	1	SHAFT, DRIVE, ESCAPEMENT
10	2	SHAFT, .0750, TAPPED, 3/8-16
11	2	RAIL, GUIDE, CHAIN, .50, SS, 8.13" LG.
12	2	ANGLE, MTG, RAIL, CHAIN
13	2	PLT, SIDE, BAR, FLIGHT, ESCAPEMENT
14	3	ASSY, BAR, FLIGHT, RELEASE, QUICK
15	2	CHAIN, RLR, .50, HOLLOW PIN
16	1	BUSH, TAPER, OD. .3/4 BORE X 1-3/8 LG
17	6	SPKT, 50B815H, IDLER, 5/8 ID, HARDENED TEETH
18	4	CLAMP, RAIL, SINGLE, 1.5 LG, SS, ROUND HOLE
19	2	BRG, FLG, 3/4 ID, 2-BOLT, 1.53 MTG HOLES
20	1	TIMING, 50T, 8 MMP, 17 MM W, 25.2 LG, 80 TEETH, EAGLE PD, HELICAL OR SET TEETH
21	1	GEARBOX, PLANETARY, NP SERIES, 10:1, FOR MBL-8310P
22	1	PULLEY, TIMING, 50T, 8 MMP, 17 MM W, SDS BORE
23	1	MOTOR, SERVO, 37 IN-LB, 4750 RPM, 460VAC, W/BRAKE KINETIX 5000 CONTROLLER
24	4	CHAIN, .50, SS, 8.13" LG.

		REV	DATE	BY	NOTE	REVISIONS		
		SIZE	SCALE	MATERIAL		DESCRIPTION		
		C 1:6		SEE BILL OF MATERIALS		ASSY, BAR, FLIGHT, ESCAPEMENT, 28.86" WIDE, 23.75" PITCH QF		
		3RD ANGLE	UNITS	FINISH		PINS		
		INCH		PART OF ASSEMBLY		3723237-001		
		TOLERANCES		X.XX: +1/32 X.XX: +0.015 X.XXX: +0.005 ASSEMBLED				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Tuesday, April 10, 2021 10:15:52 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Wednesday, September 10, 2014 11:19:27 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Friday, April 16, 2021 6:50:22 AM				
		DATE CREATED		DATE UPDATED				
		3723237-001		Monday, July 27, 2020 9:44:36 AM				
		DATE CREATED						



D

C

B

A

372345




372345-001

BILL OF MATERIALS

ITEM	QTY	NUMBER	DESCRIPTION
1	2	300306	NUT, FLANGE
2	2	300314	WASHER, CLAMP
3	2	300317	SHAFT, GUIDE
4	1	300322	PLT, MTG, SHAFT
5	1	300323	PLT, MTG, SHAFT
6	1	300326	PLT, MTG, CYL
7	1	300711	NUT, FLOATING
8	1	300712	NUT SPECIAL
9	4	309590	GEAR, MITER, 12DP, 15T, 0.50B
10	2	309593	BLK, MTG, SHAFT
11	2	309594	SCREW, ADJ, VERT
12	1	309597	WLDMNT, BLK, ADJ. VERT
13	1	309597-001	WLDMNT, BLK, ADJ. VERT
14	2	311965	BLK, MTG, CLAMP
15	1	313273	WLDMNT, BAR, MTG, CYL
16	1	313274	BAR, CROSS, TOP
17	1	313275	COVER, TOP
18	1	313276	SHAFT, CROSS, ADJ.
19	2	313279	SHAFT, SLIDE
20	1	372346	PLT, CLAMP, PRODUCT
21	1	372347	SUBASSY, PLT, CLAMP, RUBBER, EXT
22	6	800366	BUSH, OILITE, 0.6260 X 0.7530 X 1/2 LG
23	2	806159	BUSH, OILITE, FLG, 0.502 X 0.753 X 5/8, 1 OD X 1/8 THK FLG
24	4	819834	BUSH, BALL, 1 X 1-9/16 X 2-1/4 LG WITH TWO INTEGRAL WIPWERS
25	2	825362-001	VALVE, CONTROL, FLOW, 1/8 NPT X 1/4 TUBE 90DEG, NUMERIC INDICATOR, MTR OUT
26	1	828032	SENSOR, AIR CYLINDER
27	4	846871	BRG, LINEAR, BALL, ID20MM, OD28MM, L30MM
28	1	847969	CYL, AIR, 32mm BORE, 25mm STROKE
29	4	848781	BRG, THRUST, BALL, 5/8 ID, 1-11/32 OD, 9/16 TALL
30	1	848782	COUNTER, DIGITAL, 1/2 HOLLOW BORE, CW, 25 COUNTS/TURN, UPSIDE DOWN
31	1	849178	WRENCH, RATCHET 3/8 SQ X 6-15/16 LG

NOTES • INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2018.		CREATED IN SOLIDWORKS 2018 FILE \CONFIG DATE CREATED DATE UPDATED UPDATED BY	ARPAC A DURAVANT COMPANY 9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com	SIZE B 3RD ANGLE 	SCALE 1:10 UNITS INCH	MATERIAL SEE BILL OF MATERIALS FINISH PART OF ASSEMBLY	DESCRIPTION ASSY, CLAMP, PRODUCT, COLLATOR, 28.858" W CONV NUMBER 372345
		MODEL DATE CREATED DATE UPDATED UPDATED BY	372345/372345 Thursday, June 12, 2014 11:15:32 AM Friday, April 9, 2021 1:21:52 PM jmeintz		TOLERANCES X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°		
		DRAFT DATE CREATED DATE UPDATED UPDATED BY	Tuesday, February 10, 2015 4:26:35 PM Monday, August 10, 2020 3:41:13 PM jw				



ARPAC		9511 WEST RIVER ST. SCHILLER PARK, IL. 60176	
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONAL TOLERANCES:		FRACTIONS TWO (2) DECIMALS THREE (3) DECIMALS ANGLES	± 1/64 ± 0.010 ± 0.005 ± 0.5°
DRAWN: 8/27/2020	BY: SRA	SCALE: NONE	SIZE: B
RELEASED:	FILENAME: 372650	APPROVED BY:	
DESCRIPTION: SCHEMATIC, PNEUMATIC, VACUUM			
24VDC, TS-2300			
			DRAWING NUMBER: 372650

ARPAC B SIZE FORMAT R5.1

2

1





D

C

B

A

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	372970	WLDMT, PLT, DEAD, TRANSFER, PRODUCT
2	1	372971	PLT, BASE, BAR, FLIGHT, PACING
3	1	372972	PLT, DEAD, BAR, FLIGHT, PACING
4	1	333728	BAR, SUPPORT, PLATE, DEAD
5	2	212436	BKT
6	2	212469	ANGLE
7	2	304538	ANGLE, UPPER DEFLECTOR, MTG



REV	DATE	BY	NOTE
REVISIONS			
SIZE		SCALE	MATERIAL
B		1:10	SEE BILL OF MATERIALS
3RD ANGLE		UNITS	DESCRIPTION
INCH			ASSY, PLT, DEAD
TOLERANCES		FINISH	NUMBER
X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°		NONE	372973


NOTES		CREATED IN	ARPAC A DURAVANT COMPANY 9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com
• INTERPRET PER ASME Y14.5M-1994.		SOLIDWORKS 2018	
• DIMENSIONS ARE IN INCHES [mm].		FILE \CONFIG	
• DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.		SIMILAR TO	
• BREAK SHARP EDGES AND CORNERS.		DATE CREATED	372973.Default
• PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.		DATE UPDATED	Monday, December 28, 2020 11:27:45 AM
• CREATED IN SOLIDWORKS 2018.		UPDATED BY	sarcher
		DATE CREATED	Monday, December 28, 2020 12:45:22 PM
		DATE UPDATED	Friday, January 22, 2021 1:24:31 PM
		UPDATED BY	sarcher

D

C

B

A

A SHEET 1 OF 1SHEET 1 OF 1

ARPAC 12/21/2021

4

3

2

1

C:\Users\jhu\Desktop\27080021\27080021.dwg created Monday, September 20, 2021

G

F


E

D




C

B

A



SECTION A-A



ITEM	QTY	NUMBER	DESCRIPTION
1	2	28358	WASHER SPECIAL
2	2	28370	WASHER SPECIAL
3	1	28817-100	SUPPORT PLATE TRANSFER R
4	1	28817-100	SUPPORT PLATE TRANSFER R
5	4	30038	SUPPORT PLATE TRANSFER R
6	2	30044	ROLLER SUPPORT
7	6	30047	ROLLER SUPPORT
8	2	30047	ROLLER SUPPORT
9	6	30047	ROLLER SUPPORT
10	1	30047	ROLLER SUPPORT
11	3	30047	ROLLER SUPPORT
12	4	30047	ROLLER SUPPORT
13	4	30047	ROLLER SUPPORT
14	2	30047	ROLLER SUPPORT
15	2	30047	ROLLER SUPPORT
16	2	30047	ROLLER SUPPORT
17	2	30047	ROLLER SUPPORT
18	2	30047	ROLLER SUPPORT
19	2	30047	ROLLER SUPPORT
20	2	30047	ROLLER SUPPORT
21	2	30047	ROLLER SUPPORT
22	2	30047	ROLLER SUPPORT
23	2	30047	ROLLER SUPPORT
24	2	30047	ROLLER SUPPORT
25	2	30047	ROLLER SUPPORT
26	2	30047	ROLLER SUPPORT
27	2	30047	ROLLER SUPPORT
28	2	30047	ROLLER SUPPORT
29	2	30047	ROLLER SUPPORT
30	2	30047	ROLLER SUPPORT
31	2	30047	ROLLER SUPPORT
32	2	30047	ROLLER SUPPORT
33	2	30047	ROLLER SUPPORT
34	2	30047	ROLLER SUPPORT

REV	DATE	BY	NOTE
1	9/20/2021	SRA	37296 WAS 37296
2	9/20/2021	SRA	37296 WAS 37296
3	9/20/2021	SRA	37296 WAS 37296
4	9/20/2021	SRA	37296 WAS 37296
5	9/20/2021	SRA	37296 WAS 37296
6	9/20/2021	SRA	37296 WAS 37296
7	9/20/2021	SRA	37296 WAS 37296
8	9/20/2021	SRA	37296 WAS 37296
9	9/20/2021	SRA	37296 WAS 37296
10	9/20/2021	SRA	37296 WAS 37296
11	9/20/2021	SRA	37296 WAS 37296
12	9/20/2021	SRA	37296 WAS 37296
13	9/20/2021	SRA	37296 WAS 37296
14	9/20/2021	SRA	37296 WAS 37296
15	9/20/2021	SRA	37296 WAS 37296
16	9/20/2021	SRA	37296 WAS 37296
17	9/20/2021	SRA	37296 WAS 37296
18	9/20/2021	SRA	37296 WAS 37296
19	9/20/2021	SRA	37296 WAS 37296
20	9/20/2021	SRA	37296 WAS 37296
21	9/20/2021	SRA	37296 WAS 37296
22	9/20/2021	SRA	37296 WAS 37296
23	9/20/2021	SRA	37296 WAS 37296
24	9/20/2021	SRA	37296 WAS 37296
25	9/20/2021	SRA	37296 WAS 37296
26	9/20/2021	SRA	37296 WAS 37296
27	9/20/2021	SRA	37296 WAS 37296
28	9/20/2021	SRA	37296 WAS 37296
29	9/20/2021	SRA	37296 WAS 37296
30	9/20/2021	SRA	37296 WAS 37296
31	9/20/2021	SRA	37296 WAS 37296
32	9/20/2021	SRA	37296 WAS 37296
33	9/20/2021	SRA	37296 WAS 37296
34	9/20/2021	SRA	37296 WAS 37296

DESCRIPTION	374152
ASSY CONVEYOR, INFEED, TS-2200, 47" ELEV	
374152	

ARPAC B SIZE FORMAT R5.1

2

1


D

C

B


A

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	2	374147	F-BAR CLAMP
2	1	374155	BAR, FLIGHT
3	4	800290-005	FSNR, NUT, HEX, 10-32, SS
4	4	841914	PLUNGER, BALL, #10-32 X 1/2"L



REV	DATE	BY	NOTE
REVISIONS			
SIZE		SCALE	MATERIAL
B		1:2	SEE BILL OF MATERIALS
3RD ANGLE		UNITS	DESCRIPTION
INCH		INCH	ASSY, BAR, FLIGHT, RELEASE, QUICK
TOLERANCES		FINISH	NUMBER
X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°		NONE	374154

NOTES		CREATED IN SOLIDWORKS 2018	ARPAC
• INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2018.		FILE \CONFIG SIMILAR TO DATE CREATED DATE UPDATED UPDATED BY	374154\374154 - Tuesday, March 30, 2021 9:39:19 AM Tuesday, April 27, 2021 9:58:51 AM sarcher
DRAFT		DATE CREATED DATE UPDATED UPDATED BY	Thursday, April 8, 2021 9:46:28 AM Tuesday, April 27, 2021 10:03:55 AM sarcher



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	4	385125	TRG. MTG. LEV. AN
2	4	385132	DOOR AGITATOR, 16880
3	2	3374169	BRKT. DOOR STOP LATCH
4	4	3374166	BRACKET, CLAMPING
5	4	802653	LATCH VISE-ACTION
6	8	335174	HINGE, DOOR, POLYAMIDE, BLACK




REVISIONS			
REV	DATE	BY	NOTE
1	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
2	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
3	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
4	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
5	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
6	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
7	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
8	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
9	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
10	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
11	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
12	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
13	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
14	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
15	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
16	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
17	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
18	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
19	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
20	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
21	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
22	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
23	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
24	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
25	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
26	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
27	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
28	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
29	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
30	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
31	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
32	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
33	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
34	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
35	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
36	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
37	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
38	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
39	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
40	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
41	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
42	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
43	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
44	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
45	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
46	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
47	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
48	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
49	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
50	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
51	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
52	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
53	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
54	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
55	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
56	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
57	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
58	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
59	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
60	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
61	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
62	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
63	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
64	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
65	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
66	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
67	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
68	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
69	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
70	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
71	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
72	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
73	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
74	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
75	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
76	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
77	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
78	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
79	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
80	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
81	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
82	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
83	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
84	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
85	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
86	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
87	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
88	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
89	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
90	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
91	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
92	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
93	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
94	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
95	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
96	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
97	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
98	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
99	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR
100	2021-04-27	1000	ASSY, GUARD, FLIGHT BAR

D

C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	383396	WLDMT, FRAME, TS-2300, RH, 48" ELEV
2	6	841409	LEVELER, ARTICULATING, 20000 # CAP, 1-8 STEM, 9.88 HIGH, CRS 4" BASE, 2 C/SUNK LAG HOLES, HEAVY LIP ON BASE

REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
B	1:40	SEE BILL OF MATERIALS	ASSY, FRAME, TS-2300, RH, 48" ELEV
3RD ANGLE	UNITS	FINISH	NUMBER
	INCH	NONE	383397
TOLERANCES			
X.X: ±1/32			
X.XX: ±.015			
X.XXX: ±.005			
ANGLES: ±1°			

NOTES		CREATED IN SOLIDWORKS 2018	
• INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2018.		ARPAC A DURAVANT COMPANY 9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com	
MODEL	FILE \CONFIG SIMILAR TO DATE CREATED DATE UPDATED	383397\Default	Thursday, March 18, 2021 5:20:42 PM Monday, April 5, 2021 1:58:51 PM jmeintz
DRAFT	DATE CREATED DATE UPDATED	Thursday, March 18, 2021 5:26:23 PM Thursday, March 18, 2021 5:27:51 PM sarcher	



D

C

B

A

ARPAC SIZE FORMAT RS.1



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	4	383404	CHANNEL, SUPPORT, GANTRY
2	4	383403	CHANNEL, HANGER, GANTRY
3	1	383402	BKT, MTG, ASSY, GUIDE
4	1	872441	GANTRY, 2-AXIS, YXCF-3 SERIES, 45KG PAYLOAD, 700MM X-STROKE, 700MM Y-STROKE
5	2	851301-003	SERVO, VPL 6.55/58 NMLB.IN, 115MMBC, 4500 RPM
6	2	872442	KIT, AXIAL, POSITION 70, FOR A-B VPL-B1153 SERVOMOTOR
7	2	872443	GEARBOX, POSITION 80, 3:1 RATIO, FOR A-B VPL-B1153 SERVOMOTOR



REV				DATE	BY	NOTE
REVISIONS						
SIZE	C	SCALE	1:8	MATERIAL	SEE BILL OF MATERIALS	
3RD ANGLE	YES	UNITS	INCH	TOLERANCES	FINISH NONE	
TOLERANCES				XX: ±1/32	NUMBER	
				X.XX: ±0.15	383405	
				ANGLES: ±1°		

NOTES
• INTERPRET PER ASME Y14.5M-1994.
• DIMENSIONS ARE IN INCHES (mm).
• DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
• BREAK SHARP EDGES AND CORNERS.
• PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
• CREATED IN SOLIDWORKS 2018.


CREATED IN SOLIDWORKS 2018
FILE \ CONFIG
SIMILAR TO
DATE CREATED
DATE UPDATED
DATE UPDATED BY
DATE CREATED
DATE UPDATED BY

383405 Default
Monday, March 22, 2021 1:26:46 PM
Wednesday, March 24, 2021 9:36:28 AM
sarcher
Monday, March 22, 2021 1:43:31 PM
Wednesday, March 24, 2021 9:36:21 AM
sarcher


ARPAC
A SUBSISTANT COMPANY
5555 W. Irving Park Rd.
Schaumburg, IL 60176
www.arpac.com





SECTION C-C
SCALE 1 : 10




SECTION D-D
SCALE 1 : 10



SECTION A-A
SCALE 1 : 10



DETAIL B
SCALE 1 : 4



17	1	848286	HANDLE, CRANK, AL, 12 MM SQUARE BORE
16	4	845590	BUSH, FLG, 8MM ID X 10MM OD X 9.5MM LG X 15MM FLG OD
15	2	846868	BRG, BALL, DEEP GROOVE, AXIAL, ID15MM, OD28MM, W9MM
14	2	845289	BUSH, OILITE, 20MM OD X 15MM ID X 15MM LG
13	1	827975	INDICATOR, DIGITAL, DIRECT DRIVE, INCLINED UPPER, P4MM, CW
12	8	827905	BRG, BALL, LINEAR, ID20MM, OD28MM, L30MM
11	1	372277	ASSY, PRODUCT COUNT, DYN DIV
10	5	289850	GUIDE, CHAIN, 14X20MM MODIFIED
9	1	372276	PLT, SUPPORT, TOP, GUIDE, LANE
8	2	284213	PLT, GUIDE, SIDE, GUIDE, LANE
7	2	284201	HINGE
6	2	284200	ENDBELL
5	2	372275	SHAFT, GUIDE, SUPPORT, GUIDE, LANE
4	4	284198	HOUSING, BLK, BRG, GUIDE, LANE
3	1	293305	NUT, GUIDE, SCREW, ADJ, GUIDE, LANE
2	1	293304	NUT, GUIDE, SCREW, ADJ, GUIDE, LANE
1	1	372274	SCREW, ADJ, GUIDE, LANE, 17" OPEN
ITM	QTY	PART NUM	DESCRIPTION

BILL OF MATERIALS

ARPAC 9511 WEST RIVER ST.
SCHILLER PARK, IL 60176

UNLESS OTHERWISE SPECIFIED
ALL DIMENSIONAL TOLERANCES:

FRACTIONS ± 1/64
TWO (2) DECIMALS ± 0.010
THREE (3) DECIMALS ± 0.005
ANGLES ± 0.5°




DRAWN: 3/22/2021 BY: SRA SCALE: 1:12 SIZE: B
RELEASED: FILENAME: 383407 APPROVED BY:

DESCRIPTION: ASSY, GUIDE, LANE, EXIT, DIVIDER, DYNAMIC

 DRAWING NUMBER:

383407

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	383426	ASSY. FRAME, DIVIDER, DYNAMIC, 48" ELEV
2	1	372271	ASSY. GUIDE, LANE, ENTRY, DIVIDER, DYNAMIC, MAX 10" W
3	1	345164	ASSY. GUIDE, SLIDE, GUIDE, LANE
4	1	383407	ASSY. GUIDE, LANE, EXIT, DIVIDER, DYNAMIC
5	1	345164-001	ASSY. GUIDE, SLIDE, GUIDE, LANE, LH
6	1	383433	ASSY. GUARDS, DIVIDER, DYNAMIC, 48" ELEV
7	1	383405	ASSY. GANTRY, TWO-AXIS
8	1	372287	ASSY. CONV. LONG, DIVIDER, DYNAMIC
9	1	384621	ASSY. CONV. SHORT, DIVIDER, DYNAMIC
10	1	384764	ASSY. CONV. INFEED, DIVIDER, LANE
11	1	383430	ASSY. GUIDE, LANE, DISCHARGE, DIVIDER
12	1	372611-001	WLDMT, BKT, MTG, ENCLOSURE
13	1	372777	BKT, MTG, BOX, 6-BUTTON
14	1	330101	BKT, MTG, BOX, BUTTON, SINGLE
15	1	828038	BELT, ACETAL, GRAY, FLAT TOP, 1100 SERIES, 27"W(684mm)



NOTES

- INTERPRET PER ASME Y14.5M-1994. DIMENSIONS ARE IN INCHES (mm).
- DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
- BREAK SHARP EDGES AND CORNERS.
- PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
- CREATED IN SOLIDWORKS 2018.

CREATED IN SOLIDWORKS 2018

FILE \CONFIO SIMILAR TO DATE CREATED DATE UPDATED DATE UPDATED BY

MODEL 383409\383409

DATE CREATED Tuesday, July 24, 2012 11:04:22 AM

DATE UPDATED Tuesday, April 20, 2021 3:57:47 PM

DATE UPDATED Friday, April 16, 2021 10:25:04 AM

DATE UPDATED Tuesday, April 20, 2021 3:57:14 PM




DATE UPDATED Gibran Mota

ARPAC




5555 W. Irving Park Rd. Schiller Park, IL 60176

www.arpac.com

REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
C	1:25	SEE BILL OF MATERIALS	ASSY. DIVIDER, DYNAMIC, LD-400, 48" ELEV
3RD ANGLE	UNITS		
INCH			
TOLERANCES	FINISH	NUMBER	
XX: ±1/32	NONE	383409	
XX: ±0.015			
XX: ±0.005			
ANGLES: ±1°			



SECTION A-A



SECTION B-B

BILL OF MATERIALS		
ITEM	QTY	NUMBER DESCRIPTION
846048	1	ALUMINUM EXTRUSION GUARD 72 IN X 1/4 IN FLG LG
2	846048-001	KEY AL EXTRUSION GUARD 72 IN X 1/4 IN FLG LG
2	846048-002	KEY AL EXTRUSION GUARD 72 IN X 1/4 IN FLG LG
4	846003	KEY AL EXTRUSION GUARD 72 IN X 1/4 IN FLG LG
5	853419	PANEL GUARD LOWER INFED
6	853419	PANEL GUARD LOWER INFED
7	853424	PANEL GUARD LOWER DISCHARGE
8	853424	PANEL GUARD LOWER DISCHARGE
9	884762	BIKT MTS GUARD DISCHARGE
10	1384915	GUARD ACCESS REACH DISCHARGE
11	1384916	BIKT MTS GUARD ACCESS REACH DISCHARGE
12	130676	BIKT MTS BOX 4-BUTTON
13	130110	BIKT BOX BUTTON SINGLE
14	217176	PANEL GUARD COLLATOR
15	127004	GUARD MAGAZINE LOWER
16	12653-001	GUARD MAGAZINE LOWER
17	127435	PANEL GUARD LOWER MAGAZINE
18	127435	PANEL GUARD LOWER MAGAZINE
19	252137-003	GUARD ENTER MAGAZINE
20	252137-003	GUARD ENTER MAGAZINE
21	252137-003	GUARD ENTER MAGAZINE
22	252137-003	GUARD ENTER MAGAZINE
23	252137-003	GUARD ENTER MAGAZINE
24	252137-003	GUARD ENTER MAGAZINE
25	252137-003	GUARD ENTER MAGAZINE
26	252137-003	GUARD ENTER MAGAZINE
27	252137-003	GUARD ENTER MAGAZINE
28	252137-003	GUARD ENTER MAGAZINE
29	252137-003	GUARD ENTER MAGAZINE
30	252137-003	GUARD ENTER MAGAZINE
31	252137-003	GUARD ENTER MAGAZINE
32	252137-003	GUARD ENTER MAGAZINE
33	252137-003	GUARD ENTER MAGAZINE
34	252137-003	GUARD ENTER MAGAZINE
35	252137-003	GUARD ENTER MAGAZINE
36	252137-003	GUARD ENTER MAGAZINE
37	252137-003	GUARD ENTER MAGAZINE
38	252137-003	GUARD ENTER MAGAZINE
39	252137-003	GUARD ENTER MAGAZINE
40	252137-003	GUARD ENTER MAGAZINE
41	252137-003	GUARD ENTER MAGAZINE
42	252137-003	GUARD ENTER MAGAZINE
43	252137-003	GUARD ENTER MAGAZINE
44	252137-003	GUARD ENTER MAGAZINE
45	252137-003	GUARD ENTER MAGAZINE
46	252137-003	GUARD ENTER MAGAZINE
47	252137-003	GUARD ENTER MAGAZINE
48	252137-003	GUARD ENTER MAGAZINE
49	252137-003	GUARD ENTER MAGAZINE
50	252137-003	GUARD ENTER MAGAZINE
51	252137-003	GUARD ENTER MAGAZINE
52	252137-003	GUARD ENTER MAGAZINE
53	252137-003	GUARD ENTER MAGAZINE
54	252137-003	GUARD ENTER MAGAZINE
55	252137-003	GUARD ENTER MAGAZINE
56	252137-003	GUARD ENTER MAGAZINE
57	252137-003	GUARD ENTER MAGAZINE
58	252137-003	GUARD ENTER MAGAZINE
59	252137-003	GUARD ENTER MAGAZINE
60	252137-003	GUARD ENTER MAGAZINE
61	252137-003	GUARD ENTER MAGAZINE
62	252137-003	GUARD ENTER MAGAZINE
63	252137-003	GUARD ENTER MAGAZINE
64	252137-003	GUARD ENTER MAGAZINE
65	252137-003	GUARD ENTER MAGAZINE
66	252137-003	GUARD ENTER MAGAZINE
67	252137-003	GUARD ENTER MAGAZINE
68	252137-003	GUARD ENTER MAGAZINE
69	252137-003	GUARD ENTER MAGAZINE
70	252137-003	GUARD ENTER MAGAZINE
71	252137-003	GUARD ENTER MAGAZINE
72	252137-003	GUARD ENTER MAGAZINE
73	252137-003	GUARD ENTER MAGAZINE
74	252137-003	GUARD ENTER MAGAZINE
75	252137-003	GUARD ENTER MAGAZINE
76	252137-003	GUARD ENTER MAGAZINE
77	252137-003	GUARD ENTER MAGAZINE
78	252137-003	GUARD ENTER MAGAZINE
79	252137-003	GUARD ENTER MAGAZINE
80	252137-003	GUARD ENTER MAGAZINE
81	252137-003	GUARD ENTER MAGAZINE
82	252137-003	GUARD ENTER MAGAZINE
83	252137-003	GUARD ENTER MAGAZINE
84	252137-003	GUARD ENTER MAGAZINE
85	252137-003	GUARD ENTER MAGAZINE
86	252137-003	GUARD ENTER MAGAZINE
87	252137-003	GUARD ENTER MAGAZINE
88	252137-003	GUARD ENTER MAGAZINE
89	252137-003	GUARD ENTER MAGAZINE
90	252137-003	GUARD ENTER MAGAZINE
91	252137-003	GUARD ENTER MAGAZINE
92	252137-003	GUARD ENTER MAGAZINE
93	252137-003	GUARD ENTER MAGAZINE
94	252137-003	GUARD ENTER MAGAZINE
95	252137-003	GUARD ENTER MAGAZINE
96	252137-003	GUARD ENTER MAGAZINE
97	252137-003	GUARD ENTER MAGAZINE
98	252137-003	GUARD ENTER MAGAZINE
99	252137-003	GUARD ENTER MAGAZINE
100	252137-003	GUARD ENTER MAGAZINE
101	252137-003	GUARD ENTER MAGAZINE
102	252137-003	GUARD ENTER MAGAZINE
103	252137-003	GUARD ENTER MAGAZINE
104	252137-003	GUARD ENTER MAGAZINE
105	252137-003	GUARD ENTER MAGAZINE
106	252137-003	GUARD ENTER MAGAZINE
107	252137-003	GUARD ENTER MAGAZINE
108	252137-003	GUARD ENTER MAGAZINE
109	252137-003	GUARD ENTER MAGAZINE
110	252137-003	GUARD ENTER MAGAZINE
111	252137-003	GUARD ENTER MAGAZINE
112	252137-003	GUARD ENTER MAGAZINE
113	252137-003	GUARD ENTER MAGAZINE
114	252137-003	GUARD ENTER MAGAZINE
115	252137-003	GUARD ENTER MAGAZINE
116	252137-003	GUARD ENTER MAGAZINE
117	252137-003	GUARD ENTER MAGAZINE
118	252137-003	GUARD ENTER MAGAZINE
119	252137-003	GUARD ENTER MAGAZINE
120	252137-003	GUARD ENTER MAGAZINE
121	252137-003	GUARD ENTER MAGAZINE
122	252137-003	GUARD ENTER MAGAZINE
123	252137-003	GUARD ENTER MAGAZINE
124	252137-003	GUARD ENTER MAGAZINE
125	252137-003	GUARD ENTER MAGAZINE
126	252137-003	GUARD ENTER MAGAZINE
127	252137-003	GUARD ENTER MAGAZINE
128	252137-003	GUARD ENTER MAGAZINE
129	252137-003	GUARD ENTER MAGAZINE
130	252137-003	GUARD ENTER MAGAZINE
131	252137-003	GUARD ENTER MAGAZINE
132	252137-003	GUARD ENTER MAGAZINE
133	252137-003	GUARD ENTER MAGAZINE
134	252137-003	GUARD ENTER MAGAZINE
135	252137-003	GUARD ENTER MAGAZINE
136	252137-003	GUARD ENTER MAGAZINE
137	252137-003	GUARD ENTER MAGAZINE
138	252137-003	GUARD ENTER MAGAZINE
139	252137-003	GUARD ENTER MAGAZINE
140	252137-003	GUARD ENTER MAGAZINE
141	252137-003	GUARD ENTER MAGAZINE
142	252137-003	GUARD ENTER MAGAZINE
143	252137-003	GUARD ENTER MAGAZINE
144	252137-003	GUARD ENTER MAGAZINE
145	252137-003	GUARD ENTER MAGAZINE
146	252137-003	GUARD ENTER MAGAZINE
147	252137-003	GUARD ENTER MAGAZINE
148	252137-003	GUARD ENTER MAGAZINE
149	252137-003	GUARD ENTER MAGAZINE
150	252137-003	GUARD ENTER MAGAZINE
151	252137-003	GUARD ENTER MAGAZINE
152	252137-003	GUARD ENTER MAGAZINE
153	252137-003	GUARD ENTER MAGAZINE
154	252137-003	GUARD ENTER MAGAZINE
155	252137-003	GUARD ENTER MAGAZINE
156	252137-003	GUARD ENTER MAGAZINE
157	252137-003	GUARD ENTER MAGAZINE
158	252137-003	GUARD ENTER MAGAZINE
159	252137-003	GUARD ENTER MAGAZINE
160	252137-003	GUARD ENTER MAGAZINE
161	252137-003	GUARD ENTER MAGAZINE
162	252137-003	GUARD ENTER MAGAZINE
163	252137-003	GUARD ENTER MAGAZINE
164	252137-003	GUARD ENTER MAGAZINE
165	252137-003	GUARD ENTER MAGAZINE
166	252137-003	GUARD ENTER MAGAZINE
167	252137-003	GUARD ENTER MAGAZINE
168	252137-003	GUARD ENTER MAGAZINE
169	252137-003	GUARD ENTER MAGAZINE
170	252137-003	GUARD ENTER MAGAZINE
171	252137-003	GUARD ENTER MAGAZINE
172	252137-003	GUARD ENTER MAGAZINE
173	252137-003	GUARD ENTER MAGAZINE
174	252137-003	GUARD ENTER MAGAZINE
175	252137-003	GUARD ENTER MAGAZINE
176	252137-003	GUARD ENTER MAGAZINE
177	252137-003	GUARD ENTER MAGAZINE
178	252137-003	GUARD ENTER MAGAZINE
179	252137-003	GUARD ENTER MAGAZINE
180	252137-003	GUARD ENTER MAGAZINE
181	252137-003	GUARD ENTER MAGAZINE
182	252137-003	GUARD ENTER MAGAZINE
183	252137-003	GUARD ENTER MAGAZINE
184	252137-003	GUARD ENTER MAGAZINE
185	252137-003	GUARD ENTER MAGAZINE
186	252137-003	GUARD ENTER MAGAZINE
187	252137-003	GUARD ENTER MAGAZINE
188	252137-003	GUARD ENTER MAGAZINE
189	252137-003	GUARD ENTER MAGAZINE
190	252137-003	GUARD ENTER MAGAZINE
191	252137-003	GUARD ENTER MAGAZINE
192	252137-003	GUARD ENTER MAGAZINE
193	252137-003	GUARD ENTER MAGAZINE
194	252137-003	GUARD ENTER MAGAZINE
195	252137-003	GUARD ENTER MAGAZINE
196	252137-003	GUARD ENTER MAGAZINE
197	252137-003	GUARD ENTER MAGAZINE
198	252137-003	GUARD ENTER MAGAZINE
199	252137-003	GUARD ENTER MAGAZINE
200	252137-003	GUARD ENTER MAGAZINE
201	252137-003	GUARD ENTER MAGAZINE
202	252137-003	GUARD ENTER MAGAZINE
203	252137-003	GUARD ENTER MAGAZINE
204	252137-003	GUARD ENTER MAGAZINE
205	252137-003	GUARD ENTER MAGAZINE
206	252137-003	GUARD ENTER MAGAZINE
207	252137-003	GUARD ENTER MAGAZINE
208	252137-003	GUARD ENTER MAGAZINE
209	252137-003	GUARD ENTER MAGAZINE
210	252137-003	GUARD ENTER MAGAZINE
211	252137-003	GUARD ENTER MAGAZINE
212	252137-003	GUARD ENTER MAGAZINE
213	252137-003	GUARD ENTER MAGAZINE
214	252137-003	GUARD ENTER MAGAZINE
215	252137-003	GUARD ENTER MAGAZINE
216	252137-003	GUARD ENTER MAGAZINE
217	252137-003	GUARD ENTER MAGAZINE
218	252137-003	GUARD ENTER MAGAZINE
219	252137-003	GUARD ENTER MAGAZINE
220	252137-003	GUARD ENTER MAGAZINE
221	252137-003	GUARD ENTER MAGAZINE
222	252137-003	GUARD ENTER MAGAZINE
223	252137-003	GUARD ENTER MAGAZINE
224	252137-003	GUARD ENTER MAGAZINE
225	252137-003	GUARD ENTER MAGAZINE
226	252137-003	GUARD ENTER MAGAZINE
227	252137-003	GUARD ENTER MAGAZINE
228	252137-003	GUARD ENTER MAGAZINE
229	252137-003	GUARD ENTER MAGAZINE
230	252137-003	GUARD ENTER MAGAZINE
231	252137-003	GUARD ENTER MAGAZINE
232	252137-003	GUARD ENTER MAGAZINE
233	252137-003	GUARD ENTER MAGAZINE
234	252137-003	GUARD ENTER MAGAZINE
235	252137-003	GUARD ENTER MAGAZINE
236	252137-003	GUARD ENTER MAGAZINE
237	252137-003	GUARD ENTER MAGAZINE
238	252137-003	GUARD ENTER MAGAZINE
239	252137-003	GUARD ENTER MAGAZINE
240	252137-003	GUARD ENTER MAGAZINE
241	252137-003	GUARD ENTER MAGAZINE
242	252137-003	GUARD ENTER MAGAZINE
243	252137-003	GUARD ENTER MAGAZINE
244	252137-003	GUARD ENTER MAGAZINE
245	252137-003	GUARD ENTER MAGAZINE
246	252137-003	GUARD ENTER MAGAZINE
247	252137-003	GUARD ENTER MAGAZINE
248	252137-003	GUARD ENTER MAGAZINE
249	252137-003	GUARD ENTER MAGAZINE
250	252137-003	GUARD ENTER MAGAZINE
251	252137-003	GUARD ENTER MAGAZINE
252	252137-003	GUARD ENTER MAGAZINE
253	252137-003	GUARD ENTER MAGAZINE
254	252137-003	GUARD ENTER MAGAZINE
255	252137-003	GUARD ENTER MAGAZINE
256	252137-003	GUARD ENTER MAGAZINE
257	252137-003	GUARD ENTER MAGAZINE
258	252137-003	GUARD ENTER MAGAZINE
259	252137-003	GUARD ENTER MAGAZINE
260	252137-003	GUARD ENTER MAGAZINE
261	252137-003	GUARD ENTER MAGAZINE
262	252137-003	GUARD ENTER MAGAZINE
263	252137-003	GUARD ENTER MAGAZINE
264	252137-003	GUARD ENTER MAGAZINE
265	252137-003	GUARD ENTER MAGAZINE
266	252137-003	GUARD ENTER MAGAZINE
267	252137-003	GUARD ENTER MAGAZINE
268	252137-003	GUARD ENTER MAGAZINE
269	252137-003	GUARD ENTER MAGAZINE
270	252137-003	GUARD ENTER MAGAZINE
271	252137-003	GUARD ENTER MAGAZINE
272	252137-003	GUARD ENTER MAGAZINE
273	252137-003	GUARD ENTER MAGAZINE
274	252137-003	GUARD ENTER MAGAZINE
275	252137-003	GUARD ENTER MAGAZINE
276	252137-003	GUARD ENTER MAGAZINE
277	252137-003	GUARD ENTER MAGAZINE
278	252137-003	GUARD ENTER MAGAZINE
279	252137-003	GUARD ENTER MAGAZINE
280	252137-003	GUARD ENTER MAGAZINE
281	252137-003	GUARD ENTER MAGAZINE
282	252137-003	GUARD ENTER MAGAZINE
283	252137-003	GUARD ENTER MAGAZINE
284	252137-003	GUARD ENTER MAGAZINE
285	252137-003	GUARD ENTER MAGAZINE
286	252137-003	GUARD ENTER MAGAZINE
287	252137-003	GUARD ENTER MAGAZINE
288	252137-003	GUARD ENTER MAGAZINE
289	252137-003	GUARD ENTER MAGAZINE
290	252137-003	GUARD ENTER MAGAZINE
291	252137-003	GUARD ENTER MAGAZINE
292	252137-003	GUARD ENTER MAGAZINE
293	252137-003	GUARD ENTER MAGAZINE
294	252137-003	GUARD ENTER MAGAZINE
295	252137-003	GUARD ENTER MAGAZINE
296	252137-003	GUARD ENTER MAGAZINE
297	252137-003	GUARD ENTER MAGAZINE
298	252137-003	GUARD ENTER MAGAZINE
299	252137-003	GUARD ENTER MAGAZINE
300	252137-003	GUARD ENTER MAGAZINE
301	252137-003	GUARD ENTER MAGAZINE
302	252137-003	GUARD ENTER MAGAZINE
303	252137-003	GUARD ENTER MAGAZINE
304	252137-003	GUARD ENTER MAGAZINE
305	252137-003	GUARD ENTER MAGAZINE
306	252137-003	GUARD ENTER MAGAZINE
307	252137-003	GUARD ENTER MAGAZINE
308	252137-003	GUARD ENTER MAGAZINE
309	252137-003	GUARD ENTER MAGAZINE
310	252137-003	GUARD ENTER MAGAZINE
311	252137-003	GUARD ENTER MAGAZINE
312	252137-003	GUARD ENTER MAGAZINE
313	252137-003	GUARD ENTER MAGAZINE
314	252137-003	GUARD ENTER MAGAZINE
315	252137-003	GUARD ENTER MAGAZINE
316	252137-003	GUARD ENTER MAGAZINE
317	252137-003	GUARD ENTER MAGAZINE
318	252137-003	GUARD ENTER MAGAZINE
319	252137-003	GUARD ENTER MAGAZINE
320	252137-003	GUARD ENTER MAGAZINE
321	252137-003	GUARD ENTER MAGAZINE
322	252137-003	GUARD ENTER MAGAZINE
323	252137-003	GUARD ENTER MAGAZINE
324	252137-003	GUARD ENTER MAGAZINE
325	252137-003	GUARD ENTER MAGAZINE
326	252137-003	GUARD ENTER MAGAZINE
327	252137-003	GUARD ENTER MAGAZINE
328		




REV	DATE	BY	NOTE
REVISIONS			
SIZE D	SCALE 1:24	MATERIAL SEE BILL OF MATERIALS	DESCRIPTION ASSY, GUARDS, TS- 2300, 48" ELEV, RH
SPD ANGLE 	UNITS INCH	TOLERANCES X.XX ±.02 X.XXX ±.015 X.XXXX ±.005 X.XXXXX ±.001	NUMBER 383421
		FINISH NONE	

D


C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	383427	ASSY, FRAME, DIVIDER, 48" ELEV
2	4	284186	WLDMT, MBR, FRAME, HOR, UPR
3	2	372327	GUARD, END, LWR
4	4	827619	LEVELER, ARTICULATING, 20000 # CAP, 1-8 STEM, 7.88 HIGH, CRS 4" BASE, 2 C'SUNK LAG HOLES, HEAVY LIP ON BASE



NOTES

- INTERPRET PER ASME Y14.5M-1994.
- DIMENSIONS ARE IN INCHES [mm].
- DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
- BREAK SHARP EDGES AND CORNERS.
- PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
- CREATED IN SOLIDWORKS 2013.

CREATED IN
SOLIDWORKS 2013

ARPAC
A DUBAYANT COMPANY

9555 W. Irving Park Rd.
Schiller Park, IL 60176
www.arpac.com

FILE \CONFIG
SIMILAR TO
DATE CREATED
DATE UPDATED
UPDATED BY

383426\383426
Friday, August 3, 2012 2:14:27 PM
Thursday, April 8, 2021 4:07:55 PM
Gibran.Mota

DRAFT
DATE CREATED
DATE UPDATED
UPDATED BY

Wednesday, January 24, 2018 6:03:09 PM
Thursday, April 8, 2021 4:07:55 PM
Gibran.Mota

REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
B	1:25	SEE BILL OF MATERIALS	ASSY, FRAME, DIVIDER, DYNAMIC, 48" ELEV
3RD ANGLE	UNITS	FINISH	NUMBER
	INCH	NONE	383426
TOLERANCES			
X.X: ±1/32			
X.XX: ±.015			
X.XXX: ±.005			
ANGLES: ±1°			

D

C

B




A

D


C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	4	284169	ASSY, WLDMT, UNION, RAIL
2	1	383428	WLDMT, FRAME, SIDE, DIVIDER
3	1	383429	WLDMT, FRAME, SIDE, DIVIDER



NOTES

- INTERPRET PER ASME Y14.5M-1994.
- DIMENSIONS ARE IN INCHES [mm].
- DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
- BREAK SHARP EDGES AND CORNERS.
- PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
- CREATED IN SOLIDWORKS 2013.

CREATED IN
SOLIDWORKS 2013
ARPAC
A DURAVANT COMPANY
9555 W. Irving Park Rd.
Schiller Park, IL 60176
www.arpac.comMODEL
FILE \CONFIG
SIMILAR TO
DATE CREATED
DATE UPDATED
UPDATED BY383427\383427
-
Wednesday, June 27, 2012 4:27:06 AM
Thursday, April 8, 2021 4:08:28 PM
Gibran.MotaDRAFT
DATE CREATED
DATE UPDATED
UPDATED BYThursday, June 28, 2012 10:45:55 PM
Thursday, April 8, 2021 4:08:39 PM
Gibran.MotaSIZE
BTOLERANCES
X.X: ±1/32
X.XX: ±.015
X.XXX: ±.005
ANGLES: ±1°SCALE
1:32UNITS
INCHMATERIAL
SEE BILL OF MATERIALSFINISH
NONE

DESCRIPTION

ASSY, FRAME, DIVIDER,
48" ELEV

NUMBER

383427

D

C

B

A

ARPAC B SIZE FORMAT R5.1

2





1

D

C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	4	372354-001	BAR, MTG, SIDE, GUIDE, LANE
2	2	306497	PLT, STOP, SPACER
3	2	121454-035	SHAFT, HANGER, 30.8044 LG
4	2	228692	ASSY, HANDLE, NUT
5	4	307084	BLK, MTG, GUIDES
6	4	383431	PLT, GUIDE, LANE, DISCHARGE, DIVIDER

REV	DATE	BY	NOTE
REVISIONS			
SIZE B		SCALE 1:12	MATERIAL SEE BILL OF MATERIALS
3RD ANGLE 		UNITS INCH	DESCRIPTION ASSY, GUIDE, LANE, DISCHARGE, DIVIDER
TOLERANCES X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°		FINISH NONE	NUMBER 383430


NOTES		CREATED IN SOLIDWORKS 2018		9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com	
• INTERPRET PER ASME Y14.5M-1994.		FILE \CONFIG		383430\3X2 355ML 4-PACK CARTONS	
• DIMENSIONS ARE IN INCHES [mm].		DATE CREATED		Thursday, April 8, 2021 3:31:58 PM	
• DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.		DATE UPDATED		Friday, April 9, 2021 12:58:02 PM	
• BREAK SHARP EDGES AND CORNERS.		UPDATED BY		Gibran.Mota	
• PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.		DATE CREATED		Friday, April 9, 2021 12:48:32 PM	
• CREATED IN SOLIDWORKS 2018.		DATE UPDATED		Friday, April 9, 2021 12:56:45 PM	
		UPDATED BY		Gibran.Mota	





D

C

B







A






BILL OF MATERIALS		
ITEM	QTY	NUMBER DESCRIPTION
1	1	972586-100 P.T. SIDE CONV. SHORT DRIVE, 1.0 HP
2	1	972588-101 P.T. SIDE CONV. LONG DRIVE, 1.0 HP
3	1	972589-101 P.T. CONNECTING CONV. DIVIDER, DYNAMIC
4	2	284697 ASSY W/ALUM. SUPPORT CARRIER
5	6	285207 STRIP WELD CONV. DIVIDER, DYNAMIC
6	1	972599-101 P.T. SINGLE 1.5 X 1.5 SS. ROUND HO
7	3	345146 CROSSBAR, INTERMEDIATE
8	1	1158-106 SS. SHIELD, LONG INFEED
9	1	616-106 SS. STRAIGHT, SS. 14-26
10	2	300344 BEARING SUPPORT
11	2	BROG. INT. 1/2 X 1/8 X 1/8 LG. SS. DOUBLE SEAL ID
12	2	30972-102 DEFLECTION ROLLER
13	3	300733 EXTRUSION, UHMW
14	2	6601-28 EXTRUSION, UHMW, 4 JECS, TO LG. FOR TIGA
15	9	636679 SPROCKET, 24 T, 62 TRACKING RING
16	2	636632 SPROCKET, 12 T, 62 BORE
17	2	288168 SHT. FLAT, 1 ID, 4 BOLT
18	1	345145 SHT. FLAT, 1 ID, 4 CONVEYOR, T DIA
19	1	232669 WSPIN, SPECIAL
20	2	309302 P.N. HOLLOW, TORQUE ARM
21	1	GEARING, 10 FLEXLOK, 30" HOLLOW SHAF
22	1	972585-1 P.N. 70 RPM, 1.5 HP, 230/460 VAC, W/ TORQUE

REV	DATE	BY	NOTE
REVISIONS			
Part No. 60132	SIZE D	SCALE 1:4	MATERIAL SEE BILL OF MATERIALS
3RD ANGLE 	UNITS INCH	DESCRIPTION ASSY. CONV. SHORT, DIVIDER, DYNAMIC	
TOLERANCES .XX: ±.02 .X.XX: ±.015 .XX.XX: ±.005 ANGLES: ±.1°		FINISH PART OF ASSEMBLY	NUMBER 384621



45	2	372885	BKT. SUPPORT. PLATE. DEAD
44	2	372886	SPACER. SUPPORT. PLATE. DEAD
43	2	372980	PLT. MTG. ASSY. BAR. FLIGHT
42	4	372979-001	PLT. MTG. ASSY. BAR. FLIGHT
41	1	282805	BKT. PRGX
40	16	807284-001	LINK. CONN. ATTACH. #60. D-1. SPECIAL 1-1/2 LG. EXTENDED PIN
39	8	807831	CLIP. RAIL. SELF-TIGHTENING. 5/16 STUD X 5/8 LG. SS. HEAVY DUTY FLIGHT BAR
38	8	221666	BRG. TAKE-UP. 1 ID. 3/4-10 TAPPED END
37	2	802736	GUIDE. CHAIN #60
36	2	187583	GUIDE. CHAIN #60
35	2	187582	GUIDE. CHAIN #60
34	2	815212-003	RAIL. GUIDE. ROUND. SS. 12' LG
33	1	803668-001	LOCKING DEVICE. KEYLESS 1"
32	2	800905	SPKT. 508B15H. IDLER. 5/8 ID. HARDENED TEETH
31	8	115939	BLOCK. GUIDE. PRODUCT
30	8	845483	ROD. ADJ. 1/2 DIA X 12 LG. 5/16-18 TAPPED THREAD. SS
29	8	823126	HD. ADJ. ZINC. 2-1/2 LG 5/16-18 X 1.26 STUD
28	4	803841	BRG. CART. 1 X 2.0472 X 1.47/64 LG. SEALED. LOCK COLLAR ID. PRESS FIT OD
27	2	187508	SPACER. TENSIONER. FLIGHT BAR
26	1	188961	SPKT. 50B15. MOD. 1.969 BORE. W/O KEY
25	4	234677	SPKT. 60B20. MOD. 1.000 BORE. SPECIAL
24	1	126781	SUPPORT. ROD
23	32	801359	CLAMP. RAIL. SINGLE. 1.5 LG. SS. ROUND HOLE
22	1	108515	HAND WHEEL. COLLATOR
21	1	300150	SHAFT. DRIVE. FLIGHT BAR
20	2	192837	SUPPORT. DEAD. PLT. BAR. FLIGHT
19	4	115987	SPKT. 60B20. MOD. 2.047 BORE
18	2	384631	BLK. MTG. ASSY. BAR. FLIGHT
17	2	221933	CROSS MEMBER. FLIGHT BAR
16	4	188684	SHAFT. IDLER
15	1	188679-002	RAIL. GUIDE. TOP. LH
14	1	188679-001	RAIL. GUIDE. TOP. RH
13	1	274433	SHAFT. TAIL
12	2	286508	PLT. VER. TAIL END. RH
11	4	126787	PLT. NUT
10	48	800486	CHAIN. RLR. #60
9	2	827116	BRG. FLG. 1 ID. 2-BOLT. 3.89 BOLT CNTRS
8	1	286509-002	RAIL. GUIDE. BOTTOM. LH
7	1	286509-001	RAIL. GUIDE. BOTTOM. RH
6	2	188379	SHAFT
5	2	192827	BLOCK. GUIDE. TENSION
4	8	193855	SPACER
3	4	112721	TIE. BAR. BEARING
2	4	372982	BLK. MTG. ASSY. BAR. FLIGHT
1	2	286507	PLT. SIDE

ITEM	QTY	PART NUM	DESCRIPTION
BILL OF MATERIALS			
AIRPAC 9511 WEST RIVER ST. SCHILLER PARK, IL 60176			
UNLESS OTHERWISE SPECIFIED: FRACTIONS: ±.004 ALL DIMENSIONAL TOLERANCES: TWO (2) DECIMALS ±.005 THREE (3) DECIMALS ±.005 ANGLES: ±.5°			
DRAWN	04/15/2021	BY: GM	SCALE: 1:8 SIZE: D
RELEASED		FILENAME: 384629	APPROVED BY:
DESCRIPTION: ASSY. BAR, FLIGHT, PACING, TS-2000			
DRAWING NUMBER: 384629			



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	286911	POST MTG DETECTOR
2	1	214781-027	SHAFT, MTG, DETECTOR, BOTTLE, 29.11 LG
3	1	286911-001	POST MTG DETECTOR
4	2	286907	INDICATOR
5	2	808969	HDL, ADJ, SS, 2.56 LG 5/16-18 X .59 STUD
6	4	225647	WLDMT, BKT, MTG, P.E.
7	2	276415	BKT, MTG, SHAFT
8	1	276242-002	ROD, GUIDE

REV		DATE		BY	NOTE
REVISIONS					
SIZE		SCALE		MATERIAL	
B		1:6		SEE BILL OF MATERIALS	
3RD ANGLE		UNITS		DESCRIPTION	
		INCH			
TOLERANCES		FINISH			
X.X: ±1/32		NONE		ASSY, DETECT, PRODUCT, 4-LANES, 28.86" WIDE	
X.XX: ±.015					
X.XXX: ±.005					
ANGLES: ±1°					
				NUMBER	
				384636	


NOTES		CREATED IN SOLIDWORKS 2018		 9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com	
• INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2018.			FILE \CONFIG SIMILAR TO	384636\384636	
			DATE CREATED	Tuesday, March 13, 2012 5:12:20 PM	
			DATE UPDATED	Friday, April 16, 2021 8:59:57 AM	
			UPDATED BY	Gibran.Mota	
		DRAFT	DATE CREATED	Wednesday, August 26, 2020 4:16:26 PM	
			DATE UPDATED	Friday, April 16, 2021 8:59:49 AM	
			UPDATED BY	Gibran.Mota	

D


C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	309540	POST, MTG, DETECTOR, TALL
2	1	214781-027	SHAFT, MTG, DETECTOR, BOTTLE, 29.11 LG
3	1	225647	WLDMT, BKT, MTG, P.E.
4	1	309540-001	POST, MTG, DETECTOR, TALL
5	1	238514	WLDMT, BKT, MTG, P.E., REFLECTOR
6	4	357429	LEVELER, CONTACT
7	4	283414	COLLAR, LOCATOR, FINGER
8	4	842149	SPRING, EXTENSION
9	2	276415	BKT, MTG, SHAFT
10	1	276242-002	ROD, GUIDE
11	2	286907	INDICATOR
12	2	808969	HDL, ADJ, SS, 2.56 LG 5/16-18 X .59 STUD



REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
B	1:6	SEE BILL OF MATERIALS	ASSY, DETECT, PRODUCT, 4-LANE, 28.86" WIDE
3RD ANGLE	UNITS	FINISH	NUMBER
INCH	TOLERANCES	NONE	384637
	X.X: ±1/32 X.XX: ±.015 X.XXX: ±.005 ANGLES: ±1°		

NOTES		CREATED IN SOLIDWORKS 2018		ARPAC	
- INTERPRET PER ASME Y14.5M-1994. - DIMENSIONS ARE IN INCHES [mm]. - DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. - BREAK SHARP EDGES AND CORNERS. - PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. - CREATED IN SOLIDWORKS 2018.		9555 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com		A DURAVANT COMPANY	
MODEL	FILE \CONFIG SIMILAR TO DATE CREATED DATE UPDATED	384637\384637	Tuesday, March 13, 2012 5:12:20 PM	sarcher	
DRAFT	DATE CREATED DATE UPDATED	Friday, August 28, 2020 11:37:41 AM	Monday, April 19, 2021 8:43:12 AM	sarcher	


4 ARPAC C SIZE FORMAT R6.1

D

C


B

A




CARTON SET-UP

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	4	815212-003	RAIL, GUIDE, ROUND, SS, 12' LG
2	4	801312	CLAMP, RAIL, DOUBLE, 1.5 LG, SS, 2.5 CENTERS, ROUND HOLE
3	1	810110	ROD, ADJ, 5/8 X 6 LG, 5/16-18 TAP, SS
4	9	801340	BKT, SWIVEL, 5/8 ROD, W/KNOB AND EYLET, POLYAMIDE
5	1	827493-001	SPEEDRAIL, SB, 2 STRAND, 6' LG
6	6	807728	ROD, ADJ, 5/8 DIA X 18 LG, 3/8-16 TAPPED THREAD, SS
7	1	801289	ROD, ADJ, 5/8 DIA X 15 LG, 3/8-16 TAPPED THREAD, SS
8	1	385047	BKT, CLAMP
9	1	385049	PLT, MTG, SHAFT
10	1	385050	SHAFT, SUPPORT, GUIDE
11	1	283373	BLK, CLAMP






SECTION A-A



LOOSE CANS SET-UP

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	4	815212-003	RAIL, GUIDE, ROUND, SS, 12' LG
2	14	801312	CLAMP, RAIL, DOUBLE, 1.5 LG, SS, 2.5 CENTERS, ROUND HOLE
3	6	807728	ROD, ADJ, 5/8 DIA X 18 LG, 3/8-16 TAPPED THREAD, SS
4	9	801340	BKT, SWIVEL, 5/8 ROD, W/KNOB AND EYLET, POLYAMIDE
5	2	810110	ROD, ADJ, 5/8 X 6 LG, 5/16-18 TAP, SS
6	6	385051	POST, SUPPORT, GUIDE
7	3	385044	CHANNEL, SUPPORT, GUIDE
8	6	385045	CLAMP, MTG, GUIDE
9	6	385047	BKT, CLAMP
10	6	385049	PLT, MTG, SHAFT
11	6	385050	SHAFT, SUPPORT, GUIDE



NOTES
• INTERPRET PER ASME Y14.5M-1994.
• DIMENSIONS ARE IN INCHES (mm).
• DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
• BREAK SHARP EDGES AND CORNERS.
• PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
• CREATED IN SOLIDWORKS 2018.

CREATED IN SOLIDWORKS 2018
FILE I CONFIG
SIMILAR TO
DATE CREATED
DATE UPDATED
DATE UPDATED
DATE UPDATED
DATE UPDATED
DATE UPDATED
DATE UPDATED

384642 Loose Cans
Friday, April 16, 2021 11:57:27 AM
Friday, May 7, 2021 1:32:39 PM
Tuesday, April 20, 2021 11:00:24 AM
Friday, May 7, 2021 1:15:40 PM
sarcher

SIZE C
SCALE 1:20
3RD ANGLE
INCH
TOLERANCES
XX: ±1/32
X.XX: ±0.015
X.XXX: ±0.005
ANGLES: ±1°

MATERIAL
SEE BILL OF MATERIALS
FINISH
NONE

DESCRIPTION
ASSY, GUIDES, ENTRY, DIVIDER, LANE
NUMBER
384642

REV	DATE	BY	NOTE
REVISIONS			

C

B

A

ARPAC C SIZE FORMAT RS.1

4

3

2

1





D

C

B

A

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	4	300373	DEFLECTION ROLLER
2	4	309572-009	SHAFT, IDLER
3	2	314799-015	WLDMT. SUPPORT, CONV
4	2	315005-003	CROSSBAR, INTERMEDIATE, CSINK
5	4	315016	PLT, STIFF
6	7	345146	CROSSBAR, INTERMEDIATE
7	1	372291	PLT, SIDE, CONV, DIVIDER, DYNAMIC
8	1	372291-001	OPPOSITE
9	1	372292	STRIP, GUIDE, SIDE, BELT, CONV
10	2	372303	XBAR, END, CONV, INFEED
11	1	372306	ASSY, ROLLER, NOSE
12	1	372311	PLT, END, CONV
13	6	801296-002	RAIL, GUIDE, TEE, 1.60 W, 10' LG, SS
14	42	801359	CLAMP, RAIL, SINGLE, 1.5 LG, SS, ROUND HOLE
15	4	841410	LEVELER, ARTICULATING, 7400 # CAP, 3/4-10 STEM, 9.5 HIGH, CRS 3" BASE, 2 C'SUNK LAG HOLES, HEAVY LIP ON BASE
16	2	850128	EXTRUSION, UHMW, J-LEGS, 10' LG, FOR 11GA SHEET



NOTES
• INTERPRET PER ASME Y14.5M-1994.
• DIMENSIONS ARE IN INCHES (mm).
• DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
• BREAK SHARP EDGES AND CORNERS.
• PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
• CREATED IN SOLIDWORKS 2018.

CREATED IN SOLIDWORKS 2018
FILE \CONFIG SIMILAR TO DATE CREATED Tuesday, April 20, 2021
DATE UPDATED Wednesday, April 21, 2021 10:46:39 AM
UPDATED BY sarcher





ARPAC
A DURHAM COMPANY
2055 W. Irving Park Rd
Spartanburg, SC 29576
www.arpac.com

REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
C	1:12	SEE BILL OF MATERIALS	ASSY, CONV, INFEED, DIVIDER, LANE
3RD ANGLE	UNITS	FINISH	NUMBER
	INCH	NONE	384764
TOLERANCES			
XX: ±1/32			
X.XX: ±0.015			
X.XXX: ±0.005			
ANGLES: ±1°			

C

B

A



8	2	371175	PANEL, GUARD, COLLATOR
7	4	369992-001	ASSY, CARRIER, LUG, COLLATOR
6	4	369992	ASSY, CARRIER, LUG, COLLATOR
5	1	384780	ASSY, TRACK, COLLATOR, 60" LG BELT, LH
4	1	384781	ASSY, TRACK, COLLATOR, 60" LG BELT, RH
3	1	286728	ASSY, COLLATOR GUIDE & ADJ.
2	2	364832	ASSY, PULLEY, DRIVE, VERTICAL
1	1	384783	ASSY, DRIVE, COLLATOR, 460VAC, VPL SERVO

ITM	QTY	PART NUM	DESCRIPTION
-----	-----	----------	-------------

BILL OF MATERIALS			
-------------------	--	--	--

ARPAC		9511 WEST RIVER ST. SCHILLER PARK, IL 60176	
-------	--	--	--

UNLESS OTHERWISE SPECIFIED ALL DIMENSIONAL TOLERANCES:		FRACTIONS TWO (2) DECIMALS THREE (3) DECIMALS ANGLES	± 1/64 ± 0.010 ± 0.005 ± 0.5°
---	--	---	--

DRAWN: 4/22/2021	BY: SRA	SCALE: 1:8	SIZE: C
------------------	---------	------------	---------

DESCRIPTION:	FILENAME: 384766
--------------	------------------

ASSY, COLLATOR, SIDE, SERVO, VPL, 60" LG BELT

DRAWING NUMBER:

384766

ARPAC SIZE FORMAT RS

4

3

2



1

D





C

B

A



SECTION A-A





BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	364844-001	PLT, TRACK, COLLATOR, LOWER, LH
2	1	364833-001	PLT, BASE, COLLATOR, LH
3	2	195481	SPACER
4	1	195482	HEX, SHAFT, 5-5/16" LG
5	1	101929-027	RLR, IDLER, CRS, 1.750, BRG, FAFNIR NI PLT
6	1	195485-001	SPACER, LH
7	1	364834-001	BLOCK, LH
8	1	364842	SHAFT, ADJ., GEAR
9	1	817259	BUSH, OILITE, 0.627 X 0.753 X 1-1/2 LG
10	3	800439	WSHR, OILITE, 0.628 X 1.250 X 1/8 THK
11	1	364843	SCREW, TENSIONER
12	2	370629	GEAR, MITER, 18T, 20 DEG, 3/16 KEY, 5/8 BORE
13	2	195479	WASHER
14	1	195480	SHAFT, IDLER
15	4	364836	PULLEY, IDLER
16	1	195472	PLT, TOP, TENSIONER
17	1	195474	PLT
18	1	195473	PLT, BOTTOM, TENSIONER
19	1	195477	NUT
20	1	195476	SHAFT
21	1	364835	PLT, RETAINER
22	1	364837-001	PLT, TRACK, COLLATOR, UPPER, LH
23	2	195483	PLT
24	1	195484	PLT, 3 BOLT BRG MNT
25	1	221045	PLT, BRG, MTG
26	2	855398	BELT, TIMING, H PITCH, 1" W, 60" LG, 120 TEETH, ENDLESS, STEEL CORDS
27	2	800596	COLLAR, SHAFT, CLAMP, 2-PIECE, 5/8
28	2	195481-001	SPACER, 2.407 LG
29	2	286735	SPACER
30	1	371653	GUIDE, MIDDLE

NOTES	
• INTERPRET PER ASME Y14.5M-1994. DIMENSIONS ARE IN INCHES (mm). DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.	
• BREAK SHARP EDGES AND CORNERS.	
• PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.	
• CREATED IN SOLIDWORKS 2013.	
DATE	DESCRIPTION
2017 05 04	384780 Default
2017 05 04	Thursday, May 4, 2017 10:17:09 AM
2021 04 21	Wednesday, April 21, 2021 6:01:43 PM
2021 04 21	sarcher
2017 05 04	Thursday, May 4, 2017 3:51:09 PM
2021 04 21	Wednesday, April 21, 2021 6:01:24 PM
2021 04 21	sarcher







5555 W. Irving Park Rd.
Schaumburg, IL 60176
www.arpac.com

REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
C	1:5	SEE BILL OF MATERIALS	ASSY, TRACK, COLLATOR, 60" LG BELT, LH
3RD ANGLE	UNITS		
	INCH		
TOLERANCES	FINISH	NUMBER	
XX: ±1/32 X.XX: ±0.15 X.XXX: ±0.05 ANGLES: ±1°	NONE	384780	



SECTION A-A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	364844	PLT, TRACK, COLLATOR, LOWER, RH
2	2	195481	SPACER
3	1	101929-027	RLR, IDLER, CRS, 1.750, BRG, FAFNIR NI PLT
4	1	195482	HEX, SHAFT, 5-5/16" LG
5	1	195480	SHAFT, IDLER
6	2	195479	WASHER
7	4	364836	PULLEY, IDLER
8	1	195473	PLT, BOTTOM, TENSIONER
9	1	195474	PLT
10	1	195472	PLT, TOP, TENSIONER
11	1	195476	SHAFT
12	1	364842	SHAFT, ADJ. GEAR
13	2	370629	GEAR, MITER, 18T, 20 DEG, 3/16 KEY, 5/8 BORE
14	1	364833	PLT, BASE, COLLATOR, RH
15	1	364834	BLOCK, RH
16	1	195485	CLUTCH BRACKET
17	2	195483	PLT
18	1	195484	PLT, 3 BOLT BRG MNT
19	1	195477	NUT
20	3	800439	WSHR, OILITE, 0.628 X 1.250 X 1/8 THK
21	1	364843	SCREW, TENSIONER
22	1	817259	BUSH, OILITE, 0.627 X 0.753 X 1-1/2 LG
23	1	364835	PLT, RETAINER
24	1	221045	PLT, BRG, MTG
25	1	364837	PLT, TRACK, COLLATOR, UPPER, RH
26	2	855398	BELT, TIMING, H PITCH, 1" W, 60" LG, 120 TEETH, ENDLESS, STEEL CORDS
27	2	800596	COLLAR, SHAFT, CLAMP, 2-PIECE, 5/8
28	2	195481-001	SPACER, 2.407 LG
29	2	286735	SPACER
30	1	371653	GUIDE, MIDDLE


NOTES
 • INTERPRET PER ASME Y14.5M-1994.
 • DIMENSIONS ARE IN INCHES (mm).
 • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.
 • BREAK SHARP EDGES AND CORNERS.
 • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.
 • CREATED IN SOLIDWORKS 2013.

CREATED IN SOLIDWORKS 2013
 FILE: I:\CONFIG
 DATE CREATED: Wednesday, May 3, 2017 12:46:35 PM
 DATE UPDATED: Thursday, April 22, 2021 10:17:19 AM
 UPDATED BY: sarcher
 DATE CREATED: Thursday, May 4, 2017 2:58:16 PM
 DATE UPDATED: Wednesday, April 21, 2021 6:10:18 PM
 UPDATED BY: sarcher



384781384781

REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
C	1:5	SEE BILL OF MATERIALS	ASSY, TRACK, COLLATOR, 60" LG BELT, RH
3RD ANGLE	UNITS	FINISH	NUMBER
INCH		NONE	384781
TOLERANCES			
XX: ±1/32			
X.XX: ±0.015			
XXX: ±0.005			
ANGLES: ±1°			



ITEMS 32 AND 33 ARE NOT SHOWN

31	221945.002	BKT. SENSOR DRIVE COLLECTOR LH
30	221945.001	BKT. SENSOR DRIVE COLLECTOR RH
29	232927	ADAPTOR, PULLEY LIMITER TORQUE
28	817233	SPIRICAL WASHER
27	341327	W/LDMT. SCREW ADJ. 1/2"X16" COLLECTOR, 87LG
26	809055	BELT, TIMING, 1/2 P-1-1/2W, 110 LG, TWIN POWER (DOUBLE SIZED)
25	800578	COLLAR, SHAFT, C-1, S/WELCE, 5/8"
24	193193	BKT
23	2193192	SHAFT, ADJ. SWIVEL
22	193191	PLT. ADJ. SWIVEL
21	193190	SPACER, CMT1.60
20	2193189	NUT, ADJ. SWIVEL
19	802770	BGR, FLG. 3/4-1.4-3-BOLT, SINGLE-LOCK, STANDARD DUTY
18	807680	BUSH, TAPER, OD. 1 BORE X 1-13/16 LG
17	800682	BUSH, TAPER, OD. 34 BORE X 1-13/16 LG
16	801251	PULLEY, TIMING, 30T, 1/2 P-1-1/2 W, SD BUSHING REQUIRED
15	193187	SPACER, PILLOW BLOCK
14	817229	PGR, PILLOW BLK, 1" ID, SINGLE-LOCK STANDARD-DUTY
13	2193186	SHAFT
12	807096	COLLAR, SHAFT, CMT1.6 PCECE, 3/4, EXTREME CL8867
11	232928	PULLEY, P38-8M-20, MOD
10	819392	LIMITER, TORQUE, MULT. RESET OPTI SIZE1 3/4" BORE, EXTREME
9	286730	SHAFT, HAND WHEEL
8	809078	HD.W/MT, S/WELCE, W/CPLG, 5/8, 5 1/2OD
7	294732	W/LDMT, BKT, MTG. SERV MOTOR
6	822280	BUSH, TAPER, OD. 32MM BORE X 1-11/4 LG
5	817226	PULLEY, TIMING, 38T, 8MM BORE, 20MM W, SH BUSHING REQUIRED
4	807792	BELT, TIMING, 8MM P, 20MM W, 1600MM LG, 200T
3	849316	MOTOR, SERV, 37 IN.7LB, 475V 1PM 480VAC, KINETIX 5500C CONTROLLER
2	870571	GEARBOX, IN-LINE, PLANE, 1:1 RATIO, 20.1, VPL-115003-P112AA
1	221881	MNT. GEAR REDUCER
ITEM	QTY	PART NAME DESCRIPTION

		9511 WEST RIVER ST. SCHILLER PARK, IL 60178	
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONAL TOLERANCES:		FRACTIONS TWO (2) DECIMALS ± 0.010 THREE (3) DECIMALS ± 0.005 ANGLES ± 0.5°	
DRAWN: 4/22/2021	BY:	SCALE: 1:6	SIZE: D
FILENAME: 384783			
DESCRIPTION: ASSY. DRIVE, COLLATOR, 460VAC, VPL SERVO			
		DRAWING NUMBER: 384783	

ARPAC C SIZE FORMAT RSL1

4

3

2


1

D

C

B

A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	1	385024	FRAME, CONV. TRANSFER, SIDE, 18 WD BELT
2	1	872419	BELT, MODULAR, MAT TOP, ACETAL, HP8505-18IN
3	4	385029	RAIL, GUIDE, BELT
4	2	385028	RAIL, GUIDE, SIDE, BELT
5	1	309571-016	SHAFT, TAIL, 19.00 LG
6	3	310689-017	SHAFT, IDLER, CSINK
7	3	300373-012	RLR, DEFLECTION, L = 18.20
8	2	839632	BRG, FLG, 1 ID, 4-BOLT
9	1	311656	WASHER, RETAINER
10	1	385020	SHAFT, DRIVE, CONV. TRANSFER, SIDE
11	4	800568	COLLAR, SHAFT, CLAMP, 2-PIECE, 1 ID x 1 3/4 OD
12	1	315027	PIN, LOCKING, DRIVE
13	4	315016	PLT, STIFF
14	2	374168-001	WLDMT, SUPPORT, CONV
15	4	841410	LEVELER, ARTICULATING, 7400 # CAP, 3/4-10 STEM, 9.5 HIGH, CRS 3" BASE, 2 O-SUNK LAG HOLES, HEAVY LIP ON BASE
16	6	872417	SPKT, NS8500-24T 1IN I_PA
17	6	872418	SPKT, NS8500-24T 1-1/2IN S_PA
18	2	315005-009	CROSSBAR, INTERMEDIATE, CSINK
19	1	872585	GEARMOTOR, FLEXBLOC, Ø1" HOLLOW SHAFT, 25:1, 70 RPM, 1.5 HP, 230/460 VAC, W/ TORQUE ARM
20	1	385008	FRAME, CONV. BRIDGE, 12 WD BELT
21	2	385021	RAIL, GUIDE, SIDE, BELT
22	3	385019	RAIL, GUIDE, BELT
23	1	309571-015	SHAFT, TAIL, 12.73 LG
24	3	310689-018	SHAFT, IDLER, CSINK, 12.73 LG
25	3	300373-019	RLR, DEFLECTION, A=12.66
26	1	872606	BELT, MODULAR, MAT TOP, ACETAL, HP8505-12IN
27	2	385027	PLT, CONNECT, CONV
28	2	385030	PLT, MTG, SHAFT, SPROCKET
29	1	385031	GUARD, BELT, CONV
30	1	385032	GUARD, BELT, CONV, TRANSFER
31	4	800970	RETAINER RING, SELF SET, 1-1/2" SQ SHAFT SS C-TYPE W/SETSCREW

4

3

2

1

NOTES	
• INTERPRET PER ASME Y14.5M-1994. DIMENSIONS ARE IN INCHES (mm). DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY.	
• BREAK SHARP EDGES AND CORNERS.	
• PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED.	
• CREATED IN SOLIDWORKS 2018.	

CREATED IN SOLIDWORKS 2018	
FILE I CONFIG	385007385007
SIMILAR TO	~
DATE CREATED	Tuesday, July 7, 2020 1:14:35 PM
DATE UPDATED	Friday, October 22, 2021 10:44:18 AM
UPDATED BY	sarcher
DATE CREATED	Wednesday, May 5, 2021 5:13:15 PM
DATE UPDATED	Friday, October 22, 2021 10:44:30 AM
UPDATED BY	sarcher

ARPAC	
3850 W. Irving Park Rd. Schiller Park, IL 60176 www.arpac.com	






REV	DATE	BY	NOTE
REVISIONS			
SIZE	SCALE	MATERIAL	DESCRIPTION
C	1:12	SEE BILL OF MATERIALS	ASSY, CONV, TRANSFER, SIDE
3RD ANGLE	UNITS		
	INCH		
TOLERANCES	FINISH		
XX: ±1/32	NONE		
X.XX: ±0.015			
X.XXX: ±0.005			
ANGLES: ±1°			
		NUMBER	
		385007	

C

B

A

BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	3	802653	LATCH, VISE-ACTION
2	3	221651	BRK, STOP, LATCH
3	2	369934	HINGE, DOOR, 38.25 LG
4	2	369933	DOOR, LEXAN, SIDE
5	1	383413	HINGE, DOOR, 72.625 LG
6	1	383414	DOOR, LEXAN, 26.88 X 72.625
7	1	369935	COVER, SIDE, DOOR, LEXAN, NARROW
8	1	369936	COVER, SIDE, DOOR, LEXAN, WIDE
9	1	285333	FRAME, MTG, GUARD, HOPPER
10	2	298636	BKT, MTG, SWITCH, DOOR
11	1	240594	WLDMT, MTG, DOOR, NARROW
12	1	328583	WLDMT, MTG, DOOR, WIDE
13	1	298730	BKT, MTG, SWITCH, DOOR
14	2	370549	PANEL, GUARD, LEXAN, MAGAZINE
15	1	371143-001	PANEL, GUARD, LEXAN
16	1	385415	COVER, LEXAN, W/CUTOUTS, MAG, EXT
17	1	385416	COVER, LEXAN, BOTTOM
18	1	369938	COVER, LEXAN, TOP




NOTES			CREATED IN SOLIDWORKS 2018		 5055 N. Irving Park Rd Chicago, IL 60630 www.arpac.com		SIZE		SCALE		MATERIAL		DESCRIPTION	
• INTERPRET PER ASME Y14.5M-1994. • DIMENSIONS ARE IN INCHES (mm). • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF ARPAC LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS 2018.			MODEL		FILE \ CONFIG SIMILAR TO 383412 DATE CREATED Monday, February 17, 2014 3:37:53 PM DATE UPDATED Monday, May 10, 2021 3:10:11 PM sarcher		3RD ANGLE 		C 1:16		SEE BILL OF MATERIALS		ASSY, COVERS, LEXAN, MAG, EXTENDED	
DRAWN		DATE CREATED Monday, May 10, 2021 2:29:57 PM DATE UPDATED Monday, May 10, 2021 11:43:19 AM sarcher		TOLERANCES XX: ±1/32 X.XX: ±0.15 X.XXX: ±0.005 ANGLES: ±1°		FINISH NONE		NUMBER 385414						

D




C

B


A



BILL OF MATERIALS			
ITEM	QTY	NUMBER	DESCRIPTION
1	2	390688	PLT, SUPPORT, BAR, TRANSFER
2	1	390689	BAR, TRANSFER, PRODUCT
3	2	390690	PLT, SHIM



SECTION A-A






REV	DATE	BY	NOTE
REVISIONS			
MATERIAL			DESCRIPTION
SEE BILL OF MATERIALS			ASSY, PLT, TRANSFER, CONV
FINISH			NUMBER
NONE			390696

NOTES		CREATED IN SOLIDWORKS	NVENIA
• INTERPRET PER ASME Y14.5-2018. • DIMENSIONS ARE IN INCHES [mm]. • DIMENSIONS IN PARENTHESES FOR REFERENCE ONLY. • BREAK SHARP EDGES AND CORNERS. • PROPRIETARY NOTICE: THIS INFORMATION IS THE PROPERTY OF NVENIA LLC AND SHALL NOT BE USED FOR ANY PURPOSE OTHER THAN THAT FOR WHICH IT WAS OBTAINED. • CREATED IN SOLIDWORKS.		750 N Wood Dale Rd Wood Dale, IL 60191 nvenia.com	
		MODEL	FILE \CONFIG SIMILAR TO
		DATE CREATED	390696\Default
		DATE UPDATED	Wednesday, December 23, 2020 2:55:00 PM
		UPDATED BY	sarcher
		DRAFT	DATE CREATED
		DATE UPDATED	Thursday, October 21, 2021 4:57:37 PM
		UPDATED BY	sarcher

SIZE	SCALE	MATERIAL	DESCRIPTION
B	1:4	SEE BILL OF MATERIALS	ASSY, PLT, TRANSFER, CONV
3RD ANGLE	UNITS	FINISH	NUMBER
	INCH	NONE	390696
TOLERANCES			
X.X: ±1/32			
X.XX: ±.015			
X.XXX: ±.005			
ANGLES: ±1°			

IN9001

REV.	ZONE	ECN	DESCRIPTION	DATE	BY
------	------	-----	-------------	------	----

**NOTES:**

- 1) ALL DIMENSIONS ARE FOR REFERENCE ONLY..
- 2) EXHAUST ALL DOWNSTREAM PRESSURE BEFORE TURNING THE VHS HAND VALVE TO THE CLOSED POSITION.
- 3) GAUGE AND PRESSURE SWITCH NOT INSTALLED, TO PREVENT DAMAGE DURING SHIPPING.

STANDARD SPECIFICATIONS:

PROOF PRESSURE: 1.5 MPa (218 psi)
OPERATING PRESSURE RANGE: 0.2~1.0 MPa (29~145 psi)
FLUID: AIR
AMBIENT AND FLUID TEMPERATURE: 0~50°C (32~122°F) WITH NO FREEZING
NOMINAL FILTRATION RATING: 5 µm
VOLTAGE: 24 VDC

PLEASE SEE WWW.SMCWORLD.COM FOR SPECIFIC PRODUCT INFORMATION

8	AN40-N04	SILENCER	1
7	ISE40A-N01-Y-P-X531	PRESSURE SWITCH	1
6	AV4000-N04-5DZ-X260	SOFT-START VALVE	1
5	K50-MP1.0-N01MS	GAUGE, PRESSURE	1
4	AW40-N04D-Z-B	FILTER/REGULATOR	1
3	Y400T-A	INTERFACE	2
2	AN30-N03	SILENCER WITH 3/8" THREAD	1
1	VHS40-N04B-Z	VALVE, 3 PORT LOCK OUT	1
ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
UNITS	mm	SCALE	FREE
DRAWN BY	DICK A. SHULER	DATE	11/20/2018
APPROVED BY			
REFER TO EDM SYSTEM		AIR COMBINATION	
PRINTED DOCUMENTS ARE UNCONTROLLED REFER TO EDM SYSTEM FOR CONTROLLED DOCUMENT		DRAWING/PART No.	
CAD FILE		SIZE	
AC40-DUW02467		B	
		SHEET 1 OF 1	
		REVISION	
		0	


REFERENCE NUMBER: US132912



Electrical Schematics




B.1. Electrical Schematics

This section contains the electrical schematics for this machine.




CANOPY SAFETY ZONE


PAGE #1
24 VDC
24 25



PAGE #1
20
0VDC



* NOTE: SEE PAGE #3 FOR
440G-T2NBBPH-1L
LOCKABLE DOOR SWITCH
TERMINAL WIRING DETAILS CHART



NVENIA
A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 10/26/2021
MODEL: TS-2300		SHEET: 2 OF
BLUE MARBLE		DRAWING NUMBER: 210011-02

PAGE #1
24 VDC
24 25



MAGAZINE SAFETY ZONE

PAGE #1
20
0VDC

440G-T2NBBPH-1L LOCKABLE DOOR SWITCH TERMINAL WIRING DETAILS

TERMINAL	COLOR	DESCRIPTION
A1	GRN	SOLENOID POWER
A2	BLUE	0VDC
11	RED	SAFETY A
12	RED/BLK	SAFETY A
21	RED/WHT	SAFETY B
22	RED/YEL	SAFETY B
33	BRN	+24 VDC
34	WHT	AUX. CONTACT (TO PLC)
41	N/A	*NOT CONNECTED
42	N/A	*NOT CONNECTED
53	N/A	*NOT CONNECTED
54	N/A	*NOT CONNECTED

**REMOVE JUMPER BETWEEN 12 AND 41



NVENIA
A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 3 OF
BLUE MARBLE		DRAWING NUMBER: 210011-03

24 25
24 VDC

460VAC



11

12

13

1


1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----



POWERFLEX 525 MAIN DRIVE SET UP (PRESET) (DIFFERENT THAN DEFAULT)

DISPLAY	PARAMETER DESCRIPTIONS	SETTING
P031	RATED VOLTAGE	460
P033	MOTOR OL CURRENT	*
P046	START SOURCE	5 ETH
P047	SPEED REFERENCE	15 ETH
P041	ACCELERATION TIME	1
P042	ACCELERATION TIME	0.5
P044	MAXIMUM FREQUENCY	60
A543	START AT POWER UP	1.0


USE VFD CABLE PROVIDED. THIS IS RATED FOR TRAYS. ALSO, USE SHIELD CONNECTORS AT MOTOR SIDE.




NIVENIA

A DURAVENT COMPANY


REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 4 OF
BLUE MARBLE		DRAWING NUMBER: 210011-04





NVENIA
A DURAVANT COMPANY


REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 09/26/2021
MODEL: TS-2300		SHEET: 7 OF
BLUE MARBLE		DRAWING NUMBER: 210011-07




NVENIA
A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 8 OF
BLUE MARBLE		DRAWING NUMBER: 210011-08

INPUT MODULE #1




INPUT MODULE #2




NVENIA
A DURAVANT COMPANY


REV. A	SIZE B
DESIGNER: JIT	DATE: 05/25/2021
MODEL: TS-2300	SHEET: 9 OF
BLUE MARBLE	DRAWING NUMBER: 210011-09




GENERAL WIRING OF 3 WIRE DEVICES



PROXIMITY SWITCH



*DO NOT USE 2 WIRE SENSORS



REMOTE INPUT/OUTPUT

RI:6:6.1

PIN NUMBER


PORT NUMBER



I/O BLOCK #

NVENIA


A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 12 OF
BLUE MARBLE		DRAWING NUMBER: 210011-12







GENERAL WIRING OF 3 WIRE DEVICES



PROXIMITY SWITCH




*DO NOT USE 2 WIRE SENSORS



NVENIA

A DURAVANT COMPANY

REV. A	SIZE B
DESIGNER: JIT	DATE: 05/26/2021
MODEL: TS-2300	SHEET: 13 OF
BLUE MARBLE	DRAWING NUMBER: 210011-13



NVENIA			
A DURAVANT COMPANY			
REV. A	ELECTRICAL SCHEMATIC	SIZE: B	
DESIGNER: JIT		DATE: 05/26/2021	
MODEL: TS-2300		SHEET: 14 OF	
BLUE MARBLE		DRAWING NUMBER: 210011-14	

SAFETY BLOCK
M23 POWER INPUT, 8X 8 PIN INPUTS
ALLEN BRADLEY #898D-P88RT-M19
ARPAC #804005-855



M23 CABLE
YELLOW STRAIGHT 19 PIN
ALLEN BRADLEY #889M-R19RM-15
ARPAC #804005-856



TO POWER, INPUTS, SAFETY RELAY

8 PIN M12 FIELD WIREABLE
MURR #7000-17301-0000000
ARPAC #804010-501



8 PIN M12 CABLE WITH FLYING LEADS
MURR #889D-F8AB-5
ARPAC #804003-204

SPARE PORT MUST HAVE JUMPER




SHORTING PLUG FOR SAFETY BLOCK
ALLEN BRADLEY #898D-B1RU-DM
ARPAC #804010-502




NVENIA
A DURAVANT COMPANY


REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 15 OF
BLUE MARBLE		DRAWING NUMBER: 210011-15




NVENIA A DURAVANT COMPANY				
REV.	A	ELECTRICAL SCHEMATIC	SIZE:	B
DESIGNER:	JIT		DATE:	11/01/2021
MODEL:	TS-2300		SHEET:	16 OF
BLUE MARBLE			DRAWING NUMBER:	210011-16







BLANK MAGAZINE LOCATION




NVENIA				
A DURAVANT COMPANY				
REV.	A	ELECTRICAL SCHEMATIC	SIZE:	B
DESIGNER:	JIT		DATE:	05/26/2021
MODEL:	TS-2300		SHEET:	17 OF
BLUE MARBLE			DRAWING NUMBER:	210011-17



</



POINT I/O POWER SUPPLY
ETHERNET SWITCH



NVENIA				
A DURAVANT COMPANY				
REV.	A	ELECTRICAL SCHEMATIC	SIZE:	B
DESIGNER:	JIT		DATE:	05/26/2021
MODEL:	TS-2300		SHEET:	1 OF
BLUE MARBLE			DRAWING NUMBER:	210011-DD01

DL1 460VAC
DL2 3Ø
DL3 60HZ TO PAGE #3,4



ENCLOSURE COOLING
FAN KIT
8.4W, 24VDC 0.35A

DIVIDER ENCLOSURE

440G-T2NBBPH-1L LOCKABLE LOCKABLE DOOR SWITCH TERMINAL WIRING

TERMINAL	COLOR	DESCRIPTION
A1	GRN	SOLENOID POWER
A2	BLUE	0VDC POWER
11	RED	SAFETY A
12	RED/BLK	SAFETY A
21	RED/WHT	SAFETY B
22	RED/YEL	SAFETY B
33	BRN	+24 VDC
34	WHT	AUX. CONTACT (TO PLC)
41	N/A	*NOT CONNECTED
42	N/A	*NOT CONNECTED
53	N/A	*NOT CONNECTED
54	N/A	*NOT CONNECTED


**REMOVE JUMPER BETWEEN 12 AND 41



NVENIA

A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 2 OF
BLUE MARBLE		DRAWING NUMBER: 210011-DD02



POWER FLEX 525 DRIVE SET UP
(DIFFERENT THAN DEFAULT)

DISPLAY	PARAMETER DESCRIPTIONS	SETTING
P031	RATED VOLTAGE	460
P033	MOTOR OL CURRENT	*
P046	START SOURCE 1	5 (ETH)
P047	SPEED REFERENCE 1	15 (ETH)
P041	ACCELERATION TIME	1 SEC
P042	DECELERATION TIME	1 SEC
P044	MAX FREQUENCY	90 HZ
A541	AUTO RESTART TRIES	0.0
A543	START AT POWER UP	1.0

* SET TO THE MAXIMUM ALLOWABLE MOTOR CURRENT

POWER FLEX 525 DRIVE SET UP
(DIFFERENT THAN DEFAULT)

DISPLAY	PARAMETER DESCRIPTIONS	SETTING
C128	EN ADDR SELECT	1
C129	EN IP ADDR CFG 1	10
C130	EN IP ADDR CFG 2	255
C131	EN IP ADDR CFG 3	255
C132	EN IP ADDR CFG 4	**
C133	EN SUBNET CFG 1	255
C134	EN SUBNET CFG 2	255
C135	EN SUBNET CFG 3	255
C136	EN SUBNET CFG 4	0

**SEE PAGE #8 FOR LAST IP NUMBER

0103CB
CIRCUIT BREAKER NUMBER
PAGE NUMBER



NVENIA
A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 04/20/2021
MODEL: TS-2300		SHEET: 3 OF
DRAWING NUMBER: 210011-DD01		
BLUE MARBLE		

FROM PAGE #1
460VAC

DL1
DL2
DL3

DL1
DL2
DL3



FROM PAGE #1
+24VDC
D24 D20


BUS SHARED POWER
TO DRIVE #2

BUS SHARED CONTROL POWER
TO DRIVE #2

BUS TO BUS CONNECTOR
#2198-H040-ADP-IN

GROUND CHASSIS
TO GROUND

CONTROL POWER



D490 HOME 3 INPUT
D20
D20


DIGITAL INPUTS
1 IN1
2 COM
3 IN2
4 SHLD

ALLEN BRADLEY
KINETIX 5500
2198-H015-ERS
AXIS MODULE
DIVIDER X SERVO CONTROLLER AND DRIVE
(DXSCD)


SAFE OFF

OSB+ BYPASS PLUS
OSB- BYPASS MINUS
S1 SAFETY ENABLE 1
SC SAFETY ENABLE COM
S2 SAFETY ENABLE 2

FROM PAGE #2
D272
D20
D273



*INSTALL WITH 1.6" CLEARANCE TOP AND BOTTOM



MOTOR BRAKE
11 GROUND MOTOR
22 BRAKE CABLE
WHEN USED

SINGLE CABLE
#2090-CSWM1DF-14AAxx

CLAMP SHIELDED
CABLE TO SERVO
DIVIDER X CABLE


DXSCD
(#1585J-M8CBJM-2)

DYSCD TO PAGE #5
(#1585J-M8CBJM-DM3)

FROM PAGE #8

2198-H2DCK CONVERTER KIT PINDUT		
TERMINAL	SIGNAL	WIRE COLOR
1	SIN+	BLACK
2	SIN-	WHITE/BLACK
3	COS+	RED
4	COS-	WHITE/RED
5	ECOM	WHITE/GRAY
7	EPWR_9V	ORANGE
10	DATA-	WHITE/GREEN
11	TS+	WHITE/ORANGE
14	EPWR_5V	GRAY

DIGITAL INPUTS (IOD) CONNECTOR PINDUT	
IOD PIN	DESCRIPTION
1	HIGH SPEED REGISTRATION/HOME POSITION (DUAL FUNCTION INPUT)
2	I/O COMMON
3	HIGH SPEED REGISTRATION INPUT. HIGH/LOW OR LOW/HIGH TRIGGERS REGISTRATION
4	I/O CABLE SHIELD TERMINATION




NVENIA
A DURAVANT COMPANY


REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 4 OF
BLUE MARBLE		DRAWING NUMBER: 210011-DD04

DIVIDER ENCLOSURE

POINT I/O RACK #1 - INPUT MODULE #1



POINT I/O RACK #1 - INPUT MODULE #2



TERMINAL LAYOUT FOR 1734-IB8




NVENIA

A DURAVANT COMPANY


REV. A	ELECTRICAL SCHEMATIC	SIZE B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 6 OF
BLUE MARBLE		DRAWING NUMBER: 210011-DD06

DIVIDER ENCLOSURE

POINT I/O RACK #1 - INPUT MODULE #3



POINT I/O RACK #1 - OUTPUT MODULE #4




TERMINAL LAYOUT FOR 1734-DB8E



1734-TB

TERMINAL LAYOUT FOR 1734-IB8



1734-TB


NVENIA
A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 10/26/2021
MODEL: TS-2300		SHEET: 7 OF
BLUE MARBLE		DRAWING NUMBER: 210011-DD07


MULTI-PIN PLUG DISTRIBUTOR FESTO NEDU-L4R1-M8G3-M12G8

DIVIDER ENCLOSURE

POINT I/O RACK #1 - OUTPUT MODULE #4



ADDRESS	PIN	TERM
0:4/00	0	D0
0:4/01	1	D1
0:4/02	2	D2
0:4/03	3	D3
0:4/04	4	D4
0:4/05	5	D5
0:4/06	6	D6
0:4/07	7	D7



TERMINAL LAYOUT FOR 1734-DB8E

00	01
02	03
04	05
06	07


1734-TB

TERMINAL LAYOUT FOR 1734-IB8


10	11
12	13
14	15
16	17

1734-TB

PROXIMITY SWITCH




P1_300	INPUT 1	WHT
P1_301	INPUT 2	BRN
D490	INPUT 3	GRN
	INPUT 4	YEL
D24	UB+	GRY
	INPUT 5	PINK
D20	UB-	BLU
	INPUT 6	RD



B1 DIVIDER AXIS X OVERTRAVEL + RIGHT
NC, SIES-8M-24V-K-2.5-M8D
B2 DIVIDER AXIS X OVERTRAVEL - (LEFT)
NC, SIES-8M-24V-K-2.5-M8D
B3 DIVIDER AXIS X HOME POSITION
NO, SIES-8M-24V-K-2.5-M8D
SPR. SERVO HOME INPUT P.

P1_302	INPUT 1	WHT
P1_303	INPUT 2	BRN
D590	INPUT 3	GRN
	INPUT 4	YEL
D24	UB+	GRY
	INPUT 5	PINK
D20	UB-	BLU
	INPUT 6	RD



B1 DIVIDER AXIS Y OVERTRAVEL + FORWARD
NC, SIES-8M-24V-K-2.5-M8D
B2 DIVIDER AXIS Y OVERTRAVEL - (REVERSE)
NC, SIES-8M-24V-K-2.5-M8D
B3 DIVIDER AXIS Y HOME POSITION
NO, SIES-8M-24V-K-2.5-M8D
SPR. SERVO HOME INPUT P.

NVENIA
A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 10/26/2021
MODEL: TS-2300		SHEET: 7 OF
BLUE MARBLE		DRAWING NUMBER: 210011-DD07

DIVIDER ENCLOSURE

POINT I/O RACK #1 - INPUT MODULE #5

D24

1734-IB8		
TERM	PIN	ADDRESS
SPARE — P1_500	I0 0	I:5/00
SPARE — P1_501	I1 1	I:5/01
SPARE — P1_502	I2 2	I:5/02
SPARE — P1_503	I3 3	I:5/03
SPARE — P1_504	I4 4	I:5/04
SPARE — P1_505	I5 5	I:5/05
SPARE — P1_506	I6 6	I:5/06
SPARE — P1_507	I7 7	I:5/07

+24VDC

D24


TERMINAL LAYOUT FOR 1734-IB8

10	11
0	1
12	13
2	3
14	15
4	5
16	17
6	7

1734-TB

NVENIA
A DURAVANT COMPANY

REV. A	ELECTRICAL SCHEMATIC	SIZE: B
DESIGNER: JIT		DATE: 05/26/2021
MODEL: TS-2300		SHEET: 8 OF
BLUE MARBLE		DRAWING NUMBER: 210011-DD08



NVENIA			
A DURAVANT COMPANY			
REV. A	ELECTRICAL SCHEMATIC	SIZE: B	
DESIGNER: JIT		DATE: 05/26/2021	
MODEL: TS-2300		SHEET: 9 OF	
BLUE MARBLE		DRAWING NUMBER: 210011-DD09	